


TN3270 Terminal Reference Guide



Copyright © February 2003 by LXE Inc.
All Rights Reserved
TN3270A136RFGD
E-SW-TN3720RG-H

Notices

LXE's TN3270 is terminal emulation software developed by LXE. The software is installed in computer equipment. Any reference, whether direct or implied, to any LXE RF equipment requires the reader to refer to the specific RF equipment's User Manuals for cautions, warnings and federal notices (e.g. FCC, EMC, UL, CE, etc.).

Copyright Notice:

This manual is copyrighted. All rights are reserved. This document may not, in whole or in part, be copied, photocopied, reproduced, translated or reduced to any electronic medium or machine-readable form without prior consent, in writing, from LXE Inc.

Copyright © February, 2003 by LXE Inc. An EMS Technologies Company.
125 Technology Parkway, Norcross, GA 30092 U.S.A. (770) 447-4224

Trademarks:

LXE® is a registered trademark of LXE Inc.

All other brand or product names are trademarks or registered trademarks of their respective companies or organizations. When this manual is in PDF format: "Acrobat ® Reader Copyright © 1987-2001 Adobe Systems Incorporated. All rights reserved. Adobe, the Adobe logo, Acrobat, and the Acrobat logo are trademarks of Adobe Systems Incorporated." applies.

Notice:

LXE Inc. reserves the right to make improvements or changes in the *software products* described in this manual at any time without notice. While reasonable efforts have been made in the preparation of this document to assure its accuracy, LXE assumes no liability resulting from any errors or omissions in this document, or from the use of the information contained herein. Further, LXE Incorporated, reserves the right to revise this publication and to make changes to it from time to time without any obligation to notify any person or organization of such revision or changes.

Revision Notice

TN3270 Terminal Reference Guide

Upgrade From Revision G to Revision H

Section	Explanation
Notices	Update Notices, Copyrights and Trademarks.
Entire Manual	Remove references to 2330 as the 2330 is obsolete. Remove all references to RTM setup.
Chapter 1 – Introduction	Add “IBM TE Related Manuals” section.
Chapter 2 – Daily Operation	Add “Starting TN3270” and “Exiting TN3270” sections.
Chapter 3 – TN3270 Configuration Utility	Revise “IBM24 – TN3270 TE Files” section. Revise parameters: ScreenSize, NormalIO, Com1Interrupt, Com2Parity, Com2StopBits, Com2BaudRate, Com2DataBits, Com2HalfDuplex, Com2Xon, Com2HwFlowCtrl, Com2TimeOut, Com2PassTermChar, Com2Interrupt. Add parameter: EAN128Fnc1 Remove parameters: RemoteRTM, LocalRTM.
Chapter 4 – Code Pages and Character Sets	Revise “Creating EBCDIC National Character Sets” section.
Appendix B – Key Maps	Add VX4 keymaps.



Table of Contents

CHAPTER 1 INTRODUCTION	1-1
How To Use This Guide	1-1
Document Conventions	1-2
Getting Help.....	1-2
IBM TE Related Manuals.....	1-3
The TN3270 Terminal Emulator	1-4
Entering Messages	1-4
Remote Setup From Host.....	1-5
Window Manager	1-5
CHAPTER 2 DAILY OPERATION	2-1
Introduction	2-1
Starting TN3270.....	2-1
Single TE	2-1
The TE Selection Menu	2-2
Exiting TN3270 Plus.....	2-3
Hosts	2-4
Connect with the Host	2-4
Autologin	2-4
Unsuccessful Host Connection	2-4
Keys and Key Sequences.....	2-5
Keyboard Lock and Reset.....	2-5
DOS Computer Special Keys	2-6
Legacy Key Incompatibility	2-6
TN3270 TE and the 2325	2-7
IBM TN3270 Function Descriptions	2-8
Function Keys.....	2-13
LXE DOS Autotransmit Function	2-14
Data Entry	2-18
Entering Messages	2-18
Interpreting the Status Line	2-20
Window Manager	2-22
The Virtual Screen and the Computer Display.....	2-22
Window Movement Types	2-25
Lock Window Mode	2-30

Cursor Tracking Mode.....	2-33
Status Line	2-35
Message Line	2-36
CHAPTER 3 TN3270 CONFIGURATION UTILITY	3-1
Introduction	3-1
Password Access Levels	3-1
Changed Radio Parameters	3-2
Configuration Files	3-2
Directory Structure	3-2
\IBM24 - TN3270 TE Files	3-2
The TN3270 Configuration Utility	3-3
Pre-Configured Passwords.....	3-3
Menu Components.....	3-4
Using the Configuration Program.....	3-6
Main Menu Display	3-7
Screen Displays	3-9
System Menu Options.....	3-10
Emulation Menu Option.....	3-14
Protocol Menu Option	3-26
Radio Menu Option – 6400 and 6500 Systems	3-41
Platform Menu	3-42
Exit With Save Option.....	3-60
Exit Without Save Option.....	3-60
CHAPTER 4 CODE PAGES AND CHARACTER SETS	4-1
Introduction	4-1
Displayable Characters	4-2
Default Code Page	4-2
LXE Character Set.....	4-3
Default TE EBCDIC Character Set	4-4
Creating EBCDIC National Character Sets	4-5
Example: UK EBCDIC Character Set	4-6
Keyboard Mapping.....	4-8
Special Keys	4-8
Alphanumeric Keys	4-8
Modifying the Keyboard Map	4-9
Messages.....	4-10
Default Messages.....	4-10
Editing The Message.Txt File	4-10

Editing ASCII Files	4-12
Editing Files at the Computer	4-12
Edit then Transfer Files Using a PC Card	4-13
Transfer Files Using DOS REMDISK/REMSERV	4-15
CHAPTER 5 3270 PROGRAMMER'S REFERENCE	5-1
Introduction	5-1
Primary Audience	5-1
Examples.....	5-1
About RF Performance	5-1
Data Stream	5-2
IBM Attributes, Orders, and Commands	5-3
Attributes	5-3
Commands	5-6
Extra Features	5-11
Requirements for Extra Feature Commands.....	5-11
Screen Design for Computer Setup Commands	5-13
Match Fields	5-14
Match Field Commands.....	5-16
Computer Setup	5-17
Command String for Computer Setup	5-17
Left Justify Mode: p2.....	5-20
Clear Mode: p3	5-21
Truncate Mode: p4.....	5-22
Advance Mode: p5.....	5-22
Auto Transmit After Data Stream Print: p6.....	5-23
Printer Carriage Return per Line: p7	5-23
Printer Line Feed per Line: p8.....	5-24
Status Line Display Mode: p9	5-24
Command String for Wildcard Match Characters	5-25
Command String for Window Setup	5-27
Display Modes: p2	5-29
Valid Window Positions: p3 and p4	5-30
Window Movement: p5	5-32
Quadrant for Cursor: p6.....	5-33
Beep Pattern Command	5-33
Printing a Field	5-36
Screen Print Command	5-37
Display Window and Virtual Screen	5-38
Status Line	5-39
Message Line	5-40
USA/Canada EBCDIC Code Page 00037	A-1

LXE Character Set.....	A-2
Decimal - Hexadecimal Equivalents	A-3
DOS U.S. PC Standard Character Set	A-5
APPENDIX B KEY MAPS	B-1
The MX1 Keypad	B-1
Alpha-Numeric Keypad (60 Key)	B-1
The MX1 Numeric-Alpha Keypad (41 Key).....	B-3
The MX2 Keypad	B-5
38-key Keypad (Also 2325 Keypad)	B-5
48-key Keypad	B-7
The MX3 Keypad	B-9
The VX1, VX2 and VX4 Keyboards.....	B-11
The 1380 Keyboard	B-13

INDEX**Illustrations**

Figure 2-1 TN3270 TE Function Key Editor.....	2-13
Figure 2-2 VMT Virtual Screen Display versus Computer Display Window	2-23
Figure 2-3 HHC Virtual Screen Display versus Computer Display Window.....	2-24
Figure 2-4 Full Window Movement of a HHC Display	2-25
Figure 2-5 Quadrant Movement of a HHC Display	2-26
Figure 2-6 Full and Quadrant Vertical Movement of a VMT Display	2-27
Figure 2-7 HHC Horizontal Display Wrapping.....	2-29
Figure 2-8 HHC Vertical Display Wrapping	2-29
Figure 2-9 Valid Window Positions - 12 and 25 Row x 80 Column	2-30
Figure 2-10 HHC Valid Window Positions - 10 Row x 20 Column	2-31
Figure 2-11 HHC Valid Window Positions - 20 Row x 20 Column	2-31
Figure 2-12 HHC Virtual Display With Arbitrary Labels	2-33
Figure 2-13 Cursor Tracking Display Examples	2-34
Figure 3-1 Configuration Utility - Sample Menu Components	3-4
Figure 3-2 Configuration Utility Main Menu	3-7
Figure 3-3 Main Menu on a Full Screen VMC with 2.4GHz Radio.....	3-9
Figure 3-4 Main Menu on a Half Screen VMC with 2.4GHz Radio	3-9
Figure 3-5 Main Menu on a Small Screen HHT with 2.4GHz Radio.....	3-9
Figure 4-1 Code Page 00437	4-2
Figure 4-2 LXE Character Set - Abbreviated	4-3
Figure 4-3 USA/Canada IBM EBCDIC.....	4-4
Figure 4-4 U.K. IBM EBCDIC	4-6
Figure 5-1 IBM 3270 Data Stream with RF Header and Trailer	5-2
Figure 5-2 3270 Screen Trigger (Auto Transmit) Feature.....	5-4

Figure 5-3 3270 Screen with Computer Setup Command	5-13
Figure 5-4 Constructing a Predecessor Field	5-14
Figure 5-5 Match Field Example	5-14
Figure 5-6 3270 Screen with Predecessor and Match Fields	5-16
Figure 5-7 Left Justify Off.....	5-20
Figure 5-8 Left Justify On.....	5-20
Figure 5-9 Valid Window Positions - 12 and 25 Row x 80 Column	5-31
Figure 5-10 Valid Window Positions - 10 Row x 20 Column.....	5-31
Figure 5-11 Valid Window Positions - 20 Row x 20 Column.....	5-31
Figure 5-12 Beep Pattern Command String.....	5-34
Figure 5-13 Beep Pattern Template	5-35
Figure 5-14 Beep Pattern Example	5-35
Figure 5-15 Print Command Example	5-36
Figure 5-16 Virtual Screen and Display Window Relationship.....	5-38



Table of Contents

CHAPTER 1 INTRODUCTION	1-1
How To Use This Guide	1-1
Document Conventions	1-2
Getting Help.....	1-2
IBM TE Related Manuals.....	1-3
The TN3270 Terminal Emulator	1-4
Entering Messages	1-4
Keyboard Data Entry.....	1-4
Barcode Data Entry	1-4
RS-232 Data Entry	1-4
Remote Setup From Host.....	1-5
Window Manager	1-5



Chapter 1 Introduction

How To Use This Guide

This guide provides detailed information on the features and functionality of LXE's TN3270 Terminal Emulation (TE) software as it relates to LXE's 2.4GHz DOS computers. Use this reference guide as you would any other source book: reading portions to learn about the system, and then referring to it when you need more information about a particular subject. This guide takes you through all aspects of the TN3270 TE and the host/client interaction of DOS mobile computers.

Note: Use this guide in conjunction with the manuals delivered with your LXE DOS computers and Access Points.

This chapter briefly describes the LXE TN3270 TE and LXE DOS mobile computers, the reference guide structure, and how to contact LXE. The remainder of the guide describes the TN3270 TE and its function in greater detail.

Chapter 2 "Daily Operation" contains information relating to the hardware and software setup of the DOS computers. It lists and explains keypress functions.

Chapter 3 "TN3270 Configuration Utility" contains information and instructions relating to the configuration utility resident in each computer. Configuration program instructions are included in this chapter.

Chapter 4 "Code Pages and Character Sets" describes the EBCDIC code pages and the LXE character set resident in each computer. Instructions are included for editing and copying ASCII files from PC to PC Card to computer.

Chapter 5 "3270 Programmer's Reference" contains relevant information for the 3270 programmer when programming the host application to communicate with LXE devices.

Appendix A "EBCDIC Code Pages" contains graphics of the Code Page and LXE Character Set.

Appendix B "Key Maps" contains keyboard specific mapping for LXE DOS equipment when it is running the TN3270 terminal emulation program.

Document Conventions

This Reference Guide uses the following document conventions:

Convention	Meaning
ALL CAPS	All caps are used to represent disk directories, file names, and application names.
“Quotes”	Indicates the title of a chapter or a section, subject, topic, element or point within a chapter (for example, “Document Conventions”).
[BRACKETS]	Indicates a key on the keyboard (for example, [CTRL]).
<i>Note:</i>	Keyword that indicates immediately relevant information.
<i>Caution:</i> 	Keyword that indicates a cautionary warning to follow.
Attention:	Keyword that indicates vital or pivotal information to follow.

Getting Help

All LXE manuals are now available on one CD and they can also be viewed/downloaded from the LXE website. Contact your LXE representative to obtain the LXE Manuals CD (Product No. 9000A426LXEMANUALS).

You can also get help from LXE by calling the telephone numbers listed on the LXE Manuals CD, in the file titled "Contacting LXE". This information is also available on the LXE website www.lxe.com.

IBM TE Related Manuals

The following lists the manuals that are available on the LXE Documentation CD-ROM (9000A426LXEMANUALS). These manuals provide references that may be required when using the IBM TN3270 TE with LXE certified DOS computers.

These manuals provide setup, operating instructions, software / accessory installation instructions:

- 1380 Reference Guide
- 1390 Reference Guide
- 2325 Reference Guide
- MX1 Reference Guide
- MX2 Reference Guide
- MX3 Reference Guide
- VX1 Reference Guide
- VX2 Reference Guide
- VX4D Reference Guide
- 6224 Session Manager Reference Guide
- DOS Autoconfigurator Instructions

The following manuals describe how to use SNMP to configure, monitor and update LXE computers with 2.4GHz radios:

- Client Configuration Manager Reference Guide
- SNMP Agent Reference Guide

The TN3270 Terminal Emulator

The TN3270 TE product is LXE's DOS based TELNET 3270 Terminal Emulator (TE) and allows the user to enter standard data into the IBM system.

Entering Messages



For complete information and operating procedures for entering messages, please refer to Chapter 2 "Daily Operation" section titled "Entering Messages" in this guide.

The LXE DOS computer accepts data entry from the keyboard, barcode scanner and the auxiliary (RS-232) input port.

Keyboard Data Entry

Once the TN3270 TE is started, data can be entered with the computer keyboard. Keyboard data can be entered into a data field and transmitted to the host. You might respond to a prompt sent by the host application with a keyboard entry, such as a menu listing choices for your next action.

Barcode Data Entry

The LXE DOS computer supports an accessory barcode reading device for reading barcode labels. Keyboard data entries can be mixed with barcode data entries. Any scanner that decodes the barcode internally and outputs an RS-232 data stream may be used. The serial port parameters may need to be changed (using the TN3270 configuration utility) to match the parameters of the scanner. Refer to the specific equipment's hardware manual for more information on which COM ports are available for use with a scanner.

RS-232 Data Entry

The LXE DOS computer accepts input from an RS-232 device connected to the RS-232 port of the computer. The DOS computer processes data from the RS-232 port the same way it processes keyed data. The data is entered at the cursor position, and the data is subject to all of the barcode/RS-232 input menu parameters, such as truncate.

Remote Setup From Host

The TN3270 TE can take advantage of LXE's Remote Setup feature. Host application programmers can specify computer software operating parameters in the host-to-terminal data stream. Remote setup applies to:

- wild card local edit characters.
 - window manager parameters.
 - beep pattern.
-

Window Manager

The TN3270 TE takes advantage of the LXE's Window Manager feature.



For complete information when using the Window Manager feature, please refer to Chapter 2 "Daily Operation" section titled "Window Manager" in this guide.

Note: This feature does not apply to DOS computers with a full size display.



Table of Contents

CHAPTER 2 DAILY OPERATION	2-1
Introduction	2-1
Starting TN3270	2-1
Single TE	2-1
The TE Selection Menu	2-2
Multiple TEs.....	2-2
Modifying the TE Selection Menu.....	2-2
Exiting TN3270 Plus.....	2-3
Hosts	2-4
Connect with the Host	2-4
Autologin	2-4
Unsuccessful Host Connection	2-4
Keys and Key Sequences.....	2-5
Keyboard Lock and Reset.....	2-5
DOS Computer Special Keys	2-6
Legacy Key Incompatibility	2-6
TN3270 TE and the 2325	2-7
IBM TN3270 Function Descriptions	2-8
ATTN	2-8
BACKTAB	2-8
CLEAR	2-8
Cursor Block/Underline Hotkey.....	2-8
DELETE	2-8
Display Version Hotkey	2-8
E_INPUT.....	2-8
ERASE	2-8
Enter	2-9
ERROR RESET	2-9
Exit Program Hotkey	2-9
Function Key Editor Hotkey	2-9
HELP Hotkey	2-9
HOMEKEYA, HOMEKEYB	2-9
INQUIRY Hotkey	2-9
INSERT	2-9
LDUB	2-9
Log File Toggle Hotkey	2-10
NEW LINE KEY.....	2-10

NEXT or TAB	2-10
PA1, PA2, PA3	2-10
[PF1 - PF24]	2-10
Printer On/Off Hotkey	2-11
PRT_FLD	2-11
PRT_SCRN	2-11
RDUB	2-11
Status Line Toggle Hotkey	2-11
SW Rev	2-11
SYS_REQ	2-11
Window Down Hotkey	2-11
Window Right Hotkey	2-12
Window Left Hotkey	2-12
Window Up Hotkey	2-12
Window Home Hotkey	2-12
Function Keys	2-13
Function Key Editing	2-13
LXE DOS Autotransmit Function	2-14
Introduction	2-14
MX1 with SE1223 Integrated Scanners	2-15
Enable the DOS Autotransmit Function	2-15
Disable the DOS Autotransmit Function	2-15
LXE 1380 / 1390 and VX1 / VX2 / VX4 with LS3203 or LS3603 Tethered Scanners ..	2-16
Enable the DOS Autotransmit Function	2-16
Disable the DOS Autotransmit Function	2-16
LXE 1380 / 1390 and VX1 / VX2 / VX4 with PSC 53XX Tethered Scanner	2-17
Enable the DOS Autotransmit Function	2-17
Disable the DOS Autotransmit Function	2-17
Data Entry	2-18
Entering Messages	2-18
Keyboard Data Entry	2-18
Barcode Data Entry	2-18
RS-232 Data Entry	2-19
Interpreting the Status Line	2-20
Operating Modes	2-20
Status Line Messages	2-20
Window Manager	2-22
The Virtual Screen and the Computer Display	2-22
Window Movement Types	2-25
Full Window Movement	2-25
Quadrant Movement	2-26
Window Movement Keys	2-28
Cursor Position	2-28
Display Wrapping	2-29
Lock Window Mode	2-30
Valid Window Positions	2-30

The VMT Screens	2-30
The HHC Screens	2-31
Window Movement in Lock Window Mode	2-32
Cursor Tracking Mode.....	2-33
Window Moving Methods	2-33
Display Example	2-33
Basic Moves	2-34
Quadrant Choice.....	2-34
Status Line	2-35
Status Line Modes.....	2-35
Display Appearance	2-35
Operation.....	2-35
Status Line and Message Line.....	2-35
Message Line.....	2-36
Physical Display	2-36
Reviewing the Message Line	2-36
Message Line Doesn't Follow the Window.....	2-36

Illustrations

Figure 2-1 TN3270 TE Function Key Editor.....	2-13
Figure 2-2 VMT Virtual Screen Display versus Computer Display Window	2-23
Figure 2-3 HHC Virtual Screen Display versus Computer Display Window.....	2-24
Figure 2-4 Full Window Movement of a HHC Display	2-25
Figure 2-5 Quadrant Movement of a HHC Display.....	2-26
Figure 2-6 Full and Quadrant Vertical Movement of a VMT Display	2-27
Figure 2-7 HHC Horizontal Display Wrapping.....	2-29
Figure 2-8 HHC Vertical Display Wrapping	2-29
Figure 2-9 Valid Window Positions - 12 and 25 Row x 80 Column	2-30
Figure 2-10 HHC Valid Window Positions - 10 Row x 20 Column	2-31
Figure 2-11 HHC Valid Window Positions - 20 Row x 20 Column	2-31
Figure 2-12 HHC Virtual Display With Arbitrary Labels	2-33
Figure 2-13 Cursor Tracking Display Examples	2-34



Chapter 2

Daily Operation

Introduction

This chapter describes those features of the TN3270 DOS computers that are used on a daily basis.

Starting TN3270

TN3270 is configured to start as follows:

- TN3270 is started automatically after the device boots if it is the only TE loaded on the computer.
- If multiple Terminal Emulators (TE's) are installed, the TE Selection Menu is displayed after boot. To launch TN3270, select the appropriate choice from the menu.

TN3270 is started manually by returning to the TE Selection Menu with the following command:

c:\teselect

- TN3270 is started automatically if it is the only TE installed.
- The TE Selection Menu is displayed if multiple TE's are installed. Select the appropriate choice from the TE Selection Menu.

Single TE

Power on the DOS computer and the TN3270 welcome screen is automatically displayed. When the TE is closed with an Alt-X keypress, the screen is cleared and the system returns to the DOS prompt.

The TE Selection Menu

Multiple TEs

In the event there is more than one Terminal Emulator (TE) installed in the computer, the user is presented with the TE Selection Menu listing the available terminal emulators that can be accessed using the computer.

For example, a user could see:

```
[3] Launch 3270  
[A] Launch ANSIPLUS  
[E] Exit to DOS
```

Please select option: [3, A, E]?

Upon selecting one of the terminal emulator options, the desired TE is launched. When the user selects E, the screen is cleared and the DOS prompt is displayed. When the TE is closed with an Alt-X keypress, the screen is cleared and the menu is presented again.

Note: The system administrator may change almost every facet of the menu display, including suppressing the “Exit to DOS” option, by modifying the variables found at the top of TESELECT.BAT. Details on modifying the TESELECT.BAT file are included in the “DOS Autoconfigurator Instructions”, included on the LXE Manuals CD.

Modifying the TE Selection Menu



Please refer to the “DOS Autoconfigurator Instructions”, included on the LXE Manuals CD for complete details on modifying the TE Selection Menu.

Exiting TN3270 Plus

The behavior of the LXE computer when exiting TN3270 can be customized by suppressing the “exit to DOS” option in the TE Selection Menu. For more information on suppressing the prompt, please refer to the “DOS Autoconfigurator Instructions”, included on the LXE Manuals CD.

If TE Selection Menu “Exit to DOS” Option is not Suppressed:

Single TE: <Alt-X> from the TE takes the system to a DOS prompt.

Dual TE: <Alt-X> from the TE takes the system to the TE Selection Menu with the “Exit to DOS” option.

If TE Selection Menu “Exit to DOS” Option is Suppressed:

Single TE: <Alt-X> from the TE takes the system to a DOS prompt.

Dual TE: <Alt-X> from the TE takes the system to the TE Selection Menu without the “Exit to DOS” option.

Hosts

Connect with the Host

For DOS computers with a single TE loaded, the computers are automatically connected to the host after the bootup process.

Autologin

The Autologin feature enables computers to automatically log on to a TELNET host computer upon initial communication.

Autologin relieves the user from repeating the same logon information every time the computer is powered up or rebooted.

The Autologin script file contains the host prompts and user replies needed for logging in. The autologin script is created in each computer using the Configuration Utility.

If the autologin sequence is unsuccessful, you can log on with one of the following methods:

Log on manually from the computer.

or

Power down until the problem is corrected. Then, power on again.

Refer to Chapter 3 “TN3270 Configuration Utility” for details on configuring the Autologin feature.

Unsuccessful Host Connection

If the computer cannot connect with the host (or the address is invalid), error messages are displayed and computer control returns to the computer.

Note: There may be a short pause while attempting to contact the host.

When the computer is unable to connect to the host, an error message is displayed on the screen explaining the inability to connect.

For Example:

```
Unsuccessful Host Connection
No Host found
Please
Power Down
```

Refer to the FTP manual for an explanation of error messages.

Keys and Key Sequences

This section describes the LXE RF DOS computer keys and key sequences in the IBM TN3270 terminal emulation.

Most key sequences require two keystrokes. To use an LXE key sequence, you must:

- press either the [2nd], [ALT], [SHIFT], or [CTRL] key
- and press the associated key

Note: Depending on which computer you are using you may need to press and release the [2nd], [ALT], [SHIFT], or [CTRL] key before pressing the associated key.

Keyboard Lock and Reset

Reset key sequence for DOS computers: [CTRL] [R]

Under certain conditions, attempted input from the keyboard locks the keyboard from further input. Since the computer does not differentiate among input from the keyboard, input from the scanner, and input from the RS-232 port; any condition that locks one locks the others.

Press [CTRL] [R] to restore the computer to normal operation.

DOS Computer Special Keys

Note: See "TN3270 Keyed Functions" for further information on these special keys.

Function	DOS Key Sequence
Cursor Block/Underline (Toggle)	Alt-B
Function Key Editor	Alt-F
Display Help	Alt-H
Inquiry or INQ	Alt-I
Log file on/off	Alt-L
Printer enable on/off	Alt-P
Status line toggle	Alt-T
Software Version Displayed	Alt-V
Exit program	Alt-X
Small Screen Only:	
Window Up	Ctrl-Up Arrow
Window Down	Ctrl-Down Arrow
Window Left	Ctrl-Left Arrow
Window Right	Ctrl-Right Arrow
Window Home	Ctrl-Home or Alt-Up Arrow

*Note: **Window Home** - The MXI can use Alt-Up Arrow only on the Alpha-Numeric keypad. The MXI can use Ctrl-Home and Alt-Up Arrow with the Numeric-Alpha keypad.*

Legacy Key Incompatibility

The following Legacy keys have no equivalent in DOS:

- Swap Application
- Change RF ID
- Shift + 5 to exit programmable function keys

If a macro containing non-legacy equivalents is defined in a DOS-based TE, those keys will be transmitted as spaces to a Legacy terminal. The exception is Alt-R (hotkey for RTM) which translates into a XFKYSTP key, which is a Shift+5 in Legacy.

Legacy macros containing the Swap Application key or the Change RF ID key are ignored by the DOS-based TE.

TN3270 TE and the 2325

Note: When running TN3270 TE, the 2325 Flag key (International) operates as a Shift key.

The International Key on the 2325 keypad (in 2325 normal mode) is used for generating an international character, for example, é, ö, etc. The key does not function as the International key when running TN3270 – instead it functions as a Shift key.

The 2325 does not have the following keys normally found on a computer keyboard:

- F11
- F12
- Right Alt
- Right Ctrl
- Scroll Lock
- Pause/Break
- Print Screen/SysReq
- PgDown
- Num Lock
- Numeric keypad keys
- PgUp
- Home
- End

Following are the unique 2325 DOS keypresses to use when running the TN3270 TE:

Keyed Function	Keypresses
Home	Shift+Left Arrow
Window Home	Alt+Up Arrow
HOMEKEYA	Shift+Left Arrow
HOMEKEYB	Shift+Left Arrow
NEXT	Tab
F6-F10	FN+(F1-F5)
F16-F20	Alt+FN+(F1-F5)

Please see previous section titled “DOS Computer Special Keys” and the following section titled “TN3270 Keyed Functions.”

IBM TN3270 Function Descriptions

ATTN

This function interrupts the application program and only works when the host system is on.

BACKTAB

This function moves the cursor back to the first position of an input field. When the cursor is not in an input field or is in the first position of an input field, the cursor moves to the first position of the previous input field. If the screen is unformatted, this function moves the cursor to row 1, column 1 of the screen.

CLEAR

This function is an Attention Identifier key. This function causes the computer to send a message to the host and the host responds as specified by the Application program.

Cursor Block/Underline Hotkey

The Cursor Block/Underline Toggle hotkey is used to change the outline of the on-screen cursor from a small square (block) to an underline. Changing the cursor size from underline to block may make it easier to see under bright light conditions.

DELETE

This function deletes data from an input field. When you press this key, the character at the cursor location is deleted, and all characters to the right of the cursor shift one position to the left.

Null characters are inserted into the right of the field as the characters in the field shift to the left.

Display Version Hotkey

Using the Display Version hotkey causes the computer to display the current TN3270 version information on the screen and the computer's IP address.

Press any key to remove the information from the screen and continue.

E_INPUT

Erases all input fields and moves the cursor to the beginning of the first input field. When the cursor is not in an input field, this function will move the cursor to row 1 column 1 and the data is erased.

If the screen is unformatted this key sequence clears the screen and the cursor moves to row 1 column 1.

ERASE

Erases all characters from the cursor position to the end of the entry field. On an unformatted screen this function erases all characters from the cursor position to the end of the screen. If the cursor is not in an input field pressing this key sequence causes the keyboard to lock.

Enter

The [Enter] keypress function is determined by the cursor's location and the application's function.

When in an input field, pressing Enter moves the cursor from the current position to the next input field. If there are no more input fields on the screen, control is returned to the application.

When the cursor is on a menu item and the [Enter] key is pressed, either the menu option function is activated or, if the menu option has a submenu of further options, the submenu is displayed.

ERROR RESET

This function unlocks the keyboard and causes the computer to exit insert mode.

Exit Program Hotkey

Using the Exit Program hotkey causes the computer to close the current TN3270 application and return control to the DOS prompt.

Function Key Editor Hotkey

Using the Function Key Editor hotkey causes the computer to begin running the Function Key Editor in the foreground while the current application remains in the background.

See the section titled "Function Keys" for editing instruction.

HELP Hotkey

Shows LXE key sequences for TN3270 functions.

HOMEKEYA, HOMEKEYB

This function causes the cursor to move to the first input position. If the screen is unformatted, pressing this key sequence moves the cursor to row 1 column 1.

INQUIRY Hotkey

The Inquire (Communications Test) hotkey checks the communication on the RF channel.

INSERT

Enables Insert mode. This mode allows a character to be inserted into an existing input field without overwriting the data. When a character is inserted at the cursor position, characters to the right of the cursor are shifted one character position to the right.

Use the reset key sequence to cancel Insert mode.

LDUB

The LDUB function moves the cursor two spaces at a time to the left.

Log File Toggle Hotkey

When logging is enabled, the application writes all pertinent data to the log text file. The log file may be disabled until there is a need to troubleshoot the computer or the system.

The log file can be viewed using a DOS text editor.

NEW LINE KEY

This function moves the cursor to the first input position in the next line. If there are no input positions the cursor moves to row 1, column 1 of the screen.

If the screen is unformatted the cursor moves to the first character position of the next line.

NEXT or TAB

This function moves the cursor from the current position to the next input field.

If the screen is unformatted pressing this function moves the cursor to row 1, column 1.

PA1, PA2, PA3

The [PA1 - PA3] keys communicate with the application program. The application program defines their use.

IBM Keys **LXE Keys**

PA1	[CTRL] [F1]
PA2	[CTRL] [F2]
PA3	[CTRL] [F3]

If you press a program access key while the computer is either not connected to an application or is trying to access an unavailable operation, the keyboard locks. Press the reset key sequence to unlock the keyboard.

[PF1 - PF24]

The Program Function [PF1 - PF24] keys communicate with the application program.

IBM Keys **LXE Keys**

PF1 - PF10	[F1 - F10]
PF11 - PF20	[ALT] [F1 - F10]
PF21 - PF24	[SHIFT] [F1 - F4]

Each PF key sends a particular signal to the application program. If you press a program function key while the computer is not connected to an application or is trying to access an unavailable operation, the keyboard locks. Press the reset key sequence key to unlock the keyboard.

Printer On/Off Hotkey

Use the Printer On/Off hotkey to turn the printer on before sending data through the RS-232 port. Use the hotkey again to turn the printer off.

When [ALT] [P] is pressed, a prompt is displayed on the screen. The prompt's contents are directly related to the current printer status and is automatically removed after print status is confirmed.

For example:

When printing is active at the time of the keypress, "Disable Printing?" is displayed. Press "Y", the message is replaced with "Printing Disabled" and the print function is disabled. Press "N" and the message is replaced with "Printing Enabled" and the print function remains active.

When printing is not active at the time of the keypress, "Enable Printing?" is displayed. Press "Y", the message is replaced with "Printing Enabled" and the print function is active. Press "N" and the message is replaced with "Printing Disabled" and the print function remains disabled.

PRT_FLD

This function causes the computer to send the first unprotected entry field of a formatted screen to a device connected to the RS-232 port.

PRT_SCRN

This function sends the entire screen on the computer to a device attached to the computer's RS-232 port.

RDUB

The RDUB function moves the cursor two spaces at a time to the right.

Status Line Toggle Hotkey

The Toggle Status Line function temporarily displays the status line on the screen.

SW Rev

Displays the current software revision level resident in the computer and the computer's IP address.

SYS_REQ

This function switches ownership of the screen between the application program and the system software. The result of this function is dependent on the Host or TN Server.

Window Down Hotkey

The window moves down according to the type of window movement enabled in the application, but the cursor does not move. When an 8-Line display windows moves vertically in full window movement, the display moves 8 lines at a time. The display does not overlap any of the area it previously occupied. When the 8-Line display window moves vertically in quadrant movement, the display window moves 4 lines at a time. The display overlaps half of the area it previously occupied.

Window Right Hotkey

The window moves right according to the type of window movement enabled in the application, but the cursor does not move. When the display window moves horizontally in full window movement, the display window moves 20 columns if it is a 20-column display, or 40 columns if it is a 40 column display. When a 20 column display window moves horizontally in quadrant movement, the display window moves 10 columns. A 40 column display moves 20 columns.

Window Left Hotkey

The window moves left according to the type of window movement enabled in the application , but the cursor does not move. When the display window moves horizontally in full window movement, the display window moves 20 columns if it is a 20-column display, or 40 columns if it is a 40 column display. When a 20 column display window moves horizontally in quadrant movement, the display window moves 10 columns. A 40 column display moves 20 columns.

Window Up Hotkey

The window moves up according to the type of window movement enabled in the application, but the cursor does not move. When an 8-Line display windows moves vertically in full window movement, the display moves 8 lines at a time. The display does not overlap any of the area it previously occupied. When the 8-Line display window moves vertically in quadrant movement, the display window moves 4 lines at a time. The display overlaps half of the area it previously occupied.

Window Home Hotkey

The Window Home key sequence causes the window to move to row 1, column 1 (or the beginning of the form) on the screen according to the type of window movement enabled in the application. The cursor does not move.

Function Keys

Function keys can be defined, edited, copied, and saved at the DOS computer (when TN3270 TE is active). The computer's function key changes are saved between TN sessions in the computer.

Note: *Do not program function keys that the host application is currently using. Doing so overrides previously specified functions by the host.*




Figure 2-1 TN3270 TE Function Key Editor

Each of the 24 function keys can represent a different, predefined string of keystrokes that are “played” into the emulation as though they came from the keyboard.

LXE keyboards may have fewer keys than their IBM counterparts. Most IBM key functions, however, can be generated by either a single key or a combination of keys.

Note: *The maximum length of a recordable macro (function key's value) is 31 keystrokes.*

Function Key Editing

Note: *The TN3270 TE must be running.*

To begin editing a function key, press Alt-F.

The TN3270 TE Function Key Editor screen is displayed.

Press a Function Key between F1 and F24.

To edit the function key, press Alt-1.

Press the keys that will be activated when the function key is pressed.

As you enter keystrokes, the data appears between the { } symbols. For example:

{SEND¹} {NEXT} {CLEAR}

When in edit mode, Alt-B to backspace (erase last entry):

To clear the function key, press Alt-2.

All keystrokes previously defined for the function key are cleared.

To save the changed function key value, press Alt-3.

The function key's new value is saved in the computer.

Remove the Editor screen by pressing ESC.

¹ Always use {SEND} instead of {Enter} and {Next} instead of {TAB}.

LXE DOS Autotransmit Function

Introduction

DOS Autotransmit is an enhancement made to the LXE TN3270 Terminal Emulators running in DOS computers using 2.4 GHz radios. DOS Autotransmit will automatically transmit barcode data when the data has an ASCII DLE appended to it.

Each scanner must be configured to add the autotransmit suffix – directions on the process for configuring the scanners (listed below) is contained later in this document.

This capability is directed toward specific scanners connected to the following LXE equipment:

Scanner or Scanner Module	Equipment
SE1223 Module	MX1 Hand Held Computers
PSC 53XX LS3203 and LS3603	VX1, VX2, VX4, 1380 and 1390 Vehicle Mount Computers
SE1200 Module	MX2 and 2325 Hand Held Computers
SE923	MX3

Important: Enabling this feature makes EVERY input field an autotransmit field. When there is a need to scan MULTIPLE fields before transmitting then it is best to use the IBM AutoEnter command.


MX1 with SE1223 Integrated Scanners

The barcodes contained in this section can be used with integrated scanners on an MX1 running the TN3270 terminal emulator.


Enable the DOS Autotransmit Function

Scan the following barcodes in order of appearance:


<Data><Suffix 1>




Scan Suffix 1




1



0




1



6



Cancel




Cancel Number

The last four barcodes are the same as a Hex 10 (10h) or DLE.

Disable the DOS Autotransmit Function

Scan this barcode to disable the DOS Autotransmit function.

Data As Is



LXE 1380 / 1390 and VX1 / VX2 / VX4 with LS3203 or LS3603 Tethered Scanners

The barcodes contained in this section can be used with tethered scanners on a 1380, 1390, VX1, VX2 or VX4 running the TN3270 terminal emulator.

Enable the DOS Autotransmit Function

Scan the following barcodes in order of appearance:

<Data><Suffix>



Suffix



Prefix/Suffix Values

1



0



1



6



Cancel



The last four barcodes are the same as Hex 10 (10h) or DLE.

Disable the DOS Autotransmit Function

Scan this barcode to disable the DOS Autotransmit function.

Data As Is



**LXE 1380 / 1390 and VX1 / VX2 /
VX4 with PSC 53XX Tethered
Scanner**

The barcodes contained in this section can be used with tethered scanners on a 1380, 1390, VX1, VX2 or VX4 running the TN3270 terminal emulator.


**Enable the DOS Autotransmit
Function**

Scan the following barcodes in order of appearance:

Enter Postamble



1 0



0 0



0 0



0 0



The last four barcodes represent scanning 10 and then scanning three nulls.

**Disable the DOS Autotransmit
Function**

Scan this barcode to disable the DOS Autotransmit function.

None



Data Entry

The Data Entry section provides basic information to help you communicate with the host computer.

Entering Messages

The LXE computer accepts data entry from the keyboard, barcode scanner, and the auxiliary (RS-232) input port.

Keyboard Data Entry

Once the computer establishes communication with the host, you can enter data with the keyboard. The application program sends messages to the computer that prompt you to make your next keyboard entry. For example, the application may prompt you to press an [F1] through [F24] key. You cannot enter data when the keyboard is locked.

When the keyboard is locked, an X is displayed in the status line.

Pressing a function key transmits a signal to the host. The host responds as specified by the application program.

Note: Do not program function keys that the host application is currently using. Doing so overrides previously specified functions by the host.

Refer to “Keys and Key Sequences” in this chapter for the function key sequences used by your computer.

Barcode Data Entry

The computers support an accessory barcode reading device for reading barcode labels. Generally, Hand Held Computer (HHC) users prefer the Long Range or Standard Range barcode scanner endcap. You can intermix keyboard data entries with barcode data entries.

The standard barcode is Code 39 (C39). All legal Code 39 characters are accepted. The standard computer software supports the following barcode formats:

- Code 39 (C39)
- Code 128 (A, B, C)
- UPC-A
- UPC-E
- Codabar (CDB)
- Code 11 (C11)
- MSI Plessey
- Discrete 2 of 5 (C25)
- Interleaved 2 of 5 (I25)
- EAN-8
- EAN-13
- EAN-128
- Code 93

RS-232 Data Entry

The DOS computers accept input from an RS-232 device connected to the RS-232 port. The computer processes data from the RS-232 port the same way it processes barcode data. The data is entered at the cursor position, and the data is subject to all of the barcode/RS-232 input menu parameters, such as truncate. You must activate the RS-232 input device before you can send data to or receive data from the RS-232 port.

Interpreting the Status Line

The status line displays symbols, words, and numerals to indicate the status of the session with the host. The status line is always presented on the last line of the physical display.

Operating Modes

The computer has two modes for presenting the status line on the computer display:

- | | |
|-----------|---|
| Exception | The Exception mode displays the status line when a message (an error code, for example) is written to the status line or the status of the terminal/host session has changed. |
| Off | The Off mode inhibits the display of the status line. |

Status Line Messages

The following table lists the status line messages, their significance, and the action to take when a particular indicator or set of indicators appear.

LXE Indicator	Condition	IBM Equivalent
INA	The terminal session is pending an LU/LU activation (SNA).	None
LOCK	A host transmission has locked the computer keyboard. Wait for the host to unlock the keyboard.	None
-OP-	You tried to perform an action in the wrong screen location. Use the [RESET] key sequence to unlock the keyboard.	<-Stick Figure->
OP>	You have attempted to enter more data (insert mode) than the field can hold. Use the [RESET] key sequence to unlock the keyboard.	Stick Figure>
NUM	You have attempted to enter non-numeric data into a numeric only field. Use the [RESET] key sequence to unlock the keyboard.	Stick Figure NUM
PLU	The computer session is connected to an application program (SNA).	Solid Block (cursor shape)
SCP	The computer session is connected to the System Services Control Point (SNA).	Stick Figure

LXE Indicator	Condition	IBM Equivalent
sta	The computer has powered on, established communication with the network controller, and is waiting to communicate with the host.	None
SYS	The host has disabled the keyboard. Wait for the host to enable the keyboard, or use the [RESET] key sequence to unlock the keyboard.	SYSTEM
T	Communication with the host is in progress.	Clock Figure
UOW	The computer session is connected to the SNA controller process but not to the PLU or SSCP.	? in Block
X	The host has disabled the keyboard. Wait for the host to enable the keyboard, or use the [RESET] key sequence to unlock the keyboard.	X
<i>Exception: The [INQ] key is not disabled when X is displayed in the status line.</i>		
-f	The operation that you have requested is not available. Use the [RESET] key sequence to unlock the keyboard.	-f
?+	The computer does not accept the operation that you attempted. Use the [RESET] key sequence to unlock the keyboard.	?+
-s	The computer does not recognize the symbol that you have keyed in. Use the [RESET] key sequence to unlock the keyboard.	-S

Window Manager

LXE's window manager is a software program that controls the virtual screen display of screen data on the LXE computer display window. Window manager display choices are specified from the host computer.

Window manager provides two *display modes* for displaying the information from the virtual screen at the computer: **cursor tracking mode** and **lock window mode**.

The *display window* is the screen on the computer that allows portions of the virtual screen to be seen.

The *virtual screen* is the full 25 line x 80 column screen generated by the host computer. An example of a virtual screen is the screen you view when you use a personal computer in DOS mode.

Lock window mode locks the display window in a permanent window position relative to the virtual screen.

Cursor tracking mode allows the display window to follow the movement of the cursor. You move the display window around the virtual screen by moving the cursor.

Note: This section does not apply to the full screen computers.

The Virtual Screen and the Computer Display

The host sends a 25 line x 80 column virtual screen to the computer. With the exception of the full screen DOS computer, the display windows of LXE DOS computers are smaller than the virtual screen. Because of this difference, the display window shows portions of the virtual screen, one section at a time.

Display	Physical Window Size and Type
Half Screen	Window Size: approximately 8" wide by 3" high.
Full Screen	Window Size: approximately 7.5" wide by 5.5" high.
Small Screen	Window Size: three inches measured diagonally.

The rows and columns displayed on the LXE DOS computer will vary depending on the type of computer and the screen size selected. Please refer to the ScreenSize parameter in Chapter 3, "TN3270 Configuration Utility".

The host computer sends a virtual screen to the computer where the display window shows a section of the virtual screen. The following illustrations show the relationship between the virtual screen and the computer display window.




Figure 2-2 VMT Virtual Screen Display versus Computer Display Window




Figure 2-3 HHC Virtual Screen Display versus Computer Display Window

Window Movement Types


Note: This section does not apply to the full screen computer.

Two types of window movement can be specified either by the host application programmer or from the TN3270 Configuration Utility: full window movement and quadrant movement.


Full Window Movement

When a 10 line display window moves vertically in full window movement, the window moves 10 lines at a time and does not overlap its previous position.

When the display window moves horizontally in full window movement, the 20 column display window moves 20 columns and overlaps its previous position by 10 columns.



Vertical Movement



Horizontal Movement


Figure 2-4 Full Window Movement of a HHC Display

Quadrant Movement


When a 10 line display window moves vertically in quadrant movement, the display window moves 5 lines at a time, causing the screen to overlap 5 lines of its previous position.

When the display window moves horizontally in quadrant movement, a 20 column display moves 10 columns.

Quadrant movement is the default for this parameter.



Vertical Movement



Horizontal Movement

Figure 2-5 Quadrant Movement of a HHC Display

Note: The Half Screen Vehicle Mount Computer (HSC) window does not move horizontally





Figure 2-6 Full and Quadrant Vertical Movement of a VMT Display

Window Movement Keys

Use these key sequences to manually move a display window around the virtual screen. The display window moves according to the type of window movement (full window movement or quadrant movement) enabled.

Key Sequence	Window Direction
[CTRL] [Up Arrow]	Up
[CTRL] [Right Arrow]	Right
[CTRL] [Left Arrow]	Left
[CTRL] [Down Arrow]	Down
[CTRL] [Home] or [ALT] [Up Arrow}	Home

Cursor Position

Window movement keys do not affect the position of the cursor on the screen. The cursor remains where it is on the virtual screen while the display window moves.

Display Wrapping

If the display window is along any of the four edges of the virtual screen and you use a window movement key sequence to direct the window beyond the edge of the virtual screen, window manager wraps the display window to the opposite edge of the screen. A window that is wrapped from top to bottom or bottom to top will change line position number and not column position. A window that is wrapped from left to right or right to left will change column number position, but not line position number. The examples shown below are the default display wrapping behavior.




Figure 2-7 HHC Horizontal Display Wrapping




Figure 2-8 HHC Vertical Display Wrapping

Display wrapping behavior can be configured. Please refer to the following parameters in Chapter 3, “TN3270 Configuration Utility” for more information:

- LockColumn
- LockRow
- ViewAllCols
- ResetToLock

Lock Window Mode

Note: This section does not apply to the full screen computer.

Lock window mode locks the display window in a permanent window position relative to the virtual screen. Although you can move the display window around the virtual screen with window movement keys, the display will automatically return to the coordinates specified in window manager when the host sends a new virtual screen or when you press any data entry key.

Valid Window Positions

These coordinates define the home position of the lock window. The first number in each pair represents a line; the second a column. Your selection will vary depending on display size and whether full window movement or quadrant movement is in effect.

The VMT Screens

	25 row x 80 column display	12 row x 80 column display
Quadrant Mode	1,1	1,1 7,1 13,1
Full Window Mode	1,1	1,1 13,1

Figure 2-9 Valid Window Positions - 12 and 25 Row x 80 Column

The HHC Screens

	10 row x 20 column display						
	1,1	1,11	1,21	1,31	1,41	1,51	1,61
Quadrant Mode	6,1	6,11	6,21	6,31	6,41	6,51	6,61
	11,1	11,11	11,21	11,31	11,41	11,51	11,61
	16,1	16,11	16,21	16,31	16,41	16,51	16,61
	21,1	21,11	21,21	21,31	21,41	21,51	21,61
Full Window Mode	10 row x 20 column display						
	1,1	1,11	1,21	1,31	1,41	1,51	1,61
	11,1	11,11	11,21	11,31	11,41	11,51	11,61

Figure 2-10 HHC Valid Window Positions - 10 Row x 20 Column

	20 row x 20 column display						
	1,1	1,11	1,21	1,31	1,41	1,51	1,61
Quadrant Mode	5,1	5,11	5,21	5,31	5,41	5,51	5,61
Full Window Mode	20 row x 20 column display						
	1,1	1,11	1,21	1,31	1,41	1,51	1,61
	5,1	5,11	5,21	5,31	5,41	5,51	5,61

Figure 2-11 HHC Valid Window Positions - 20 Row x 20 Column

Window Movement in Lock**Window Mode**

Cursor location and the position of the display window on the virtual screen combine in the following four ways to affect what is displayed when you enter data in lock window mode:

When the cursor is located...	and the display window...	then, when you enter a data key...
in the lock window	is in the same position as the lock window	that data appears and the window does not move.
in the lock window	is outside the lock window	that data appears and the display window returns to the lock window position.
in the display window	is outside the lock window	that data appears in the display window and the window does not move even if the cursor crosses a window boundary.
outside the display window and outside the lock window	---	that data is put in the virtual screen but does not appear in the display window. The display window does not move.

Cursor Tracking Mode

Note: This section does not apply to the full screen computer.

In cursor tracking mode, the display window moves with the cursor as the cursor moves around the screen. The type of window movement depends on your choice of either full window movement or quadrant movement.

Window Moving Methods

Window manager uses two methods to move the display window up, down, left and right when you are in cursor tracking mode:

- Arrow (cursor movement) keys cause the cursor to cross the window boundaries at the edges of the window you are currently in.
- Window movement keys (refer to “Window Movement” in this section).

Display Example

This illustration and the following table describe how window manager moves the display window around the virtual screen in cursor tracking mode. The display example divides windows into four equal pieces, or quadrants. For example, the window positioned at 1,1 consists of upper left quadrant A, upper right quadrant B, lower right quadrant G, and, lower left quadrant H.

1	10	11	20	21	30	31	40	41	50	51	60	61
A	B	C	D	E	F							
G	H	I	J	K	L							
M	N	O	P	Q	R							
S	T	U	V	W	X							
Y	Z	AA	BB	CC	DD							

Figure 2-12 HHC Virtual Display With Arbitrary Labels

Basic Moves

The following table describes the basic moves the display window makes when tracking the cursor - up, down, left, right, and diagonally. Use this table with the display example.

A window is made of quadrants...	The cursor is in quadrant	The operator moves the cursor to quadrant	In quadrant movement, the new window becomes...	In full window movement, new window becomes...	The rule invoked for this type of move is...
O,P,U,V	O	I	I,J,O,P	C,D,I,J	basic up
P,Q,V,W	P	O	O,P,U,V	N,O,T,U	basic left
C,D,I,J	D	V	O,P,U,V	O,P,U,V	straight down (cursor placed in bottom half)
H,I,N,O	I	Q	J,K,P,Q	J,K,P,Q	straight right (cursor placed in right half)
V,W,BB,CC	V	Y	S,T,Y,Z	S,T,Y,Z	straight left (cursor cannot be placed in right half)
W,X,CC,DD	W	N	G,H,M,N	G,H,M,N	diagonal up and left (cursor placed in lower right quadrant)
M,N,S,T	S	DD	W,X,CC,DD	W,X,CC,DD	diagonal down and right (cursor placed in lower right quadrant)

Figure 2-13 Cursor Tracking Display Examples

Quadrant Choice

The computer display window is divided into four quadrants. The choice of quadrant where the cursor appears when the host sends a virtual screen to the computer is made either at the host or from the Configuration Utility:

1. Upper right
2. Upper left
3. Lower left
4. Lower right

The default for this parameter is quadrant 4.

Status Line

The status line appears on line 25 on the virtual screen, occupies up to 80 character positions, and displays messages that indicate an exception condition. Status line messages and the conditions they represent in the TN3270 terminal emulation are described in the previous section titled “Data Entry”.

Status Line Modes

There are two modes for displaying the status line:

Always off	The status line never appears.
Exception only	The status line appears when the computer emulation determines an exception condition exists.

Display Appearance

When enabled and displayed, the entire status line appears in the computer window. An 80 character status line appears in an interleaved format. A 20 character status line occupies a single line at the bottom of the window.

Operation

When the status line parameter is enabled and an exception condition occurs, the status line appears at the bottom of the display window.

The status line overwrites the last line (or lines) of the display window, including the cursor (if it is on the bottom of the display). If you then enter valid data, the status line disappears and the previous virtual screen reappears, along with the new data that you enter.

The status line remains in the display window when you move the display.

The appearance or disappearance of the status line never causes the display window to move.

Status Line and Message Line

If both the message line and the status line are displayed and any operator input causes one of them to be removed, the computer removes them both.

Message Line

The TN3270 terminal emulation supports an 80 character message line that the host can address. This 80 character message line

- exists in one of the available 24 lines of the virtual screen (usually line 24).
- appears in the current computer display window when received.
- displays all 80 characters in the window at one time.

Physical Display

If necessary, the message line is displayed in an interleaved format. Trailing blanks at the end of the message are suppressed to save a line in the window.

When the message line appears, it overwrites as many of the bottom lines of the computer display as necessary. The message line does not overwrite the status line -- they are displayed together. If the computer displays both the message line and the status line and your input causes one of them to be removed, the computer removes them both.

Display of the message line does not change the location of the display window on the virtual screen.

If the message line overwrites the cursor and you enter data, the computer removes the message line and displays your data at the cursor.

Reviewing the Message Line

Any keystroke will cause the message line to disappear from the window. The message remains in the virtual screen on the line where the host originally put it. You can review the message by moving the window to that line in the virtual screen and moving the window left and right.

Message Line Doesn't Follow the Window

If you move the window using window movement keys or cursor tracking while the message line is displayed in the window, the message line will not follow the display window.

Table of Contents

CHAPTER 3 TN3270 CONFIGURATION UTILITY	3-1
Introduction	3-1
Password Access Levels	3-1
Changed Radio Parameters	3-2
Configuration Files	3-2
Directory Structure	3-2
\IBM24 - TN3270 TE Files	3-2
The TN3270 Configuration Utility	3-3
Pre-Configured Passwords.....	3-3
Menu Components.....	3-4
Using the Configuration Program.....	3-6
Main Menu Display	3-7
Screen Displays	3-9
System Menu Options.....	3-10
Passwords	3-10
Default Passwords.....	3-11
OperatorPasswd – Level 1 Password	3-11
SupvPasswd – Level 2 Password	3-12
LxeEngPasswd – Level 3 Password	3-12
Reset Defaults	3-13
Resetting Parameters Changes Files	3-13
Emulation Menu Option	3-14
LockWindow – Lock Window Mode.....	3-14
LockRow – Lock Row	3-14
LockCol – Lock Column	3-15
FullWinIncs – Full Window Mode	3-15
HostQuad – Host Quadrant	3-16
StatusLine – Status Line Mode	3-16
AlphaOnly – Alpha Only Wildcard	3-17
DigitsOnly – Digits Only Wildcard	3-17
NumericOnly – Numeric Only Wildcard	3-18
AlphaNumericOnly – Alphanumeric Only Wildcard	3-18
MatchAll – Match All Wildcard	3-19
LeftJustify – Left Justify Mode	3-19
ClearData – Clear Data Mode	3-20
TruncateData – Truncate Data Mode	3-20
AutoAdvance – Automatic Advance Mode	3-21

AutoEnter – Automatic Enter.....	3-21
BCPReStrip – Barcode Head Character Strip	3-22
BCPostStrip – Barcode Tail Character Strip.....	3-22
CRPerLine – Carriage Return per Line.....	3-23
LFPerLine – Line Feed per Line	3-23
Trigger – Enable Trigger.....	3-23
Type32702E – Negotiate as 3270-2-E	3-24
ViewAllCols – View All Columns.....	3-24
ResetToLock – Reset Screen To Locked Position.....	3-25
Protocol Menu Option	3-26
Hosts Parameters	3-27
Host1 – First Host Name.....	3-28
Host1LU – First Host Logical Unit Name.....	3-28
Host1RLS – First Host Connect Retries	3-29
Host2 – Second Host Name	3-29
Host2LU – Second Host Logical Unit Name	3-29
Host2RLS – Second Host Connect Retries.....	3-29
Host3 – Third Host Name	3-30
Host3LU – Third Host Logical Unit Name	3-30
Host3RLS – Third Host Connect Retries.....	3-30
Host4 – Fourth Host Name	3-30
Host4LU – Fourth Host Logical Unit Name.....	3-30
Host4RLS – Fourth Host Connect Retries.....	3-30
Host5 – Fifth Host Name	3-31
Host5LU – Fifth Host Logical Unit Name	3-31
Host5RLS – Fifth Host Connect Retries.....	3-31
Host6 – Sixth Host Name	3-31
Host6LU – Sixth Host Logical Unit Name	3-31
Host6RLS – Sixth Host Connect Retries.....	3-31
HostDataTimeout – Host Wait Interval	3-32
Auto Login Parameters.....	3-33
Auto Login and the MX2	3-33
AutoLoginOn – Terminal Automatic Login	3-34
Prompt1 – First Host String	3-34
Reply1 – First Response Sent to Host	3-35
Prompt2 – Second Host String.....	3-35
Reply2 – Second Response Sent to Host	3-35
Prompt3 – Third Host String	3-35
Reply3 – Third Response Sent to Host	3-35
Prompt4 – Fourth Host String	3-36
Reply4 – Fourth Response Sent to Host	3-36
Prompt5 – Fifth Host String.....	3-36
Reply5 – Fifth Response Sent to Host	3-36
Prompt6 – Sixth Host String.....	3-36
Reply6 – Sixth Response Sent to Host	3-36
ALITimeout – Login Interval Timeout	3-37

Interface Parameters	3-38
DNS Parameters	3-38
General Parameters	3-38
Kernel Parameters	3-38
Logging Parameters.....	3-39
EvtMask – Event Logging Mask	3-39
TNLogging – TELNET Logging.....	3-39
TNLogFS – TELNET Log File Size.....	3-40
Radio Menu Option – 6400 and 6500 Systems	3-41
Driver Settings.....	3-41
Packet Driver.....	3-41
Platform Menu	3-42
CursorType – Cursor Type.....	3-42
BeeperVolume – Beeper Volume.....	3-43
Printing – Print to COM Port	3-43
Com1BaudRate – COM1 Baud Rate.....	3-44
Com1DataBits – COM1 Data Bits	3-44
Com1Parity – COM1 Parity	3-45
Com1StopBits – COM1 Stop Bits	3-45
Com1HalfDuplex – COM1 Half Duplex	3-46
Com1Xon – COM1 Software Flow Control	3-46
Com1HwFlowCtrl – COM1 Hardware Flow Control.....	3-47
Com1TimeOut – COM1 Time Out	3-47
Com1PassTermChar – COM1 Pass Termination Character	3-48
Com1Interrupt – COM1 Interrupt.....	3-48
Com2BaudRate – COM2 Baud Rate.....	3-49
Com2DataBits – COM2 Data Bits	3-49
Com2Parity – COM2 Parity	3-50
Com2StopBits – COM2 Stop Bits	3-50
Com2HalfDuplex – COM2 Half Duplex	3-51
Com2Xon – COM2 Software Flow Control	3-51
Com2HwFlowCtrl – COM2 Hardware Flow Control.....	3-52
Com2TimeOut – COM2 Time Out	3-52
Com2PassTermChar – COM2 Pass Termination Character	3-53
Com2Interrupt – COM2 Interrupt	3-53
InitialScrlDly – Initial Scroll Delay	3-54
RepeatScrlDly – Repeat Scroll Delay	3-54
HardwareModel – Hardware Model	3-54
ScreenSize – Font Size Selections	3-55
APIType – API Type.....	3-56
DockedBehavior – Docked I/O Configuration.....	3-56
NormalIO – Undocked I/O Configuration	3-58
EAN128Fnc1 – Decode F1 As Space	3-59
Exit With Save Option.....	3-60
Exit Without Save Option.....	3-60

Illustrations

Figure 3-1 Configuration Utility - Sample Menu Components	3-4
Figure 3-2 Configuration Utility Main Menu	3-7
Figure 3-3 Main Menu on a Full Screen VMC with 2.4GHz Radio.....	3-9
Figure 3-4 Main Menu on a Half Screen VMC with 2.4GHz Radio	3-9
Figure 3-5 Main Menu on a Small Screen HHT with 2.4GHz Radio.....	3-9

Chapter 3 **TN3270 Configuration Utility**

Introduction

The TN3270 configuration program provides the ability to modify the DOS terminal emulation (TE) setup parameters and hardware parameters. The configuration program is a DOS program. The configuration utility allows the modification of the following parameters:

- Terminal emulation parameters.
- Radio configuration parameters.
- Hardware configuration parameters.
- TN host interaction parameters.

Configuration menu options displayed on the screens, *and in this chapter*, are unique to the

- computer being configured,
- the access level of the current user, and
- computer screen display size.

The illustrations contained in this section represent the menu options for each menu as shown on a screen that has 20 or more columns. Menus displayed on the hand held computers display all parameters relative to the TE setup, although an extra keypress may be needed to move from parameter to parameter.

Password Access Levels

There are three (3) access levels associated with the configuration utility. The access levels are:

- Operator (Access Level 1)
- System Administrator (Access Level 2)
- LXE Technical staff (Access Level 3)

Access to the configuration utility is gained by entering the appropriate password at the Enter Password text box. The password determines the access level of the user. Passwords are masked upon entry.

Passwords are modified by selecting the System option from the main menu. The Password menu option is then chosen:

Only passwords for the current access level (or any lower access levels) can be modified. For example, the System Administrator may change his/her password and that of the Operator, but the Operator can only change his/her password.

See the “Pre-Configured Passwords” section for password entry instruction. See the “Passwords” option in the System menu for password edit instruction.

Changed Radio Parameters

Radio parameters are changed by editing the NET.CFG and SOCKET.CFG files. Please refer to the equipment Reference Guide for information on editing these files.

The DOS computer must be rebooted before the radio parameter changes will take effect.

Configuration Files

Please refer to the equipment Reference Guide for information on the AUTOEXEC.BAT and CONFIG.SYS files. Files installed in each TN3270 TE computer are specific to the computer.

Directory Structure

The directory structure of a computer intended for TN3270 TE operation is, essentially, the same for each system. In addition to the standard operating files, the DOS computer will contain an IBM24 directory where the TN3270 specific files reside.

\IBM24 - TN3270 TE Files

Filename	Function
CONFIG.EXE	TN3270 TE Configuration utility file.
CONFIG.INF	TN3270 TE Configuration utility file.
DOS3270.EXE	TN3270 TE interface program.
FIBM*.FNT	LXE screen font files.
HELP3270.TXT	Text used for TN3270 TE application's help screens.
HELP3271.TXT	Text used for TN3270 TE application's help screens.
LANG2.TXT	Text used for CONFIG.EXE screen displays.
LANGUAGE.TXT	Text used for CONFIG.EXE screen displays.
LXE.INI	Stores configuration parameters set using CONFIG.EXE.
MESSAGE.TXT	Text used for TN3270 TE application's messages.
REV.BAT	Displays software revision level.

The TN3270 Configuration Utility

The TN3270 TE Configuration utility is accessed at the DOS prompt.

From the DOS prompt:

Type **CD\IBM24**, at the DOS prompt.

Press [Enter].

Type **CONFIG** at the prompt.

Press [Enter].

The LXE Configuration Utility welcome screen is displayed while the configuration utility loads. It is removed and the Enter Password text is displayed:

```
Enter Password  
Password [ ]
```

The cursor is located at the beginning of the password field.

Pre-Configured Passwords

The TN3270 TE is shipped with passwords pre-configured. The pre-configured passwords are:

- **Operator Access (Level 1) = Tab 1 2**
- **System Administrator Access (Level 2) = Tab 3 4 5**

Refer to the “Passwords” section of this chapter for information on changing the passwords.

If an incorrect password is entered, the Configuration Utility closes and control returns to the DOS prompt or the TE. If the correct password is entered, the Configuration Utility Main Menu appears.

Menu Components

Each configuration menu is made up of several components.




Figure 3-1 Configuration Utility - Sample Menu Components

Note: The sample screen contains items from various configuration screens. Configuration menu options and components displayed are unique to the computer being configured, the current user's access level, and the computer screen display size.

Title Bar

The title bar is the highlighted area at the top of the screen. The title bar contains:

- **Menu Name:** The name of the currently displayed menu. (Located in the center of the bar.)
- **Page Number:** The current page number as well as the total number of pages used to display the current menu. (Located in the upper right hand corner of the title bar.)

Option List

The list of parameters or additional menus available from the current menu.

Status Bar

The status bar is the highlighted area at the bottom of the screen. The status bar contains:

- **Option Description:** A brief description of the currently highlighted (selected) option. (Located at the top of the status line.)
- **Keyboard Commands:** The keyboard commands available from the current menu. Typically commands used to select or modify a parameter. (Located at the bottom of the status line.)

Modifiable Parameters

There are two types of modifiable parameters within the configuration utility:

- Pre-defined
- User Defined

Pre-Defined Parameters

Pre-defined parameters are parameters with a specific set of pre-defined options. These parameters may only be set to one of the pre-defined options.

User Defined Parameters

User defined parameters are parameter strings that have no pre-defined options. The user defined parameter strings are denoted with [brackets]. The space within the brackets indicates the maximum characters allowed:

- | | |
|--------------------|------------------------|
| [] | Short parameter field |
| [] | Longer parameter field |

These parameters require the user to type in a parameter definition when modifying them. Some parameters have a default setting. This default can be recalled by using the Reset to Defaults option from the main menu.

Note: When using the Reset to Defaults option all parameters available for that user level are reset to their factory default setting, with the exception of the passwords.

Non-Modifiable Parameters

The non-modifiable parameters are those which cannot be modified by Operators or System Administrators. These parameters are not displayed for Operators and are marked as *Read Only* for Administrators.

Using the Configuration Program

The set of keyboard commands used to select menu items and parameters, as well as modify parameter values are as follows:

Action	Keystrokes
Exit a menu	[Esc]
Acknowledge message or prompt	[Esc] or [Enter]
Select menu option (Menu or Parameter)	Up, Down, Left or Right Arrow
Display menu	[Enter]
Modify parameter	[Space] or Left Arrow or Right Arrow or type in the value
Next/Previous page selection	Up or Down Arrow

Main Menu Display




Figure 3-2 Configuration Utility Main Menu

The main menu of the configuration utility allows access to the System, Emulation, Protocol, Radio, and Platform parameters, as well as saving the modified parameters and exiting the configuration utility program.

Configuration menu options and/or parameters displayed at the menu and activity screens are unique to the computer being configured, the access level of the current user, and computer screen display size.

The Main menu is composed of the following menu options:

Main Menu Option	Function	Access Level
System	Opens submenu containing modifiable System parameters: - Passwords - Reset Defaults	2 and 3 1, 2 and 3
Emulation	Modify screen display parameters such as LeftJustify, LockRow, etc.	2 and 3
Protocol	Opens submenu containing modifiable host protocol parameters: - Hosts - Auto Login - Logging - Interface, DNS, General and Kernel parameters are changed by editing the SOCKET.CFG file.	2 and 3
Radio	Radio Menu options are altered by editing the NET.CFG file. See the Radio Menu section later in this chapter for more details	2 and 3
Platform	Modify platform parameters such as Beeper Volume, Comm Port Settings, Printing, CursorType, etc.	1, 2 and 3

Main Menu Option	Function	Access Level
Exit with Save	Saves current settings and exits the configuration program.	1, 2 and 3
Exit Without Save	Exits the configuration program without saving the changed parameter settings.	1, 2 and 3

Note: When parameters are changed, the DOS computer must be rebooted before the parameter changes will take effect.

Screen Displays

The configuration utility screen displays are designed for all three TE screen types:

- | | |
|--------------|--|
| Half Screen | approximately 8" wide by 3" high. (12 rows x 80 columns) |
| Full Screen | approximately 7.5" wide by 5.5" high. (25 rows x 80 columns) |
| Small Screen | three inches measured diagonally. (20 rows x 20 columns) |

All menus and parameter editing segments are available regardless of the size of the screen – an extra keypress may be required to move from screen to screen.




Figure 3-3 Main Menu on a Full Screen VMC with 2.4GHz Radio




Figure 3-4 Main Menu on a Half Screen VMC with 2.4GHz Radio




Figure 3-5 Main Menu on a Small Screen HHT with 2.4GHz Radio

System Menu Options

Upon choosing System at the Main Menu, the next screen displayed is the System submenu.

To return to the Main Menu press the [Esc] key.

Submenu	Parameters
Passwords	OperatorPasswd SupvPasswd LxeEngPasswd
Reset Defaults	Yes No

Passwords

Selecting Passwords at the System menu displays the Passwords activity screen. Press [Esc] to return to the System menu.

Note: *Passwords are NOT affected by the Reset Defaults function.*

Default Passwords

Passwords entered by users are validated against user-defined entries found in the configuration file (LXE.INI). If the configuration file (LXE.INI) does not exist, the configuration utility will use the internally generated password.

The default password is generated daily, and therefore does not remain the same. To obtain the generated password, contact LXE customer support.

OperatorPasswd – Level 1 Password

Function

The OperatorPasswd parameter specifies the password that must be typed by Level 1 users before they may have access to the Configuration Utility.

Note: When the OperatorPasswd value is changed, write it down and keep in a safe place.

Options

Valid options: user defined (3 character alphanumeric string)

Default setting: Tab 1 2 (pre-configured by LXE)

Change the password by typing the new password. Press [Esc] to return to the System Menu. When exiting the utility, select the Exit with Save option.

A user with an access level of 1 (operator) has access to the following menu options:

- System - Passwords - User can edit the Operator password.
- System - Reset Defaults - User can reset the system to the default values.
- Platform - User can edit the Beeper Volume parameter value.

Access Level

Parameter can be modified by a user with an access level of 1, 2 or 3.

SupvPasswd – Level 2 Password**Function**

The SupvPasswd parameter specifies the password that must be typed by Level 2 users before they may have access to the Configuration Utility. This level allows modification of all parameters.

Note: When the SupvPasswd value is changed, write it down and keep in a safe place.

Options

Valid options: user defined (4 character alphanumeric string)

Default setting: Tab 3 4 5 (pre-configured by LXE)

Change the password by typing the new password. Press [Esc] to return to the System Menu. When exiting the utility, select the Exit with Save option.

Access Level

Parameter can only be modified by a user with an access level of 2 or 3.

LxeEngPasswd – Level 3 Password**Function**

The LxeEngPasswd parameter specifies the password that must be typed by Level 3 users before they may have access to the Configuration Utility. This level allows modification of all parameters (except read-only parameters).

Note: When the LxeEngPasswd value is changed, write it down and keep in a safe place.

Options

Valid options: user defined (5 character alphanumeric string)

Default setting: Tab 6 7 8 9 (pre-configured by LXE)

Change the password by typing the new password. Press [Esc] to return to the System Menu. When exiting the utility, select the Exit with Save option.

Access Level

Parameter can be modified by a user with an access level of 3.

Reset Defaults

Note: Passwords are NOT affected by the Reset Defaults function.

The Reset Defaults option from the System menu allows the restoration of factory defaults. This feature only allows the restoration of defaults for the parameters currently accessible to the user.

In other words, only the parameters available to the current user's access level will be restored. For example, a user with Operator access will reset the Beeper Loudness parameter only.

To return to the System Menu press the [Esc] key.

Reset Press the [Y] key and then the [Enter] key to reset the default values. System values are returned to their default values and configuration files are changed. See the sub-section titled "Reset Parameters" in this Section.

- or -

Ignore Press the [N] key and then the [Enter] key to ignore the Reset command and remove the Reset text box from the screen display. System values are not changed.

- or -

Ignore At the [N] prompt, press the [Enter] key to remove the Reset box from the screen display. System values are not changed.

Resetting Parameters Changes Files

When parameters in a TE computer are changed or reset to default values, the LXE.INI file is changed.

Note: The computer must be rebooted before the parameter changes will take effect.

Configuration files are updated upon exiting the Configuration utility.

Emulation Menu Option

The Emulation menu contains parameters pertaining to the DOS terminal emulation. Emulation parameters are displayed on multiple screens.

To access the second screen of terminal emulation parameters, press the [Page Down] key.

To return to the first screen, press the [Page Up] key. A detailed description of each terminal emulation parameter follows.

To return to the Main Menu, press [Esc].

Access Levels

Refer to the “Passwords” section of this chapter for more information on *access levels*.

LockWindow – Lock Window Mode

Function

The LockWindow parameter determines whether the display window is locked in a permanent window position or if it follows the cursor in the virtual window.

Options

Valid options: Does not track (locked in permanent position)
 Track cursor

Default setting: Track cursor

Change the parameter by pressing the left or right arrow keys until the desired value is displayed. Press [Esc] to return to the Main Menu. When exiting the utility, select the Exit with Save option.

Access Level

Parameter may only be modified by a user with an access level of 2 or 3.

LockRow – Lock Row

Function

The LockRow parameter specifies the row coordinate of the upper left-hand corner (Home) position of the physical display window.

Options

Valid options: 1 - 15

Default setting: 1

Change the parameter by typing one of the numbers shown above for the type of computer you are configuring. Press [Esc] to return to the Main Menu. When exiting the utility, select the Exit with Save option.

Access Level

Parameter may only be modified by a user with an access level of 2 or 3.

LockCol – Lock Column**Function**

The LockCol parameter specifies the column coordinate of the upper left-hand corner (Home) position of the physical display window.

Options

Valid options: 1 - 61

Default setting: 1

Change the parameter by typing one of the numbers shown above. Press [Esc] to return to the Main Menu. When exiting the utility, select the Exit with Save option.

Access Level

Parameter may only be modified by a user with an access level of 2 or 3.

FullWinIncs – Full Window Mode**Function**

The FullWinIncs parameter determines whether the computer display moves in half or full window increments.

Options

Valid options: Half, Full

Default setting: Half

Change the parameter by pressing the left or right arrow keys until the desired setting is displayed. Press [Esc] to return to the Main Menu. When exiting the utility, select the Exit with Save option.

Access Level

Parameter may only be modified by a user with an access level of 2 or 3.

HostQuad – Host Quadrant**Function**

The HostQuad parameter determines which quadrant the cursor appears in when the host sends a virtual screen to the computer.

Options

Valid options:	1 Upper right
	2 Upper left
	3 Lower left
	4 Lower right

Default setting: 4

Change the parameter by pressing the left or right arrow keys until the desired setting is displayed or by typing one of the numbers shown above. Press [Esc] to return to the Main Menu. When exiting the utility, select the Exit with Save option.

Access Level

Parameter may only be modified by a user with an access level of 2 or 3.

StatusLine – Status Line Mode**Function**

The StatusLine parameter specifies whether the status line will be displayed (usually on line 25) or not.

The status line on a full screen computer is always displayed. The status line on any other computer is displayed only when there is an exception to normal operation.

Options

Valid options: Enabled, Disabled

Default setting: Enabled

Change the parameter by pressing the left or right arrow keys until the desired setting is displayed. Press [Esc] to return to the Main Menu. When exiting the utility, select the Exit with Save option.

Access Level

Parameter may only be modified by a user with an access level of 2 or 3.

AlphaOnly – Alpha Only Wildcard**Function**

The AlphaOnly parameter specifies the wildcard character that represents an alphabetic character. The characters represented by this wildcard are: A - Z, a - z, comma (,), period (.), dash (-) and space ().

Options

Enter the decimal equivalent of the ASCII character desired.

Valid options: 32 - 126 (Decimal)

Default setting: 63 (? in ASCII)

Note: See Chapter 4 “Code Pages and Character Sets” section titled “DOS US PC Standard Character Set” for Decimal to ASCII equivalents.

Change the parameter by pressing the left or right arrow keys until the desired setting is displayed or by typing the decimal value. Press [Esc] to return to the Main Menu. When exiting the utility, select the Exit with Save option.

Access Level

Parameter may only be modified by a user with an access level of 2 or 3.

DigitsOnly – Digits Only Wildcard**Function**

The DigitsOnly parameter specifies the wildcard character that represents a digit. The characters represented by this wildcard are: 0 - 9.

Options

Enter the decimal equivalent of the ASCII character desired.

Valid options: 32 - 126 (Decimal)

Default setting: 36 (\$ in ASCII)

Note: See Chapter 4 “Code Pages and Character Sets” section titled “DOS US PC Standard Character Set” for Decimal to ASCII equivalents.

Change the parameter by pressing the left or right arrow keys until the desired setting is displayed or by typing the decimal value. Press [Esc] to return to the Main Menu. When exiting the utility, select the Exit with Save option.

Access Level

Parameter may only be modified by a user with an access level of 2 or 3.

NumericOnly – Numeric Only Wildcard**Function**

The NumericOnly parameter specifies the wildcard character that represents a numeric character. The characters represented by this wildcard are: 0 - 9, plus (+), comma (,), period (.) and dash (-) and space ().

Options

Enter the decimal equivalent of the ASCII character desired.

Valid options: 32 - 126 (Decimal)

Default setting: 35 (# in ASCII)

Note: See Chapter 4 “Code Pages and Character Sets” section titled “DOS US PC Standard Character Set” for Decimal to ASCII equivalents.

Change the parameter by pressing the left or right arrow keys until the desired setting is displayed or by typing the decimal value. Press [Esc] to return to the Main Menu. When exiting the utility, select the Exit with Save option.

Access Level

Parameter may only be modified by a user with an access level of 2 or 3.

AlphaNumericOnly – Alphanumeric Only Wildcard**Function**

The AlphaNumericOnly parameter specifies the wildcard character that represents an alphanumeric character. The characters represented by this wildcard are: A - Z, a - z, 0 - 9, plus (+), comma (,), period (.), dash (-) and space ().

Options

Enter the decimal equivalent of the ASCII character desired.

Valid options: 32 - 126 (Decimal)

Default setting: 43 (+ in ASCII)

Note: See Chapter 4 “Code Pages and Character Sets” section titled “DOS US PC Standard Character Set” for Decimal to ASCII equivalents.

Change the parameter by pressing the left or right arrow keys until the desired setting is displayed or by typing the decimal value. Press [Esc] to return to the Main Menu. When exiting the utility, select the Exit with Save option.

Access Level

Parameter may only be modified by a user with an access level of 2 or 3.

MatchAll – Match All Wildcard**Function**

The MatchAll parameter specifies the wildcard character that represents any non-control character (all characters included). The characters represented by this wildcard are: any GL or GR character.

Options

Enter the decimal equivalent of the ASCII character desired.

Valid options: 32 - 126 (Decimal)

Default setting: 42 (* in ASCII)

Note: See Chapter 4 “Code Pages and Character Sets” section titled “DOS US PC Standard Character Set” for Decimal to ASCII equivalents.

Change the parameter by pressing the left or right arrow keys until the desired setting is displayed or by typing the decimal value. Press [Esc] to return to the Main Menu. When exiting the utility, select the Exit with Save option.

Access Level

Parameter may only be modified by a user with an access level of 2 or 3.

LeftJustify – Left Justify Mode**Function**

The LeftJustify parameter determines where the cursor appears in a field from one barcode entry to the next.

Options

When enabled, the cursor in a field justifies to the left each time a new barcode entry occurs. When disabled, the barcode entry appears at the end of the previous entry in that field.

Valid options: Yes, No

Default setting: Yes

Change the parameter by pressing the left or right arrow keys until the desired setting is displayed. Press [Esc] to return to the Main Menu. When exiting the utility, select the Exit with Save option.

Access Level

Parameter may only be modified by a user with an access level of 2 or 3.

ClearData – Clear Data Mode**Function**

The ClearData parameter determines if a field is automatically cleared when the next barcode entry occurs or if the data in the field is overwritten by the new entry.

Options

Valid options: Clear, Overwrite

Default setting: Clear

Change the parameter by pressing the left or right arrow keys until the desired setting is displayed. Press [Esc] to return to the Main Menu. When exiting the utility, select the Exit with Save option.

Access Level

Parameter may only be modified by a user with an access level of 2 or 3.

TruncateData – Truncate Data Mode**Function**

The TruncateData parameter determines whether the character position of a barcode entry that exceeds the field length are simply dropped off or if the leftover characters are entered in the next available field.

Options

Valid options: Don't Truncate, Truncate

Default setting: Truncate

Change the parameter by pressing the left or right arrow keys until the desired setting is displayed. Press [Esc] to return to the Main Menu. When exiting the utility, select the Exit with Save option.

Access Level

Parameter may only be modified by a user with an access level of 2 or 3.

AutoAdvance – Automatic Advance Mode**Function**

The AutoAdvance parameter determines whether the cursor advances to the next field at the end of a barcode entry. If the cursor does not advance to the next field, the next barcode entry is entered at the end of the previous barcode entry.

Options

Valid options: Yes, No

Default setting: Yes

Change the parameter by pressing the left or right arrow keys until the desired setting is displayed. Press [Esc] to return to the Main Menu. When exiting the utility, select the Exit with Save option.

Access Level

Parameter may only be modified by a user with an access level of 2 or 3.

AutoEnter – Automatic Enter**Function**

The AutoEnter parameter determines whether there is an automatic [Enter] function after a datastream print.

Options

Valid options: Disabled, Enabled

Default setting: Enabled

Change the parameter by pressing the left or right arrow keys until the desired setting is displayed. Press [Esc] to return to the Main Menu. When exiting the utility, select the Exit with Save option.

Access Level

Parameter may only be modified by a user with an access level of 2 or 3.

BCPreStrip – Barcode Head Character Strip**Function**

The BCPreStrip parameter determines the number of characters to strip from the head of a barcode.

Options

Valid options: 0 - 20

Default setting: 0

Change the parameter by pressing the left or right arrow keys until the desired setting is displayed. Press [Esc] to return to the Main Menu. When exiting the utility, select the Exit with Save option.

Access Level

Parameter may only be modified by a user with an access level of 2 or 3.

Related Parameters

BCPostStrip

BCPostStrip – Barcode Tail Character Strip**Function**

The BCPostStrip parameter determines the number of characters to strip from the tail of a barcode.

Options

Valid options: 0 - 20

Default setting: 0

Change the parameter by pressing the left or right arrow keys until the desired setting is displayed. Press [Esc] to return to the Main Menu. When exiting the utility, select the Exit with Save option.

Access Level

Parameter may only be modified by a user with an access level of 2 or 3.

Related Parameters

BCPreStrip

CRPerLine – Carriage Return per Line**Function**

The CRPerLine parameter determines whether a single carriage return (CR) is transmitted in screen paint.

Options

Valid options: Enabled, Disabled

Default setting: Disabled

Change the parameter by pressing the left or right arrow keys until the desired setting is displayed. Press [Esc] to return to the Main Menu. When exiting the utility, select the Exit with Save option.

Access Level

Parameter may only be modified by a user with an access level of 2 or 3.

LFPerLine – Line Feed per Line**Function**

The LFPerLine parameter determines whether a single line feed (LF) is transmitted in screen paint.

Options

Valid options: Enabled, Disabled

Default setting: Disabled

Change the parameter by pressing the left or right arrow keys until the desired setting is displayed. Press [Esc] to return to the Main Menu. When exiting the utility, select the Exit with Save option.

Access Level

Parameter may only be modified by a user with an access level of 2 or 3.

Trigger – Enable Trigger**Function**

The Trigger parameter determines whether a trigger press (of the scanning device) is treated as an autosend.

Options

Valid options: Enable, Disable

Default setting: Disable

Change the parameter by pressing the left or right arrow keys until the desired setting is displayed. Press [Esc] to return to the Main Menu. When exiting the utility, select the Exit with Save option.

Access Level

Parameter may only be modified by a user with an access level of 2 or 3.

Type32702E – Negotiate as 3270-2-E**Function**

If enabled, the TN3270 TE will negotiate with the Host as a 3270-2-E computer.

If disabled, the TN3270 TE will negotiate with the Host as a 3270-2.

Options

Valid options: Disabled, Enabled

Default setting: Enabled

Access Level

Parameter may only be modified by a user with an access level of 2 or 3.

ViewAllCols – View All Columns**Function**

The ViewAllCols parameter determines whether the user can view all columns and rows. If Hide Columns is selected, all columns to the left of the LockCol and all rows above the LockRow are not displayed. Data in the rows or columns that are not displayed cannot be used. Vertical display panning stops at the LockRow at the top of the screen and row 25 at the bottom. Likewise, horizontal display panning stops at the LockCol value at the left of the screen and column 80 at the right.

Options

Valid options: View All Columns, Hide Columns

Default setting: View All Columns

Change the parameter by pressing the left or right arrow keys until the desired setting is displayed. Press [Esc] to return to the Main Menu. When exiting the utility, select the Exit with Save option.

Access Level

Parameter may only be modified by a user with an access level of 2 or 3.

Related Parameters

LockCol, LockRow

ResetToLock – Reset Screen To Locked Position**Function**

The ResetToLock parameter determines how a new screen will be displayed. When Don't Reset on Enter is selected, a new screen is displayed in the position it was last left in. When Reset on Enter is selected, a new screen is displayed at the LockRow and LockCol position.

Options

Valid options: Don't Reset on Enter, Reset on Enter

Default setting: Don't Reset on Enter

Change the parameter by pressing the left or right arrow keys until the desired setting is displayed. Press [Esc] to return to the Main Menu. When exiting the utility, select the Exit with Save option.

Access Level

Parameter may only be modified by a user with an access level of 2 or 3.

Related Parameters

LockCol, LockRow

Protocol Menu Option

Upon choosing Protocol at the Main Menu, the next screen displayed is the Protocol submenu.

To return to the Main Menu press the [Esc] key. A detailed description of Protocol parameters follows.

Menu Option	Parameters
Hosts	Host1 Host1LU Host1RLS <i>...through...</i> Host6 Host6LU Host6RLS HostDataTimeout
Auto Login	AutoLoginOn Prompt1 Reply1 Prompt2 Reply2 <i>...through...</i> Prompt6 Reply6 ALITimeout
Interface	The Interface, DNS, General, Kernel parameters are changed by editing the SOCKET.CFG file. When any of these options are selected, the following message is displayed:
DNS	<i>Manually edit SOCKET.cfg in the pctcp directory</i>
General	
Kernel	
Logging	EvtMask TNLogging TNLogFS

Hosts Parameters

The Hosts parameters enable computers to specify a list of up to six host computers. The list is provided for alternate host connection in case the first or current host fails or is unavailable. There is no provision for hot swapping between hosts. The number of host retries (when the host is not immediately available) is also set on this screen.

The Hosts screen contains parameters pertaining to computer login.

Press the <Esc> key to return to the Protocol Menu.

Note: There are six (6) parameters available for host name (Host1 through Host6), Host Logical Unit Name (Host1LU through Host6LU) and retrying lost sessions (Host1RLS through Host6RLS). The only difference in the parameter names is the number of the host. The functions of each are the same.

The TE (Terminal Emulation) will try and connect to the first defined host in the list. If that host fails, the TE will attempt the next specified host in the list. Once all hosts in the list plus one more attempt at the first defined host are tried and no successful connection is made, the TE will issue the message “No Hosts found Please Power Down”. Once there is a connection with a host (TCP/IP-Telnet level), the TE will wait up to ‘HostDataTimeout’ seconds for host data before trying the next host. If the connection process starts over, the logic of “Try All Hosts” starting with the next defined host begins. If there is still no connection, “Try the first host” is tried one last time before issuing the power down message.

Once there is an established session, meaning PLU data has been received from the host, there is a RLS (Retry Lost Session) parameter per host to guide reconnect logic. If RLS is set to yes and PLU data has been received from the host and a disconnect occurs, the current host will be retried again before trying the next host.

Each time there is a host connection (TCP/IP-Telnet level) success, the autologin timers and sequences are reinitialized.

Host1 – First Host Name**Function**

The host string containing the domain name or IP address of an IBM host with a TN server. This is the first host to contact when login is attempted. The number of retry attempts to Host1 is contained in the Host1RLS parameter. Permission to retry a lost session with Host1 is contained in the Host1RLS parameter.

Host2 stores the host name of the “second” host in the system.

Host3 stores the host name of the “third” host in the system.

Host4 stores the host name of the “fourth” host in the system.

Host5 stores the host name of the “fifth” host in the system.

Host6 stores the host name of the “sixth” host in the system.

Options

Valid options: [user defined]

Default setting: Blank

Change the parameter by typing the name for the host. Press [Esc] to return to the Protocol menu. When exiting the utility, select the Exit with Save option.

Access Level

Parameter may only be modified by a user with an access level of 2 or 3.

Host1LU – First Host Logical Unit Name**Function**

The Host1 string containing the logical unit name of an IBM host with a TN server. This is the logical unit name of the first host to contact when login is attempted. The number of retry attempts to Host1 is contained in the Host1RLS parameter. Permission to retry a lost session with Host1 is contained in the Host1RLS parameter.

Host2LU stores the logical unit name of the “second” host in the system.

Host3LU stores the logical unit name of the “third” host in the system.

Host4LU stores the logical unit name of the “fourth” host in the system.

Host5LU stores the logical unit name of the “fifth” host in the system.

Host6LU stores the logical unit name of the “sixth” host in the system.

Options

Valid options: [user defined]

Default setting: Blank

Change the parameter by typing the logical unit name for the host. Press [Esc] to return to the Protocol menu. When exiting the utility, select the Exit with Save option.

Access Level

Parameter may only be modified by a user with an access level of 2 or 3.

Host1RLS – First Host Connect Retries**Function**

The Host1RLS parameter is used to allow retries with Host1 after a lost session , if PLU data had been previously received from this host, before attempting connection with Host 2.

Host2RLS stores the retry permission of the “second” host in the system.

Host3RLS stores the retry permission of the “third” host in the system.

Host4RLS stores the retry permission of the “fourth” host in the system.

Host5RLS stores the retry permission of the “fifth” host in the system.

Host6RLS stores the retry permission of the “sixth” host in the system.

Options

Valid options: Yes, No

Default setting: Yes

Change the parameter by pressing the left or right arrow keys until the desired setting is displayed. Press [Esc] to return to the Protocol menu. When exiting the utility, select the Exit with Save option.

Access Level

Parameter may only be modified by a user with an access level of 2 or 3.

Host2 – Second Host Name

The host string containing the domain name or IP address of an IBM host with a TN server. This is the second host to contact when login is attempted. The number of retry attempts to Host2 is contained in the Host2RLS parameter. Permission to retry a lost session with Host2 is contained in the Host2RLS parameter.

Note: See the previous parameter description of Host1 for equivalent Host2 valid values, defaults and other information.

Host2LU – Second Host Logical Unit Name

The Host2 string containing the logical unit name of an IBM host with a TN server. This is the logical unit name of the second host to contact when login is attempted. The number of retry attempts to Host2 is contained in the Host2RLS parameter. Permission to retry a lost session with Host2 is contained in the Host2RLS parameter.

Note: See the previous parameter description of Host1LU for equivalent Host2LU valid values, defaults and other information.

Host2RLS – Second Host Connect Retries

The Host2RLS parameter is used to allow retries with Host2 after a lost session, if PLU data had been previously received from this host, before attempting connection with Host3.

Note: See the previous parameter description of Host1RLS for equivalent Host2RLS valid values, defaults and other information.

Host3 – Third Host Name

The host string containing the domain name or IP address of an IBM host with a TN server. This is the third host to contact when login is attempted. The number of retry attempts to Host3 is contained in the Host3RLS parameter. Permission to retry a lost session with Host3 is contained in the Host3RLS parameter.

Note: See the previous parameter description of Host1 for equivalent Host3 valid values, defaults and other information.

Host3LU – Third Host Logical Unit Name

The Host3 string containing the logical unit name of an IBM host with a TN server. This is the logical unit name of the third host to contact when login is attempted. The number of retry attempts to Host3 is contained in the Host3RLS parameter. Permission to retry a lost session with Host3 is contained in the Host3RLS parameter.

Note: See the previous parameter description of Host1LU for equivalent Host3LU valid values, defaults and other information.

Host3RLS – Third Host Connect Retries

The Host3RLS parameter is used to allow retries with Host3 after a lost session, if PLU data had been previously received from this host, before attempting connection with Host4.

Note: See the previous parameter description of Host1RLS for equivalent Host3RLS valid values, defaults and other information.

Host4 – Fourth Host Name

The host string containing the domain name or IP address of an IBM host with a TN server. This is the fourth host to contact when login is attempted. The number of retry attempts to Host4 is contained in the Host4RLS parameter. Permission to retry a lost session with Host4 is contained in the Host4RLS parameter.

Note: See the previous parameter description of Host1 for equivalent Host4 valid values, defaults and other information.

Host4LU – Fourth Host Logical Unit Name

The Host4 string containing the logical unit name of an IBM host with a TN server. This is the logical unit name of the fourth host to contact when login is attempted. The number of retry attempts to Host4 is contained in the Host4RLS parameter. Permission to retry a lost session with Host4 is contained in the Host4RLS parameter.

Note: See the previous parameter description of Host1LU for equivalent Host4LU valid values, defaults and other information.

Host4RLS – Fourth Host Connect Retries

The Host4RLS parameter is used to allow retries with Host4 after a lost session, if PLU data had been previously received from this host, before attempting connection with Host5.

Note: See the previous parameter description of Host1RLS for equivalent Host4RLS valid values, defaults and other information.

Host5 – Fifth Host Name

The host string containing the domain name or IP address of an IBM host with a TN server. This is the fifth host to contact when login is attempted. The number of retry attempts to Host5 is contained in the Host5RLS parameter. Permission to retry a lost session with Host5 is contained in the Host5RLS parameter.

Note: See the previous parameter description of Host1 for equivalent Host5 valid values, defaults and other information.

Host5LU – Fifth Host Logical Unit Name

The Host5 string containing the logical unit name of an IBM host with a TN server. This is the logical unit name of the fifth host to contact when login is attempted. The number of retry attempts to Host5 is contained in the Host5RLS parameter. Permission to retry a lost session with Host5 is contained in the Host5RLS parameter.

Note: See the previous parameter description of Host1LU for equivalent Host5LU valid values, defaults and other information.

Host5RLS – Fifth Host Connect Retries

The Host5RLS parameter is used to allow retries with Host5 after a lost session, if PLU data had been previously received from this host, before attempting connection with Host6.

Note: See the previous parameter description of Host1RLS for equivalent Host5RLS valid values, defaults and other information.

Host6 – Sixth Host Name

The host string containing the domain name or IP address of an IBM host with a TN server. This is the sixth host to contact when login is attempted. The number of retry attempts to Host6 is contained in the Host6RLS parameter. Permission to retry a lost session with Host6 is contained in the Host6RLS parameter.

Note: See the previous parameter description of Host1 for equivalent Host6 valid values, defaults and other information.

Host6LU – Sixth Host Logical Unit Name

The Host6 string containing the logical unit name of an IBM host with a TN server. This is the logical unit name of the sixth host to contact when login is attempted. The number of retry attempts to Host6 is contained in the Host6RLS parameter. Permission to retry a lost session with Host6 is contained in the Host6RLS parameter.

Note: See the previous parameter description of Host1LU for equivalent Host6LU valid values, defaults and other information.

Host6RLS – Sixth Host Connect Retries

The Host6RLS parameter is used to allow retries with Host6 after a lost session, if PLU data had been previously received from this host.

Note: See the previous parameter description of Host1RLS for equivalent Host6RLS valid values, defaults and other information.

HostDataTimeout – Host Wait Interval**Function**

The parameter containing the number of seconds the TE will wait after a TCP/IP connection before trying the next host if no data is received from the host. When the host wait interval has expired and the connection is not made, the next host – with YES in the HostnRLS parameter – will be tried.

The HostDataTimeout timer starts when a message similar to “Connecting to” disappears from the screen. The timer starts counting down until the host responds with data. When data is received from the host, the time delay function is closed and the login process continues. If data is not received from the host before the time delay function concludes, the next host will be tried and the HostDataTimeout process begins again.

Setting this parameter to 0 inhibits the host data timeout function. LXE does not recommend setting this parameter to 0.

Options

Valid options: 0 (disabled)
1 - 240

Default setting: 20

Change the parameter by pressing the left or right arrow keys until the desired setting is displayed or by typing the number of the desired setting. Press [Esc] to return to the Protocol Menu. When exiting the utility, select the Exit with Save option.

Access Level

Parameter may only be modified by a user with an access level of 2 or 3.

Auto Login Parameters

The Auto Login feature parameters allows the TELNET client used by the computer to use the autologin parameters and function as an automatic login for the user.

Note: The default value for AutoLoginOn is “Disabled”.

Auto Login is designed for NVT(ASCII) mode and IBM data stream mode. The prompts and replies do not need to differentiate what type of mode to be in. The client mode will determine the prompt to match (in ASCII or EBCDIC) on the screen received from the host or server.

The prompt only needs to match any word or phrase on the receiving message for the reply to be sent as keyboard input. In the Reply fields, to identify any function or AID key for IBM data stream, the name of the key must be in curly brackets, i.e. {enter}, {DEL}, {SysReq}, {f1}, {f12}, etc. for that key's value to be sent in the message.

When specifying keypresses in the Reply1 and Prompt1 match fields, use {TAB} with {NEXT} and {Enter} with {Enter}.

With NVT data stream, the only function key supported is {Enter}. Control keys with characters A to Z are identified as ^A, ^B, ^C, ...^Z.

The Auto Login screen contains parameters pertaining to computer login:

Press the <Esc> key to return to the Protocol Menu.

Note: There are six (6) parameters available for prompts (Prompt1 through Prompt6) and six (6) parameters available for reply (Reply1 through Reply6). The only difference in the parameter names is the number at the end of the parameter. The functions of each are the same.

After Login and Password have been completed, you can use the rest of the prompt/reply sequences to, for example, issue commands, load files, or start a program running, once the user has been auto connected to the host.

Note: Be aware the host may send multiple screens that appear to the user as only one screen. Choose a prompt content as close to the reply input field as possible to eliminate the possibility the prompt is a part of one screen and the reply is a part of another screen.

Auto Login and the MX2

The MX2 keypad does not have “{“ or “}” keys. To define an Auto Login setup, it is necessary transfer the LXE.INI file to a PC, edit the file on the PC, and then transfer the LXE.INI file back to the MX2.

Lines longer than 25 characters may not display correctly in the configuration file. Even though the line does not display, it functions correctly. To view the entire LXE.INI file, use the NED.EXE text editor.

AutoLoginOn – Terminal Automatic Login**Function**

Turn autologin function on (Enabled). When this parameter is set to enabled, the TELNET client used by the computer will use the autologin parameters and attempt to autologin at computer powerup.

When it is disabled, the computer will stop at the signon screen and the user must supply the response to the login: and Password: prompts to get logged in.

Open stack only.

Options

Valid options: Disabled, Enabled

Default setting: Disabled

Change the parameter by pressing the left or right arrow keys until the desired setting is displayed. Press [Esc] to return to the Protocol Menu. When exiting the utility, select the Exit with Save option.

Access Level

Parameter may only be modified by a user with an access level of 2 or 3.

Prompt1 – First Host String**Function**

The host string that the computer's auto login must see in order to send Reply1 back to the host. Normally this is the "User:" prompt.

Prompt2 stores the text of the second string in the auto login process. Normally this is the Password: prompt.

Prompt3 stores the text of the third string in the auto login process.

Prompt4 stores the text of the fourth string in the auto login process.

Prompt5 stores the text of the fifth string in the auto login process.

Prompt6 stores the text of the sixth string in the auto login process.

Options

Valid options: [user defined] all characters except quotation marks (") and the left square bracket ([)

Default setting: Blank

Change the parameter by typing the text displayed to the user. Press [Esc] to return to the Protocol Menu. When exiting the utility, select the Exit with Save option.

Access Level

Parameter may only be modified by a user with an access level of 2 or 3.

Reply1 – First Response Sent to Host**Function**

The string that the computer's autologin mechanism sends to the host after Prompt1 has been received. Normally this is the user name that is being logged in.

Reply2 stores the text of the second string sent to the host. Normally this is the user's password.

Reply3 stores the text of the third string sent to the host.

Reply4 stores the text of the fourth string sent to the host.

Reply5 stores the text of the fifth string sent to the host.

Reply6 stores the text of the sixth string sent to the host.

Options

Valid options: [user defined] all characters except quotation marks (") and the left square bracket ([)

Default setting: Blank

Change the parameter by typing the text of the reply to the host. Press [Esc] to return to the Protocol Menu. When exiting the utility, select the Exit with Save option.

Access Level

Parameter may only be modified by a user with an access level of 2 or 3.

Prompt2 – Second Host String

The host string that the computer's auto login must see in order to send Reply2 back to the host.

Note: See the previous parameter description of Prompt1 for equivalent Prompt2 valid values, defaults and other information.

Reply2 – Second Response Sent to Host

The string that the computer's autologin mechanism sends to the host after Prompt2 has been received.

Note: See the previous parameter description of Reply1 for equivalent Reply2 valid values, defaults and other information.

Prompt3 – Third Host String

The host string that the computer's auto login must see in order to send Reply3 back to the host.

Note: See the previous parameter description of Prompt1 for equivalent Prompt3 valid values, defaults and other information.

Reply3 – Third Response Sent to Host

The string that the computer's autologin mechanism sends to the host after Prompt3 has been received.

Note: See the previous parameter description of Reply1 for equivalent Reply3 valid values, defaults and other information.

Prompt4 – Fourth Host String

The host string that the computer's auto login must see in order to send Reply4 back to the host.

Note: See the previous parameter description of Prompt1 for equivalent Prompt4 valid values, defaults and other information.

Reply4 – Fourth Response Sent to Host

The string that the computer's autologin mechanism sends to the host after Prompt4 has been received.

Note: See the previous parameter description of Reply1 for equivalent Reply4 valid values, defaults and other information.

Prompt5 – Fifth Host String

The host string that the computer's auto login must see in order to send Reply5 back to the host.

Note: See the previous parameter description of Prompt1 for equivalent Prompt5 valid values, defaults and other information.

Reply5 – Fifth Response Sent to Host

The string that the computer's autologin mechanism sends to the host after Prompt5 has been received.

Note: See the previous parameter description of Reply1 for equivalent Reply5 valid values, defaults and other information.

Prompt6 – Sixth Host String

The host string that the computer's auto login must see in order to send Reply6 back to the host.

Note: See the previous parameter description of Prompt1 for equivalent Prompt6 valid values, defaults and other information.

Reply6 – Sixth Response Sent to Host

The string that the computer's autologin mechanism sends to the host after Prompt6 has been received.

Note: See the previous parameter description of Reply1 for equivalent Reply6 valid values, defaults and other information.

ALITimeout – Login Interval Timeout**Function**

The parameter containing the number of seconds to wait between sending Prompt n and Reply n and the next Prompt n .

Options

Valid options: 0 - 120 sec

Default setting: 10 sec.

Change the parameter by pressing the left or right arrow keys until the desired setting is displayed or by typing the number of the desired setting. Press [Esc] to return to the Protocol Menu. When exiting the utility, select the Exit with Save option.

Access Level

Parameter may only be modified by a user with an access level of 2 or 3.

Interface Parameters

The Interface parameters are changed by editing the SOCKET.CFG file. When the Interface option is selected, the user is instructed to manually edit the parameters in the SOCKET.CFG file:

Manually edit SOCKET.CFG in the pctcp dir



For information on editing the SOCKET.CFG file, please refer to the reference guide for the appropriate LXE computer.

DNS Parameters

The DNS parameters are changed by editing the SOCKET.CFG file. When the DNS option is selected, the user is instructed to manually edit the parameters in the SOCKET.CFG file:

Manually edit SOCKET.CFG in the pctcp dir



For information on editing the SOCKET.CFG file, please refer to the reference guide for the appropriate LXE computer.

General Parameters

The General parameters are changed by editing the SOCKET.CFG file. When the General option is selected, the user is instructed to manually edit the parameters in the SOCKET.CFG file:

Manually edit SOCKET.CFG in the pctcp dir



For information on editing the SOCKET.CFG file, please refer to the reference guide for the appropriate LXE computer.

Kernel Parameters

The Kernel parameters are changed by editing the SOCKET.CFG file. When the Kernel option is selected, the user is instructed to manually edit the parameters in the SOCKET.CFG file:

Manually edit SOCKET.CFG in the pctcp dir



For information on editing the SOCKET.CFG file, please refer to the reference guide for the appropriate LXE computer.

Logging Parameters

The Logging screen contains parameters pertaining to TN events and logs.

Press the <Esc> key to return to the Protocol Menu.

EvtMask – Event Logging Mask

Function

The EvtMask parameter is Off when the parameter value is 0. A value of 1F indicates all options are On.

Options

Valid options: [user defined]

Default setting: 0

Change the parameter by pressing the left or right arrow keys until the desired setting is displayed or by typing in a hexadecimal code between 0 and 1f. Press [Esc] to return to the Protocol Menu. When exiting the utility, select the Exit with Save option.

Access Level

Parameter may only be modified by a user with an access level of 2 or 3.

TNLogging – TELNET Logging

Function

The TNLogging function can be turned on and off using this parameter.

Options

Valid options: On, Off

Default setting: Off

Change the parameter by pressing the left or right arrow keys until the desired setting is displayed. Press [Esc] to return to the Protocol Menu. When exiting the utility, select the Exit with Save option.

Access Level

Parameter may only be modified by a user with an access level of 2 or 3.

TNLogFS – TELNET Log File Size**Function**

Use the TNLogFS parameter to set the size of the TN logging file. Setting the value to 1 will inhibit TN logging.

Options

Valid options: 1 - 62

Default setting: 20

Change the parameter by pressing the left or right arrow keys until the desired setting is displayed or by typing the number of the setting. Press [Esc] to return to the Protocol Menu. When exiting the utility, select the Exit with Save option.

Access Level

Parameter may only be modified by a user with an access level of 2 or 3.

Radio Menu Option – 6400 and 6500 Systems

The Radio menu contains parameters pertaining to the Radio Frequency Network. Upon choosing Radio at the Main Menu, the next screen displayed is the Radio submenu.

To return to the Main Menu press the <Esc> key. A detailed description of 2.4GHz Radio parameters follows.

Driver Settings

The Driver Settings parameters are changed by editing the NET.CFG file. When the Driver Settings option is selected, the user is instructed to manually edit the parameters in the NET.CFG file:

[Manually edit NET.CFG in the pctcp dir](#)



For information on editing the NET.CFG file, please refer to the reference guide for the appropriate LXE computer.

Packet Driver

The Packet Driver parameters are changed by editing the NET.CFG file. When the Packet Driver option is selected, the user is instructed to manually edit the parameters in the NET.CFG file:

[Manually edit NET.CFG in the pctcp dir](#)



For information on editing the NET.CFG file, please refer to the reference guide for the appropriate LXE computer.

Platform Menu

Upon choosing Platform at the Main Menu, the next screen displayed is the first in a series of screens:

To return to the Main Menu press the [Esc] key. To view the next Platform screen, press the PageDown key:

A detailed description of Platform parameters follows.

Note: Configuration menu options and components displayed are unique to the computer being configured, the current user's access level, the computer screen display size.

Parameter Access Levels

Refer to the “System Passwords” section of this chapter for more information on *access levels*.

CursorType – Cursor Type

Function

The CursorType parameter determines whether the cursor will be displayed as a block or an underscore character.

Options

Valid options: Block, Underscore

Default setting: Block

Change the parameter by pressing the left or right arrow keys until the desired setting is displayed. Press [Esc] to return to the Platform Menu. When exiting the utility, select the Exit with Save option.

Access Level

Parameter may only be modified by a user with an access level of 2 or 3.

BeeperVolume – Beeper Volume**Function**

The BeeperVolume parameter specifies the default beeper volume for the computer. This parameter allows you to increase or decrease the beeper volume. Each computer may react differently to the beeper settings; some settings may appear to give the same audible tone. The volume ranges from inaudible (lower numbers) to loud (higher numbers).

Note: The MX1 must have an endcap installed. The beeper is located in the MX1 endcap.

Options

Valid options: 0 (Beeper off)
1 - 9

Default setting: 6 (2325/MX2)
9 (MX3)
5 (all other platforms)

Change the parameter by pressing the left or right arrow keys until the desired setting is displayed. Press [Esc] to return to the Platform Menu. When exiting the utility, select the Exit with Save option.

Access Level

Parameter may only be modified by users with access levels of 1, 2 or 3.

Printing – Print to COM Port**Function**

The Printing parameter allows you to print using the COM port. The LXE Escape *P causes the TE to print to the RS232 port.

Options

Valid options: Enabled, Disabled

Default setting: Disabled

Change the parameter by pressing the left or right arrow keys until the desired setting is displayed. Press [Esc] to return to the Platform Menu. When exiting the utility, select the Exit with Save option.

Access Level

Parameter may only be modified by users with access levels of 2 or 3.

Com1BaudRate – COM1 Baud Rate**Function**

The Com1BaudRate parameter specifies the baud rate setting for communication port 1 (COM1).

Options

Valid options: 600, 1200, 2400, 4800, 9600, 19200, 38400 bps

Default setting: 9600

Change the parameter by pressing the left or right arrow keys until the desired setting is displayed. Press [Esc] to return to the Platform Menu. When exiting the utility, select the Exit with Save option.

Access Level

Parameter may only be modified by users with an access level of 2 or 3.

Com1DataBits – COM1 Data Bits**Function**

The Com1DataBits parameter specifies the data bits setting for communications port number 1 (COM1).

Options

Valid options: Eight, Seven

Default setting: Eight

Change the parameter by pressing the left or right arrow keys until the desired setting is displayed. Press [Esc] to return to the Platform Menu. When exiting the utility, select the Exit with Save option.

Access Level

Parameter may only be modified by users with an access level of 2 or 3.

Com1Parity – COM1 Parity**Function**

The Com1Parity parameter specifies the parity setting for communications port number 1 (COM1).

Options

Valid options: Even, Odd, None

Default setting: None

Change the parameter by pressing the left or right arrow keys until the desired setting is displayed. Press [Esc] to return to the Platform Menu. When exiting the utility, select the Exit with Save option.

Access Level

Parameter may only be modified by a user with an access level of 2 or 3.

Com1StopBits – COM1 Stop Bits**Function**

The Com1StopBits parameter specifies the stop bits setting for communications port number 1 (COM1).

Options

Valid options: 1, 2

Default setting: 1

Change the parameter by pressing the left or right arrow keys until the desired setting is displayed. Press [Esc] to return to the Platform Menu. When exiting the utility, select the Exit with Save option.

Access Level

Parameter may only be modified by a user with an access level of 2 or 3.

Com1HalfDuplex – COM1 Half Duplex**Function**

The Com1HalfDuplex parameter determines whether or not characters received on communications port number 1 (COM1) are echoed back to COM1. When Echo is selected, the characters received on COM1 are echoed back out to COM1. When No Echo is selected, the characters are not echoed.

Options

Valid options: Echo, No Echo

Default setting: No Echo

Change the parameter by pressing the left or right arrow keys until the desired setting is displayed. Press [Esc] to return to the Platform Menu. When exiting the utility, select the Exit with Save option.

Access Level

Parameter may only be modified by users with an access level of 2 or 3.

Com1Xon – COM1 Software Flow Control**Function**

The Com1Xon parameter enables or disables the use of software flow control (XON/XOFF) for communications port number 1 (COM1).

Options

Valid options: Disable, Enable

Default setting: Disable

Change the parameter by pressing the left or right arrow keys until the desired setting is displayed. Press [Esc] to return to the Platform Menu. When exiting the utility, select the Exit with Save option.

Access Level

Parameter may only be modified by users with an access level of 2 or 3.

Com1HwFlowCtrl – COM1 Hardware Flow Control**Function**

The Com1HwFlowCtrl parameter specifies the Platform flow control setting for communications port number 1 (COM1).

Options

Valid options: Off, RTS/CTS, DTR/CTS

Default setting: Off

Change the parameter by pressing the left or right arrow keys until the desired setting is displayed. Press [Esc] to return to the Platform Menu. When exiting the utility, select the Exit with Save option.

Access Level

Parameter may only be modified by users with an access level of 2 or 3.

Com1TimeOut – COM1 Time Out**Function**

The Com1TimeOut parameter enables or disables the time out feature for communications port number 1 (COM1). When enabled (On), a gap of more than 50ms between characters received on COM1 terminates the message. When disabled (Off), the message is not terminated by a time gap between characters.

Options

Valid options: Off, On

Default setting: Off

Change the parameter by pressing the left or right arrow keys until the desired setting is displayed. Press [Esc] to return to the Platform Menu. When exiting the utility, select the Exit with Save option.

Access Level

Parameter may only be modified by users with an access level of 2 or 3.

Com1PassTermChar – COM1 Pass Termination Character**Function**

The Com1PassTermChar parameter determines whether or not communications port number 1 (COM1) will propagate (transmit to host) the termination character. Propagation characters are: 00, 0A, 0D.

Options

Valid options: Don't Propagate, Propagate

Default setting: Propagate

Change the parameter by pressing the left or right arrow keys until the desired setting is displayed. Press [Esc] to return to the Platform Menu. When exiting the utility, select the Exit with Save option.

Access Level

Parameter may only be modified by a user with an access level of 2 or 3.

Com1Interrupt – COM1 Interrupt**Function**

The Com1Interrupt parameter determines if power is interrupted to Com1 when the keyboard is locked. If Com1Interrupt is On, power to the scanner (Com1) is turned off when the keyboard is locked. This parameter is not valid for 2325/MX2.

Options

Valid options: Off, On

Default setting: Off

Change the parameter by pressing the left or right arrow keys until the desired setting is displayed. Press [Esc] to return to the Platform Menu. When exiting the utility, select the Exit with Save option.

Access Level

Parameter may only be modified by a user with an access level of 2 or 3.

Com2BaudRate – COM2 Baud Rate**Function**

The Com2BaudRate parameter specifies the baud rate setting for communication port number 2 (COM2). This parameter is not valid for 2325/MX2.

Options

Valid options: 600, 1200, 2400, 4800, 9600, 19200, 38400 bps

Default setting: 9600

Change the parameter by pressing the left or right arrow keys until the desired setting is displayed. Press [Esc] to return to the Platform Menu. When exiting the utility, select the Exit with Save option.

Access Level

Parameter may only be modified by a user with an access level of 2 or 3.

Com2DataBits – COM2 Data Bits**Function**

The Com2DataBits parameter specifies the data bits setting for communications port number 2 (COM2). This parameter is not valid for 2325/MX2.

Options

Valid options: Eight, Seven

Default setting: Eight

Change the parameter by pressing the left or right arrow keys until the desired setting is displayed. Press [Esc] to return to the Platform Menu. When exiting the utility, select the Exit with Save option.

Access Level

Parameter may only be modified by a user with an access level of 2 or 3.

Com2Parity – COM2 Parity**Function**

The Com2Parity parameter specifies the parity setting for communications port number 2 (COM2). This parameter is not valid for 2325/MX2.

Options

Valid options: Even, Odd, None

Default setting: None

Change the parameter by pressing the left or right arrow keys until the desired setting is displayed. Press [Esc] to return to the Platform Menu. When exiting the utility, select the Exit with Save option.

Access Level

Parameter may only be modified by a user with an access level of 2 or 3.

Com2StopBits – COM2 Stop Bits**Function**

The Com2StopBits parameter specifies the stop bits setting for communications port number 2 (COM2). This parameter is not valid for 2325/MX2.

Options

Valid options: 1, 2

Default setting: 1

Change the parameter by pressing the left or right arrow keys until the desired setting is displayed. Press [Esc] to return to the Platform Menu. When exiting the utility, select the Exit with Save option.

Access Level

Parameter may only be modified by a user with an access level of 2 or 3.

Com2HalfDuplex – COM2 Half Duplex**Function**

The Com2HalfDuplex parameter determines whether or not characters received on communications port number 2 (COM2) are echoed back to COM2. When Echo is selected, the characters received on COM2 are echoed back out to COM2. When No Echo is selected, the characters are not echoed. This parameter is not valid for 2325/MX2.

Options

Valid options: Echo, No Echo

Default setting: No Echo

Change the parameter by pressing the left or right arrow keys until the desired setting is displayed. Press [Esc] to return to the Platform Menu. When exiting the utility, select the Exit with Save option.

Access Level

Parameter may only be modified by a user with an access level of 2 or 3.

Com2Xon – COM2 Software Flow Control**Function**

The Com2Xon parameter enables or disables the use of software flow control (XON/XOFF) for communications port number 2 (COM2). This parameter is not valid for 2325/MX2.

Options

Valid options: Disable, Enable

Default setting: Disable

Change the parameter by pressing the left or right arrow keys until the desired setting is displayed. Press [Esc] to return to the Platform Menu. When exiting the utility, select the Exit with Save option.

Access Level

Parameter may only be modified by a user with an access level of 2 or 3.

Com2HwFlowCtrl – COM2 Hardware Flow Control**Function**

The Com2HwFlowCtrl parameter specifies the hardware flow control setting for communications port number 2 (COM2). This parameter is not valid for 2325/MX2.

Options

Valid options: Off, RTS/CTS, DTR/CTS

Default setting: Off

Change the parameter by pressing the left or right arrow keys until the desired setting is displayed. Press [Esc] to return to the Platform Menu. When exiting the utility, select the Exit with Save option.

Access Level

Parameter may only be modified by a user with an access level of 2 or 3.

Com2TimeOut – COM2 Time Out**Function**

The Com2TimeOut parameter enables or disables the time out feature for communications port number 2 (COM2). When enabled (On), a gap of more than 50ms between characters received on COM2 terminates the message. When disabled (Off), the message is not terminated by a time gap between characters. This parameter is not valid for 2325/MX2.

Options

Valid options: Off, On

Default setting: Off

Change the parameter by pressing the left or right arrow keys until the desired setting is displayed. Press [Esc] to return to the Platform Menu. When exiting the utility, select the Exit with Save option.

Access Level

Parameter may only be modified by a user with an access level of 2 or 3.

Com2PassTermChar – COM2 Pass Termination Character**Function**

The Com2PassTermChar parameter determines whether or not communications port number 2 (COM2) will propagate (transmit to host) the termination character. Propagation characters are: 00, 0A, 0D. This parameter is not valid for 2325/MX2.

Options

Valid options: Don't Propagate, Propagate

Default setting: Propagate

Change the parameter by pressing the left or right arrow keys until the desired setting is displayed. Press [Esc] to return to the Platform Menu. When exiting the utility, select the Exit with Save option.

Access Level

Parameter may only be modified by a user with an access level of 2 or 3.

Com2Interrupt – COM2 Interrupt**Function**

The Com2Interrupt parameter determines if power is interrupted to COM2 when the keyboard is locked. If Com2Interrupt is On, power to the scanner (COM2) is turned off when the keyboard is locked. This parameter is not valid for 2325/MX2.

Options

Valid options: Off, On

Default setting: Off

Change the parameter by pressing the left or right arrow keys until the desired setting is displayed. Press [Esc] to return to the Platform Menu. When exiting the utility, select the Exit with Save option.

Access Level

Parameter may only be modified by a user with an access level of 2 or 3.

InitialScrlDly – Initial Scroll Delay

Function

The InitialScrlDly parameter determines how long (in milliseconds) a key must be held down (depressed) before it repeats.

Options

Valid options: 0, 250, 500, 750, 1000 msec

Default setting: 500

Change the parameter by pressing the left or right arrow keys until the desired setting is displayed. Press [Esc] to return to the Platform Menu. When exiting the utility, select the Exit with Save option.

Access Level

Parameter may only be modified by a user with an access level of 2 or 3.

RepeatScrlDly – Repeat Scroll Delay

Function

The RepeatScrlDly parameter specifies the speed (in cps - characters per second) at which the key is repeated or the cursor moves across the display.

Options

Valid options: 2, 8, 16, 24, 30 cps

Default setting: 16

Change the parameter by pressing the left or right arrow keys until the desired setting is displayed. Press [Esc] to return to the Platform Menu. When exiting the utility, select the Exit with Save option.

Access Level

Parameter may only be modified by a user with an access level of 2 or 3.

HardwareModel – Hardware Model

Function

The HardwareModel parameter specifies which computer is configured.

Options

Valid options: MX1, MX3, 1330/1390/VX2, 1320/1380/VX1, 2325/MX2

Default setting: Set by LXE Engineering (Read Only)

Access level

This is a **read only** parameter that may be viewed but not modified.

ScreenSize – Font Size Selections**Function**

This option allows the user to configure the display fonts on DOS computers running the terminal emulation program. These settings are in effect only when the TE program is running. They do not supercede the font settings at the DOS prompt or on a batch unit.

Options**MX1**

Valid options: 10 rows x 20 cols
 10 rows x 24 cols
 16 rows x 20 cols
 16 rows x 24 cols
 20 rows x 20 cols

Default setting: 20 rows x 20 cols

2325 / MX2

Valid options: 9 rows x 20 cols
 16 rows x 20 cols

Default setting: 9 rows x 20 cols

MX3

Valid options: 8 rows x 40 cols
 16 rows x 40 cols
 12 rows x 80 cols
 16 rows x 80 cols
 25 rows x 80 cols

Default setting: 16 rows x 80 cols

1380 / VX1

Valid options: 8 rows x 40 cols
 16 rows x 40 cols
 12 rows x 80 cols
 16 rows x 80 cols
 25 rows x 80 cols

Default setting: 12 rows x 80 cols

1390 / VX2 / VX4

Valid options: 16 rows x 40 cols
 25 rows x 40 cols
 25 rows x 80 cols

Default setting: 25 rows x 80 cols

Access Level

This is a level 2 read only parameter that may be viewed but not modified by a user with an access level of 2.

APIType – API Type

Function

The APIType parameter specifies the API (Application Program Interface) type.

Options

Valid options: MX3, 1330/1320, MX1, 1380/1390, VX1/VX2, MX2/2325

Default setting: Set by LXE Engineering (Read Only)

Access Level

This is a **read only** parameter that may be viewed but not modified.

DockedBehavior – Docked I/O Configuration

Function

The DockedBehavior parameter specifies which comm port to use as local input (for a bar code scanner) and which one to use as local output (for a printer). This parameter only affects operation of the MX1 and MX3 when they are docked. This parameter is valid for MX1 and MX3 only.

The MX1 supports endcaps with an integrated scanner, an RS-232 port or both. A selection of a DockedBehavior configuration that is not fully supported by the endcap will result in partial functionality. The TE will not attempt to correct the selection.

The MX3 COM2 port supports both an IR port and an RS-232 port. The power is applied to the port configured as input until the terminal receives a print command. At that time, the power is switched to the port configured as output. When the print command is completed, power is returned to the input port. This configuration option allows dual scanning through a cradle.

Options

MX1

Valid options:	Not supported ¹	COM1 RS-232	Not supported
		COM1 Scanner	Not supported
		COM2 IR	Not supported
	RS-IN/OUT:IR:IN	COM1 RS-232	Input/Output
		COM1 Scanner	N/A
		COM2 IR	Input
	IS-IN:IR-IN/OUT	COM1 RS-232	N/A
		COM1 Scanner	Input
		COM2 IR	Input/Output
	RS-IN:IR-IN/OUT	COM1 RS-232	Input
		COM1 Scanner	N/A
		COM2 IR	Input/Output
	IS&RS-IN:RS-OUT	COM1 RS-232	Output
		COM1 Scanner	Input
		COM2 IR	Input

Default setting: Not supported

¹ Defaults to undocked configuration. See Normal IO.

MX3

Valid options:	Not supported ²	COM1	Not supported
		COM2 IR	Not supported
		COM2 RS-232	Not supported
	CM1-IN:CM2RS-IN/OUT	COM1	Input
		COM2 IR	N/A
		COM2 RS-232	Input/Output
	CM1-IN/OUT:CM2RS-IN	COM1	Input/Output
		COM2 IR	N/A
		COM2 RS-232	Input
	CM1-IN:CM2IR-IN/OUT	COM1	Input
		COM2 IR	Input/Output
		COM2 RS-232	N/A
	CM1-IN/OUT:CM2IR-IN	COM1	Input/Output
		COM2 IR	Input
		COM2 RS-232	N/A
	CM1&CM2RS-IN:IR-OUT	COM1	Input
		COM2 IR	Output
		COM2 RS-232	Input
	CM1&IR-IN:CM2RS-OUT	COM1	Input
		COM2 IR	Input
		COM2 RS-232	Output

Default setting: Not supported

Access Level

Parameter may only be modified by a user with an access level of 2 or 3.

Related Parameters

NormalIO

² Defaults to undocked configuration. See Normal IO.

NormalIO – Undocked I/O Configuration

Function

The NormalIO parameter specifies which comm port to use as local input (for a bar code scanner) and which one to use as local output (for a printer). This parameter only affects operation of the MX1 and MX3 when they are not docked. This parameter is also valid for 1380, 1390, VX1, VX2 and VX4.

The MX1 supports endcaps with an integrated scanner, an RS-232 port or both. A selection of a NormalIO configuration that is not fully supported by the endcap will result in partial functionality. The TE will not attempt to correct the selection.

Options

MX1

Valid options:	IS-IN:RS-OUT	COM1 RS-232	Output
		COM1 Scanner	Input
		COM2 IR	N/A
	RS-IN/OUT	COM1 RS-232	Input/Output
		COM1 Scanner	N/A
		COM2 IR	N/A
	IS-IN	COM1 RS-232	N/A
		COM1 Scanner	Input
		COM2 IR	N/A

Default setting: IS-IN:RS-OUT

MX3

Valid options:	CM1-IN:CM2 RS-IN/OUT	COM1	Input
		COM2 IR	N/A
		COM2 RS-232	Input/Output
	CM1-IN/OUT:CM2 RS-IN	COM1	Input/Output
		COM1 IR	N/A
		COM2 RS-232	Input

Default setting: CM1-IN:CM2 RS-IN/OUT

VX1, VX2, VX4, 1380, 1390

Valid options:	CM1-IN:CM2-IN/OUT	COM1	Input
		COM2	Input/Output
	CM1-IN/OUT:CM2-IN	COM1	Input/Output
		COM2	N/A

Default setting: CM1-IN:CM2-IN/OUT

Access Level

Parameter may only be modified by a user with an access level of 2 or 3.

Related Parameters

Docked Behavior

EAN128Fnc1 – Decode F1 As Space**Function**

EAN128Fnc1 enables a scanned F1 (0x1D) character to be decoded as a space or dropped from barcode data.

When an F1 character is scanned using wand emulation on a legacy terminal, the wand emulation converts all data to Code 39 and any character not in Code 39 is set to a space. Therefore, on the legacy scan, the F1 character is decoded as a space.

However, the LXE DOS computer receives data from the scanner as RS-232 data. When the F1 character is scanned, it is dropped from the barcode data since the character is not printable.

Enabling EAN128Fnc1 allows the 0x1D character to be converted to a space character in the barcode data.

Options

Valid options:	Off	(0x1D character is dropped)
	On	(0x1D character converted to a space)

Default: Off

Access Level

Parameter may only be modified by a user with an access level of 2 or 3.

Exit With Save Option

The Exit with Save option on the main menu allows the user to save the current configuration settings and exit the utility.

To return to the Main Menu press the [Esc] key.

No Press the [N] key and then the [Enter] key to ignore the Save command and remove the Save and Exit text box from the screen display. Parameters are not changed. You are returned to the Main Menu.

- or -

Ignore At the [N] prompt, press the [Enter] or [Esc] key to remove the text box from the screen display. You are returned to the Main Menu.

- or -

Yes Press the [Y] key and then the [Enter] key to save changes made to configuration parameters. Configuration files are updated upon exit.

Upon choosing [Y], the next screen displays:

Press any key to continue.

Press the [Enter] key to save changes made to configuration parameters and restart the computer.

The computer will need to be turned off and then on again for new parameter values to take effect.

Configuration files are updated upon exiting the Configuration utility.

Exit Without Save Option

The Exit without Save option on the main menu allows the user to exit the configuration utility without saving any changes made to the current settings.

To return to the Main Menu press the [Esc] key.

Yes Press the [Y] key and then the [Enter] key to exit the Configuration program. Configuration files are not changed.

- or -

No Press the [N] key and then the [Enter] key to ignore the Exit command and remove the Exit text box from the screen display. System values are not changed and you are returned to the Main Menu.

- or -

Ignore At the [N] prompt, press the [Esc] key twice to remove the Exit box from the screen display. System values are not changed and you are returned to the Main Menu.

Table of Contents

CHAPTER 4 CODE PAGES AND CHARACTER SETS	4-1
Introduction	4-1
Displayable Characters	4-2
Default Code Page	4-2
LXE Character Set.....	4-3
Default TE EBCDIC Character Set	4-4
Creating EBCDIC National Character Sets	4-5
Example: UK EBCDIC Character Set.....	4-6
Sample EBCDIC.TXT File	4-7
Keyboard Mapping.....	4-8
Special Keys	4-8
Alphanumeric Keys	4-8
Modifying the Keyboard Map	4-9
Sample Keys.Txt File	4-9
Messages.....	4-10
Default Messages.....	4-10
Editing The Message.Txt File	4-10
Sample Message.Txt File	4-11
Editing ASCII Files	4-12
Editing Files at the Computer	4-12
Edit then Transfer Files Using a PC Card	4-13
Transfer Files Using DOS REMDISK/REMSERV	4-15

Illustrations

Figure 4-1 Code Page 00437	4-2
Figure 4-2 LXE Character Set - Abbreviated	4-3
Figure 4-3 USA/Canada IBM EBCDIC.....	4-4
Figure 4-4 U.K. IBM EBCDIC.....	4-6



Chapter 4

Code Pages and Character Sets

Introduction

On a standard PC running DOS, a program can access 256 characters from the “Active Code Page” in VGA Text Mode. This character set consists of a table of 256 characters, numbered 0 to 255. A DOS program can display any character by selecting a number between 0 and 255.

The LXE DOS Computers use a standard VGA chipset which produces the same results as on a standard PC.

What is actually displayed on the screen is dependant on which Code Page table is loaded and active. The VGA standard can accommodate 2 loaded Code Pages, with only one active at any given time.

A *Code Page table* is an ordered collection of up to 256 “display fonts”, with each font representing the actual pixels drawn on the display. Hundreds of Code Pages and “Font Files” exist, enabling the display of virtually any character in any language. The TN3270 TE uses two – USA/Canada Code Page 00037 and the LXE Character Set.



Appendix A contains a graphic representation of the USA/Canada IBM EBCDIC code page, the LXE Character Set, Decimal/Hexadecimal counterparts, and the decimal equivalents of Code Page 00437 (USA).

Displayable Characters

Default Code Page

The standard “Code Page” on a U.S. PC is Code Page 437. The first 128 characters represent the standard ASCII characters, and the next 128 are “Extended Characters”. The extended characters include several multi-national characters, such as “à”, and line drawing characters, such as “|”.

Many, but not all of the characters required by the IBM EBCDIC character sets can be displayed using the standard PC character set. The standard PC character set is shown below.

Note: The hexadecimal value of a character is obtained by reading the table first by column then by row

	0	1	2	3	4	5	6	7	8	9	A	B	C	D	E	F
0				0	@	P	`	p	Ç	É	á	Ã	Þ	ã	a	÷
1			!	1	A	Q	a	q	ü	æ	í	È	Ý	Ø	ß	±
2			"	2	B	R	b	r	é	Æ	ó	Ê	®	¬	Γ	≥
3			#	3	C	S	c	s	â	ô	ú	Ê	©	"	π	≤
4			\$	4	D	T	d	t	ä	ö	ñ	ß	¾		Σ	(
5			%	5	E	U	e	u	à	ò	Ñ	ø	õ	Õ	σ)
6			&	6	F	V	f	v	å	û	ª	Í	Ô	¶	μ	÷
7			'	7	G	W	g	w	ç	ù	º	Î	Ò	‡	τ	~
8			(8	H	X	h	x	ê	ÿ	¸	Ï	LL	+	ϕ	°
9)	9	I	Y	i	y	ë	Ö	¬	Ì	¶	‐	Θ	.
A		*	:	J	Z	j	z	è	Ü	¬		Ó	Γ	Ω	.	.
B		+	;	K	[k	{	í	¢	½	¶	Õ	☼	δ	³	
C	,	<	L	\	l		î	£	¼	¶	Û	§	∞	¹		
D	-	=	M]	m	}	ì	¥	í	þ	=	¶	ϕ	²		
E	.	>	N	^	n	~	Ä	Â	«	ý	Ù	§	ε	■		
F	/	?	O	_	o	ã	Ã	Á	»	Ð	Ú	■	∩			

Figure 4-1 Code Page 00437

LXE Character Set

An LXE specific file containing all characters required to display any of the IBM EBCDIC character sets has been developed. This font file is loaded when the TE executes, and is unloaded upon exit.

The LXE Character Set in its entirety is located in Appendix A “EBCDIC Code Pages”. A portion of the Character Set is shown below.

Note: *The hexadecimal value of a character is obtained by reading the table first by column then by row. Add “0x” to the beginning of the hex value, then the column identifier, then the row identifier. For example, the hexadecimal value of the exclamation point in the table shown below is “0x21” and the value of μ is “0xb5”.*

	0	1	2	3	4	5	6	7	8	9	A	B	C	D	E	F
0				0	@	P	`	p	Ç	É	á	Ã	Þ	ã	a	÷
1			!	1	A	Q	a	q	ü	æ	í	È	Ý	Ø	ß	±
2			"	2	B	R	b	r	é	Æ	ó	Ê	®	¬	Γ	≥
3			#	3	C	S	c	s	â	ô	ú	Ë	©	"	π	≤
4			\$	4	D	T	d	t	ä	ö	ñ	ß	¾		Σ	(
5			%	5	E	U	e	u	à	ò	Ñ	ø	õ	Õ	σ)
6			&	6	F	V	f	v	å	û	ª	Í	Ô	∏	μ	÷

Figure 4-2 LXE Character Set - Abbreviated

Default TE EBCDIC Character Set

The TEs contain an internal translation table to map EBCDIC character values to positions in the Active Code Page. For example, the EBCDIC character “0x40” is represented by an ASCII space character. The space character is in position 32 (0x20) in Code Page 437. The TE translation table therefore contains an entry similar to:

0x40 → 32

which says “when an EBCDIC 0x40 value is received, display the character in position 32”.

The internal translation table contains the mapping for all characters in the “USA/Canada” EBCDIC code page. *The mapping assumes that the LXE Character Set is loaded.*

	0	1	2	3	4	5	6	7	8	9	A	B	C	D	E	F
0					&	-	ø	Ø	°	μ	^	{	}	\	0	
1					é	/	É	a	j	~	£	A	J	÷	1	
2				â	ê	Â	Ê	b	k	s	¥	B	K	S	2	
3				ä	ë	Ä	Ë	c	l	t	•	C	L	T	3	
4				à	è	À	È	d	m	u	©	D	M	U	4	
5				á	í	Á	Í	e	n	v	§	E	N	V	5	
6				ã	î	Ã	Î	f	o	w	¶	F	O	W	6	
7				å	ï	Å	Ï	g	p	x	¼	G	P	X	7	
8				ç	ì	Ç	Ì	h	q	y	½	H	Q	Y	8	
9				ñ	ß	Ñ	’	i	r	z	¾	I	R	Z	9	
A				¢	!		:	«	ª	í	[-	ı	²	³	
B				.	\$,	#	»	º	ł]	ô	û	Ô	Û	
C				⟨	*	%	@	ð	æ	Ð	—	ö	ü	Ö	Ü	
D				()	-	'	ý	,	Ý	”	ò	ù	Ò	Ù	
E				+	;	>	=	þ	Æ	þ	'	ó	ú	Ó	Ú	
F					¬	?	"	±	¤	®	×	õ	ÿ	Õ		

Figure 4-3 USA/Canada IBM EBCDIC

Creating EBCDIC National Character Sets

The method for creating EBCDIC character sets for countries other than the U.S. is described below, and is followed by an example.

Upon loading, the TE first loads the LXE Character Set, then searches for a file called “**EBCDIC.TXT**”. If this file is not found, the TE uses its internal translation table (default U.S. EBCDIC). If this file is found, the TE modifies its internal translation table based on the information contained in the file. Each line in this text file contains two entries separated by a space:

EBCDIC character LXE Character Set Position

For example:

0x40 32

- or -

0x40 0x20

Where the <white space> represents any number of spaces and/or tabs, and is used for clarity. The first entry is the EBCDIC character position in hexadecimal in the *default EBCDIC character table*, and the second entry is the hexadecimal or decimal position in the LXE Character Set table.

The **EBCDIC.TXT** file is a standard DOS text file, and may be edited using the DOS **edit** utility.

Example: UK EBCDIC Character Set

The table below shows the UK EBCDIC Character Set. The highlighted cells indicate characters that are in different positions when compared to the US Character Set.

Note: The hexadecimal value of a character is obtained by reading the table first by column then by row. Add “0x” to the beginning of the hex value, then the column identifier, then the row identifier. For example, the hexadecimal value of the exclamation point in the table shown below is “0x5a” and the value of μ is “0xa0”.

	0	1	2	3	4	5	6	7	8	9	A	B	C	D	E	F	
0						&	-	ø	Ø	°	μ	¢	{	}	\	0	
1						é	/	É	a	j	—	[A	J	÷	1	
2						â	ê	Â	Ê	b	k	s	¥	B	K	S	2
3						ä	ë	Ä	Ë	c	l	t	•	C	L	T	3
4						à	è	À	È	d	m	u	©	D	M	U	4
5						á	í	Á	Í	e	n	v	§	E	N	V	5
6						ã	î	Ã	Î	f	o	w	¶	F	O	W	6
7						å	ï	Å	Ï	g	p	x	¼	G	P	X	7
8						ç	ì	Ç	Ì	h	q	y	½	H	Q	Y	8
9						ñ	ß	Ñ	’	i	r	z	¾	I	R	Z	9
A						\$!		:	«	ª	í	^	-	¹	²	³
B						.	£	,	#	»	°	¿]	ô	û	Ô	Û
C						‘	*	%	@	ð	æ	Ð	~	ö	ü	Ö	Ü
D						()	—	'	ý	,	Ý	..	ò	ù	Ò	Ù
E						+	;	>	=	þ	Æ	þ	'	ó	ú	Ó	Ú
F							¬	?	"	±	¤	®	×	ð	ÿ	Õ	

Figure 4-4 U.K. IBM EBCDIC

The following characters are in different positions:

Display Character	Position in LXE Character Set	Position in US EBCDIC	Position in UK EBCDIC
	Figure 4-2	Figure 4-3	Figure 4-4
\$	0x24	0x5b	0x4a
£	0xa3	0xb1	0x5b
¢	0xa2	0x4a	0xb0
[0x5b	0xba	0xb1
{	0x7b	N/A	0xc0
^	0x5e	0xb0	0xba
- (upper)	0xaf	0xbc	0xa1

The **EBCDIC.TXT** file to generate the U.K. EBCDIC translation table would then contain the following entries:

```
0x4a, 0x24
0x5b, 0xa3
0xb0, 0xa2
0xb1, 0x5b
0xc0, 0x7b
0xba, 0x5e
0xa1, 0xaf
```

This lets the TE replace the given EBCDIC locations with the desired characters from the LXE Character Set Table.

Sample EBCDIC.TXT File

```
0x41, 0x24
0x5b, 0xa3
0xb0, 0xa2
0xb1, 0x5b
0xc0, 0x7b
0xba, 0x5e
0xa1, 0xaf
```

Keyboard Mapping

Note: If a key combination is already used by the TE to generate either IBM or LXE commands, these key's maps will be disregarded. Please refer to Chapter 2 "Daily Operation" section titled "Keys and Key Sequences" for a comprehensive listing of these special keys.

On a standard PC 101-key keyboard and on LXE Computers, every alphanumeric key (A..Z, 0..9) has a four possible states:

State	Description
Normal	Normal key pressed
Shifted	Key pressed with Shift key down
Alt	Key pressed with Alt key down
Ctrl	Key pressed with Ctrl key down

In the Normal and Shifted states, the key generates a displayable character; that is the key with the legend 'A' will display an 'a' in the Normal state, and an 'A' in the shifted state. The Alt and Ctrl states are used to augment the Computer's functionality.

In general, there are three types of keys used by the TEs. These are:

- a) IBM Function Keys, such as "F1".
- b) LXE Function Keys, such as "Setup", or "Function Key Editor".
- c) Displayable Character Keys.

Since the first two types of keys do not have legends on PC or LXE DOS Computers keyboards, LXE has mapped certain Alt and Ctrl state keys to these functions. For example, a **Ctrl-S** generates an IBM "System Request" command and an **Alt-S** generates an LXE "Setup" command.

Special Keys

In general, an attempt has been made to reserve **Alt-** key combinations to LXE commands, and **Ctrl-** key combinations to IBM commands, although this may not always be the case. Function keys (labeled F1 through F10) are reserved for use for IBM emulation.

Those keys (and corresponding key states) that have not been reserved may be mapped to display characters that are not inherently available directly from the keyboard.

Alphanumeric Keys

All alphanumeric keys translate into their IBM displayable counterparts. That is, an "A" on the keyboard generates a **0xC1** (EBCDIC "A") or **0x81** (EBCDIC "a"), depending on whether the Shift key is active or not.

In order for a user to type a character that is not represented on the keyboard, a user-driven keyboard map is available.

Modifying the Keyboard Map

Upon loading, the TE checks for a file called **KEYS.TXT**. If this file does not exist, the TE uses the default keyboard map or mapping, as described in prior sections. Otherwise, it interprets the file contents and replaces given key combinations with a displayable character from the LXE Character Set shown in the previous table titled “LXE Character Set.”.

The **KEYS.TXT** file has the following format:

KEYCODE, Hexadecimal position in LXE Character Set.

where KEYCODE is

NA - NZ, N0 - N9	representing the “normal” keys A through Z, and digits 0 through 9
SA - SZ, S0 - S9	representing the “shifted” keys A through Z and digits 0 through 9
CA - CZ, C0 - C9	representing the “Ctrl” keys A through Z and digits 0 through 9
AA - AZ, A0 - A9	representing the “Alt” keys A through Z and digits 0 through 9

For example, the following entries:

NO, 0xd6	means display Ö when the user presses the key O
CV, 0xa9	means display © when the user presses Ctrl-V
AZ, 0xbc	means display ¼ when the user presses Alt-Z

Sample Keys.Txt File

```
CF4 0xe1
CF5 0xe2
CF6 0xe3
CF7 0xe4
CF8 0xe5
```

Messages

Default Messages

The file **MESSAGE.TXT** contains a list of messages used by the TE during normal operations. Each line contains a unique identifier, followed by a comma, and the message text. Shown below are several lines from the default file:

```
ERRGEN, Error
ERROOR, Communications|Error
ERRNONE, Communications|Link|is OK
ERRNET, Network|Error
ERRLIMIT, Connection|Limit|Reached
ERRUNK, Unknown|Error
ERRRFINST, RF Error
ERRRFINIT, RF|Initialization|Error
ERRDISC, Disconnect|Error
```

The message text may contain one or more vertical bars, which indicate multiline text. For example, if the ERRGEN message is used by the TE, it will be displayed in a popup window with a single line, “Error”. The ERROOR message will be displayed in two lines, “Communications” on the first line, and “Error” on the next.

Editing The Message.Txt File

The message file can be edited using the DOS editor on a standard PC. The LXE Character Set should be loaded using the provided utility in order to view the results of the message displayed in that character set.

In order to display a character from the extended character set (characters 128 - 255), use the standard DOS facility by pressing and holding the **Alt** key and typing in the decimal position of the character *using the numeric keypad*.

For example, the word Réseau would be typed in as:

R	Do not press Enter
Alt-233	Hold down the Alt key and type 233 using the numeric keypad
s	Do not press Enter
e	Do not press Enter
a	Do not press Enter
u	Press Enter

Each letter is on a separate line for clarity only. The number 233 is the decimal equivalent of **0xe9**, which is the location of the letter é in the LXE Character Set.

Sample Message.Txt File

```
ERRGEN, Error
ERRNONE, Communications|Link|is OK
ERRNET, Network|Error
ERRLIMIT, Connection|Limit|Reached
ERRUNK, Unknown|Error
ERRRFINST, RF Error
ERRRFINIT, RF|Initialization|Error
ERROOR, Communications|Error
ERRDISC, Disconnect|Error
STAT1, Not connected
STAT2, Connect error
STAT3, Connect pending
STAT4, Connected
STAT5, Blocked
STAT6, Out of range
STAT7, Flow controlled
STAT8, Disconnected
STAT9, Transport Error
MSGCONNECT, Connecting|Please wait
MSGCOM1R, COM1 Read
MSGCOM1W, COM1 Write
MSGCOM2R, COM2 Read
MSGCOM2W, COM2 Write
MSGCOM1, Loading RS232
MSGLOGON, Logfile on
MSGLOGOFF, Logfile off
MSGSWAP1, Swapping to|Primary NC
MSGSWAP2, Swapping to|Secondary NC
MSGSWAP3, Current NC is|Primary NC|Swap to|Secondary NC?
MSGSWAP4, Current NC is|Secondary NC|Swap to|Primary NC?
MSGREBOOT, Rebooting...
MSGSTART, Testing|Communications|Link
MSGMACC, Macro cleared
MSGMACE, Edit
MSGTIMEOUT, Timeout...
MSGPRINT1, Disable|Printing?
MSGPRINT2, Enable|Printing?
MSGPRINT3, Printing| Disabled
MSGPRINT4, Printing| Enabled
MSGPRINTE, Printer|Not|Ready
```

Editing ASCII Files

There are several ways to edit “text” files that are contained in the directories. The files could be:

- edited while resident in the computer.
- edited on an IBM compatible PC/Laptop (with a PCMCIA card drive) and transferred to the computer using a PCMCIA card.
- edited on an IBM compatible PC/Laptop and transferred to the computer using a file transfer utility (REMDISK / REMSERV).

The following processes use the KEYS.TXT file.

Editing Files at the Computer



Refer to the DOS User’s Manuals delivered with your DOS computer for complete instructions when using DOS commands and utilities.

1. Power on the computer. Exit from any running programs. The DOS prompt should appear on the screen.

C:>

Note: Enter the appropriate DOS commands to locate the filename of the ASCII editor you want to use. The ROM-DOS NED file (NED.EXE and NED.CFG) are usually in the DOS directory.

2. Enter the appropriate commands to locate the file you want to edit.

For example, at the DOS prompt, type:

CD\IBM Press Enter

Result: This will change the pointer to the IBM directory.

Then type the following at the DOS prompt to make sure the file you want to edit is in the IBM directory:

C:\IBM > DIR KEYS.TXT Press Enter

If the file exists in the IBM subdirectory, the KEYS.TXT file information will be displayed. If not, the computer will display File Not Found.

Type the following at the DOS prompt:

COPY KEYS.TXT KEYS.OLD

This will create a backup of the KEYS.TXT file.

3. After a copy of the original KEYS file has been made, type the following at the DOS prompt:

NED KEYS.TXT

This will allow you to edit the KEYS.TXT file.

Note: If NED.EXE is not installed or you prefer not to use it, you may use any text editor to edit the KEYS.TXT file.

4. Save the changes to your KEYS.TXT file and exit the text editor.
5. Restart the computer by pressing Ctrl+Alt+Del.

Edit then Transfer Files Using a PC Card

PCMCIA cards are used in computers and computerized equipment and are commonly called PC Cards. PC Cards can be used to store Flash Memory, SRAM Memory, function as Network/LAN drivers, FAX/Modem drivers, be used as ATA disks, hard disks, SCSI disk drives, and other I/O functions. After files have been transferred to the PC card, the card is inserted in the computer or equipment and the files on the card are accessed in the same manner as any file on the computer system.

Requirements:

- Diskette(s) containing files to be transferred to the computer.
- One (1) SRAM card (PC card).

Note: If the PC Card is unformatted, format the card using the DOS FORMAT command before copying files to the card. Refer to the DOS manual for more information on the FORMAT command.

An IBM compatible PC/Laptop with:

- DOS version 3 or later.
 - one floppy drive (minimum).
 - one (1) PCMCIA Type II slot (minimum).
 - PCMCIA Card management software (i.e. Phoenix Card Management).
1. Insert the Diskette (containing files to be edited and/or transferred) into the floppy disk drive of the PC/Laptop. (Typically this is drive A:)
 2. Insert the SRAM card into the PCMCIA slot of the PC/Laptop. (Typically this is drive D:)
 3. At the DOS prompt, type the following...

A:

Where A: is the drive containing the diskette.

4. Press Enter
5. Locate the file(s) to be edited or copied to the computer. (Use the DOS DIR and CD commands to locate files.)

Refer to the MS-DOS manual for more information on the DIR and CD commands.

6. Type the following at the DOS prompt:

`COPY KEYS.TXT KEYS.OLD`

This will create a backup of the KEYS.TXT file.

7. After a copy of the original KEYS file has been made, type the following at the DOS prompt:

`EDIT KEYS.TXT`

This will allow you to edit the KEYS.TXT file.

Note: If EDIT is not installed or you prefer not to use it, you may use any text editor, such as NED.EXE to edit the KEYS.TXT file.

8. Save the changes to your KEYS.TXT file and exit the text editor.
9. Once the file(s) have been edited on the SRAM card, remove the SRAM card from the PC/Laptop.
10. Following the instructions in the specific computer's Reference Guide insert the SRAM card into the appropriate slot in the computer.
11. Copy the edited file to the appropriate drive and subdirectory in the computer.

Transfer Files Using DOS REMDISK/REMSERV

Requirements:

- An IBM compatible PC/Laptop with:
 - DOS version 3 or later
 - one serial port (minimum)
 - one floppy drive (minimum).
- An LXE computer with a serial port.
- One 3-wire null modem serial cable for a serial connection.



Refer to the DOS Computer's Reference Guide for more details on using REMDISK and REMSERV. The parameters for each utility are detailed in the Reference Guides.

Note: Edit the file on the PC/Laptop before transferring it to the computer with REMDISK/REMSERV.

1. Using the null modem cable, connect the PC/Laptop to the LXE computer's serial port.
2. On the PC/Laptop, make sure the REMDISK.EXE is running with the same baud rate and packet/nonpacket-style transmission that REMSERV.EXE is using on the LXE DOS computer.
3. The LXE computer's drive specified in the REMSERV command becomes the next assigned drive letter for the PC/Laptop. For example, if D: was the last drive assigned on the PC/Laptop, the REMDISK creates drive E.
4. Insert the Diskette (containing files to be transferred) into the floppy disk drive of the PC/Laptop. (Typically this is drive A:.)
5. At the DOS prompt on the PC/Laptop, type...

A:

where A: is the drive containing the diskette.

3. Press Enter.
4. Locate the file(s) to be copied to the computer. (Use the DOS DIR and CD commands to locate files.)

Note: Refer to the DOS manual for more information on the DIR and CD commands.

5. Copy the specified files from the diskette to the computer. (Use the DOS COPY or XCOPY commands to copy the specified files from the SRAM card.)

Note: Refer to the MS-DOS manual for more information on the COPY and XCOPY commands.

`COPY A:\KEYS.TXT E:\KEYS.TXT`

This command copies a single file (KEYS.TXT) from the diskette to the LXE computer (where A: is the floppy drive containing the diskette and E: is the LXE computer's hard drive).



Table of Contents

CHAPTER 5 3270 PROGRAMMER'S REFERENCE	5-1
Introduction	5-1
Primary Audience	5-1
Examples.....	5-1
About RF Performance	5-1
Screen Design.....	5-1
Collisions.....	5-1
Data Stream	5-2
RF Header	5-2
RF Trailer	5-2
IBM Attributes, Orders, and Commands	5-3
Attributes	5-3
Field Attributes.....	5-3
Extended Field Attributes.....	5-3
Extended Highlighting.....	5-3
Field Validation	5-3
Character Attributes	5-4
Auto Transmit / Trigger	5-4
Orders	5-5
Commands	5-6
IBM 3270 Commands	5-6
WSF (Write Structured Field)	5-7
Outbound Structured Fields	5-7
Inbound Structured Fields.....	5-8
SDLC Commands.....	5-9
Host Commands (Primary)	5-9
Access Point Responses (Secondary)	5-9
SNA Commands	5-10
Extra Features	5-11
Requirements for Extra Feature Commands.....	5-11
First Field Only	5-12
Multiple Fields	5-12
Screen Design for Computer Setup Commands	5-13
Match Fields	5-14
Constructing Predecessor Fields	5-14
Constructing Match Fields	5-14
Data Fails Match Test	5-14
Wildcard Match Characters.....	5-15
Match Field Commands	5-16

Commands.....	5-16
Computer Setup	5-17
Command String for Computer Setup	5-17
Semicolon.....	5-17
String Elements	5-18
Left Justify Mode: p2.....	5-20
Clear Mode: p3	5-21
Truncate Mode: p4.....	5-22
Advance Mode: p5.....	5-22
Auto Transmit After Data Stream Print: p6.....	5-23
Printer Carriage Return per Line: p7	5-23
Printer Line Feed per Line: p8.....	5-24
Status Line Display Mode: p9	5-24
Command String for Wildcard Match Characters	5-25
Command String.....	5-25
String Elements	5-25
Command String for Window Setup	5-27
Command String.....	5-27
String Elements	5-27
Display Modes: p2	5-29
Valid Window Positions: p3 and p4	5-30
The 12/25 Row x 80 Column Screen	5-31
The 10 Row x 20 Column Screen	5-31
Window Movement: p5	5-32
Parameter Values.....	5-32
Quadrant for Cursor: p6.....	5-33
Beep Pattern Command	5-33
Rules.....	5-33
Command String.....	5-34
Elements	5-34
Determine the Beep Pattern Number	5-35
Printing a Field	5-36
Rules.....	5-36
Auto Transmit	5-37
CR/LF	5-37
Screen Print Command	5-37
Display Window and Virtual Screen	5-38
Status Line	5-39
Behavior	5-39
Removing the Status Line	5-39
Modes of Operation.....	5-39
Message Line	5-40
Display Window.....	5-40
Overwriting the Display	5-40
Removing the Message Line	5-40

Window Movement Keys.....	5-40
---------------------------	------

Illustrations

Figure 5-1 IBM 3270 Data Stream with RF Header and Trailer	5-2
Figure 5-2 3270 Screen Trigger (Auto Transmit) Feature.....	5-4
Figure 5-3 3270 Screen with Computer Setup Command	5-13
Figure 5-4 Constructing a Predecessor Field	5-14
Figure 5-5 Match Field Example	5-14
Figure 5-6 3270 Screen with Predecessor and Match Fields	5-16
Figure 5-7 Left Justify Off.....	5-20
Figure 5-8 Left Justify On.....	5-20
Figure 5-9 Valid Window Positions - 12 and 25 Row x 80 Column	5-31
Figure 5-10 Valid Window Positions - 10 Row x 20 Column.....	5-31
Figure 5-11 Valid Window Positions - 20 Row x 20 Column.....	5-31
Figure 5-12 Beep Pattern Command String.....	5-34
Figure 5-13 Beep Pattern Template	5-35
Figure 5-14 Beep Pattern Example	5-35
Figure 5-15 Print Command Example	5-36
Figure 5-16 Virtual Screen and Display Window Relationship.....	5-38



Chapter 5 **3270 Programmer's Reference**

Introduction

This chapter provides information to help the application programmer program the host application to communicate with LXE devices.

This chapter does not rewrite the IBM programming books. Instead, it lists all the IBM commands, orders, and attributes that LXE supports. It also lists all the commands that LXE supports that are in addition to the IBM 3270 environment.

Primary Audience

The primary audience for this chapter is the application programmer who is experienced with IBM 3270 programming standards and responsible for writing applications that communicate with LXE devices in a 3270 environment.

Examples

The examples provided are for illustration purposes and should only be used as guidelines. Do not use these examples for your operation because every operation is different. Additionally, the examples in this guide are only fragments of code and are not intended for implementation.

About RF Performance

There are several factors that can adversely affect performance in an RF environment. You can optimize RF performance by avoiding these factors or minimizing their occurrence.

Screen Design

The screen design directly affects RF performance. Here are some rules you need to follow for creating and sending screens:

- Do not transmit a large number of space characters and null characters on the screen.
- Do not clutter the screens with unnecessary information.
- Perform a partial screen update (Write command) whenever possible because it takes less time than updating the entire screen (Erase/Write command).

Collisions

In an RF environment, computers compete to communicate with the Access Point. If the access point is busy, the computer must wait and transmit its message again.

A collision occurs when two or more transmissions occur at the same time. The access point receiving the messages from the computers either accepts the message with the stronger signal or the access point dumps both messages. The computers must retransmit the messages that are dumped or not received.

Data Stream

An RF header is added to the beginning and an RF trailer is added to the end of the IBM data stream. The contents of the IBM data stream do not change, but the data stream gains a header and trailer.

Refer to the following diagram that illustrates the addition of an RF header and trailer to the IBM data stream:




Figure 5-1 IBM 3270 Data Stream with RF Header and Trailer

RF Header

The RF header identifies

- the connection parameters between the Access Point and RF computers.
- the direction of a message (whether the message is inbound or outbound).
- the sequence number of transmissions for error detection. The sequence numbers indicate the order in which each message was sent. The device receiving the messages can detect whether a message was lost from the sending device based on the sequence number in the RF header.

RF Trailer

The RF trailer consists of a cyclic redundancy check (CRC). CRC is an error detection process where the sending device calculates the value of the characters in the message and puts this value at the end of the message.

When the receiving device gets the message, this device recalculates the CRC and compares it to the value originally transmitted. If the values do not match, the message must be sent again.

IBM Attributes, Orders, and Commands

LXE supports some of the features defined by the IBM 3270 environment. This chapter discusses all of the IBM attributes, orders and commands LXE supports. This chapter also discusses the SDLC commands and SNA commands LXE supports.

In 3270 environments, field attributes define the start of a field and control the characteristics of that field. Character attributes control the characteristics of a single character. Orders are instructions that provide control information.

This section discusses all the IBM attributes and orders that LXE supports. If an IBM attribute or order is not listed, LXE does not support it, and it is treated as a no operation (NOP).

Attributes

Field attributes define the start of a field and the characteristics of all characters in the field. LXE supports three of the five IBM attributes: field attribute (FA), extended field attributes (EFA), and character attributes.

Field Attributes

Refer to the following list of field attributes that LXE supports:

- Protected/Unprotected
- Display/Nondisplay
- Alphanumeric/Numeric

Extended Field Attributes

LXE supports the following extended field attributes:

- Extended Highlighting
- Field Validation

The extended field attributes are used with the start field extended order. Refer to “Orders” for more information.

Extended Highlighting

Extended highlighting includes normal, blink, underline (only space characters), and reverse video. These are the only extended highlighting attributes that LXE supports.

Field Validation

LXE supports the following field validation attributes:

Mandatory entry	Requires the operator to enter data in a field before transmitting.
Mandatory fill	Requires a field to be completely filled with data. In other words, every character position in the field must be filled.
Trigger	LXE supports trigger differently than IBM. LXE trigger automatically transmits all the fields with the modified data tag set. This feature simulates the [Send] key.

Character Attributes

LXE supports extended highlighting on a character-by-character basis. Extended color and character set are not supported.

Auto Transmit / Trigger

You can automatically send data to the host on an IBM 3270 screen by using an IBM attribute called trigger. This method simulates a [Send] key that is sent to the host.

LXE supports the IBM Trigger feature differently than IBM does. An LXE trigger automatically transmits all the fields with the modified data tag (MDT) enabled. IBM transmits only the trigger field. Trigger is an extended field attribute that you set in the field attribute character. Exiting the modified trigger field causes all the modified fields to be transmitted to the host.

Refer to the following example of the trigger feature on a 3270 screen:




Figure 5-2 3270 Screen Trigger (Auto Transmit) Feature

LXE recommends that you use the trigger feature instead of any other feature for automatically sending data. The trigger feature is in the extended field attribute of the field attribute, and does not take any extra character spaces on the screen. Other features take more character spaces on the screen to send data automatically.

Orders

Refer to the following table of IBM orders that LXE supports. For a detailed discussion on the function of each order, refer to “3270 Information Display System Data Stream Programmer’s Reference,” GA23-0059-07.

Order	What it Does
Erase Unprotected to Address (EUA)	Stores nulls in all unprotected character locations starting at the current buffer address and ending at the specified stop address. The stop address is not included.
Insert Cursor (IC)	Repositions the cursor to the location specified by the current buffer address.
Modify Field (MF)	Updates field and extended field attributes at the current buffer address.
Program Tab (PT)	Advances the current buffer address to the address of the first character position of the next unprotected field.
Repeat to Address (RA)	Stores a specified character in all character buffer locations starting at the current buffer address and ending at the specified stop address. The stop address is not included.
Set Attribute (SA)	Specifies a character’s attribute type and value.
Start Field (SF)	Indicates the beginning of a field.
Start Field Extended (SFE)	Indicates the beginning of a field and indicates the field’s properties that are described in the extended field attribute.
Set Buffer Address (SBA)	Specifies a new character buffer address where the operations are to start or continue.

Commands

In the 3270 environments, IBM commands define the function that the display performs. For example, IBM commands control whether an application program writes to or reads from a display; or, whether the old screen is erased before new data appears.

This section lists and describes all the IBM 3270, SNA, and SDLC commands that LXE supports. If a command is not listed here, LXE does not support it and it is treated as a no operation (NOP).

IBM 3270 Commands

IBM 3270 commands define the function the display should perform. LXE supports the following IBM 3270 commands:

Command	What it Does
Erase All Unprotected (EAU)	Clears all unprotected character positions of the partition to nulls. Any character attributes affected are set to their default values.
Erase/Write (EW)	<ul style="list-style-type: none"> • Sets the implicit partition size to its default value, if applicable. • Resets program check indication, if applicable. • Erases the character buffer. • Sets all associated character attributes and extended field attributes to their default values. • Erases all field validation attributes. • Sets the cursor position to (0,0). • Provides an acknowledgment of any outstanding read or enter, if applicable. • Provides a negative trigger reply. • Performs a write operation.
Read Buffer (RB)	Transmit all data to the addressed display buffer to the host.
Read Modified (RM)	Initiates either a read modified operation or a short read operation.
Read Modified All (RMA)	Causes both the addresses and the data from all modified fields to be sent to the host independent of the attention identifier (AID) code.
Write (W)	Writes data into specified locations of the character buffer without erasing or modifying data in any other locations.
Write Structured Field (WSF)	LXE does not support all the commands associated with WSF. Refer to WSF in this guide for more information.

WSF (Write Structured Field)

Write structured fields enable the host to query a device about its capabilities or to request the computer to return its data. There are three kinds of write structured fields:

- Outbound structured fields
- Inbound structured fields
- Outbound/inbound structured fields

LXE supports some of the commands associated with outbound structured fields and inbound structured fields.

LXE does not support outbound/inbound structured fields.

Outbound Structured Fields

The following table describes the fields related to outbound structured fields that LXE supports:

Field	What it Does
Outbound 3270DS	Directs 3270 data stream orders and data to a computer.
Read Partition	Supports query and query list. Query requests a summary of the query replies supported by the computer. Query list requests information from the computer about the features a computer supports.
Set Reply Mode	Defines the format of any subsequent inbound data streams from an alphanumeric partition.

Inbound Structured Fields

The following table describes the query reply fields related to inbound structured fields that LXE supports:

Field	What it Does	
	Type	Description
Field Validation	Supports three types of field validation:	
	Mandatory Entry	Requires the operator to enter data in a field before transmitting.
	Mandatory Fill	Requires a field to be completely filled with data. Each character position in the field must be filled.
	Trigger	LXE supports trigger differently than IBM. LXE trigger automatically transmits all the fields with the trigger built into the extended field attribute to the host.
Highlighting	Supports the following highlighted attributes:	
	<ul style="list-style-type: none"> • normal • blink • reverse video • underline (underlines a space - does not underline a character.) 	
Implicit Partition	Transmits the size of the virtual screen, which is always 25 lines by 80 columns for an LXE computer.	
Null	Informs the host that the device does not support any of the features that the host inquired about with the read partition query list command.	
Reply Modes	Specifies all of the query replies that are supported. The LXE computer supports field validation, highlighting, implicit partition, and reply modes.	
Summary	Transmits the reply modes supported by the computer. The LXE computer supports all three modes: field mode, extended field mode, and character mode.	

SDLC Commands

In a 3270 environment, the host always initiates the communication between the host and the access point. Since the host initiates the communication, the host is the primary device and the access point is the secondary device.

Host Commands (Primary)

The following is a list of the synchronous data link control (SDLC) commands that LXE supports:

DISC	Disconnect
I	Information
RNR	Receive Not Ready
RR	Receive Ready
SNRM	Set Normal Response Mode
TEST	Test
XID	Transmit Identification

Access Point Responses (Secondary)

LXE supports eight Access Point responses to the SDLC commands:

DM	Disconnect Mode
FRMR	Frame Reject
I	Information
RNR	Receive Not Ready
RR	Receive Ready
TEST	Test
UA	Unnumbered Acknowledgment
XID	Transmit Identification

SNA Commands

The following is a list of systems network architecture (SNA) commands that LXE supports:

Bind	
Cancel	
Signal	
Unbind	
ACTLU	Activate Logical Unit
ACTPU	Activate Physical Unit
DACTLU	Deactivate Logical Unit
DACTPU	Deactivate Physical Unit
LUSTAT	Logical Unit Statistics
NMVT	Network Management Vector Transport
REQTEST	Request Test
REQMS	Request Maintenance Statistics
REQFMS	Request Formatted Maintenance Statistics
RSHUTD	Request Shut Down

Extra Features

LXE offers many features that are beyond the capabilities of the standard IBM 3270 computer. These features allow for remote computer configuration, at-the-computer data editing, custom beeper control, and attached printer control.

This section describes these features and contains information on how to program your host application to take advantage of these features.

This section discusses how the extra feature commands are sent on a 3270 screen to the RF computer. The screen design of the commands that you must send to the computer is discussed in detail. Some of the commands mentioned in this section are discussed in greater detail in the following sections.

LXE offers a group of private commands for computer setup, operator input, and RS-232 port for printing. The following briefly describes the commands. A detailed discussion of each command appears in the following sections.

LXE supports the following commands that deal with computer setup:

- *E Terminal Emulation (TE) Setup
- *L Wildcard Match Characters Setup
- *W Window Manager Setup

LXE supports the following commands that go beyond computer setup commands:

- *B Beep Pattern
- *P Printing a Field

Requirements for Extra Feature Commands

Some of the extra feature commands are used only once on a screen and these commands must be in the first position of the screen. Other commands are used several times and appear anywhere on the screen.

First Field Only

The following commands must be in the first field of a 3270 screen sent to an LXE computer:

- *B Beep Pattern
- *E Terminal Emulation (TE) Setup
- *L Wildcard Match Characters Setup
- *P Data Stream Print
- *W Window Manager Setup

You can use only one of these commands with each screen. You cannot stack these commands.

Multiple Fields

The following commands can be in any field on a 3270 screen sent to an LXE computer:

- *C Nondisplayable local edit match field
- *D Displayable local edit match field

You can use as many of these commands on a 3270 screen sent to an LXE computer as you want. You can stack these commands and mix them.

Screen Design for Computer Setup Commands

All computer setup commands must be in the first field of the 3270 screen. The field attribute must occupy position 1,1. This field attribute can be protected (input prohibited) or unprotected (input capable). Do not use space characters in this field.

Computer setup commands include terminal emulation setup, wildcard match characters, and window manager setup.

Refer to the following diagram of a 3270 screen containing a computer setup command:

1	16	80
1	FA * E 1 ; 1 ; 1 ; 1 ; 0 ; ; 1 ...	
25		

Figure 5-3 3270 Screen with Computer Setup Command

Note: The first field attribute on a 3270 screen must begin at row 1, column 1 to use the computer setup commands.

See Also

Refer to “Computer Setup” in the following section for more information on the format of a computer setup command.

Match Fields

Match fields enables you to control data entry at the computer. The computer locally edits information in the match field as the computer operator enters data instead of the host performing the edit. Prior to constructing the match fields, you must construct a predecessor field that consists of an asterisk and a command letter. The match fields consist of exact match characters and wildcard match characters. The match field can be as long as you want.

Constructing Predecessor Fields

You must construct a predecessor field that is exactly two characters long before you construct the match field. The predecessor field must be preceded by a field attribute (FA) that protects (no input allowed) the predecessor field. The predecessor field contains an asterisk (*) and a command letter indicating the field type. No space characters are allowed. Refer to the diagram below:



Figure 5-4 Constructing a Predecessor Field

A list of command letters used in the predecessor field is discussed in “Match Field Commands” later in this section.

Constructing Match Fields

The match field must immediately follow the command letter of the predecessor field. You cannot have a space between the predecessor field and match field. You must enter exact match characters and wildcard match characters in the match field. These characters determine what the computer operator can enter into the field. Do not include space characters. Refer to an example of a match field below:




Figure 5-5 Match Field Example

A list of wildcard match characters is discussed on the following page. The field attribute (FA) of the match field determines whether the computer operator sees the entered match characters.

Data Fails Match Test

The computer edits the field locally as data is entered and not when the field is exited. If the data fails the match test during the editing of each position, the cursor does not move. The computer locks the keyboard, sounds the alarm, displays an error message, and discards the character.

Wildcard Match Characters

A wildcard match character represents a predefined range of acceptable values that the computer operator can enter in a match field for the computer to compare against. When constructing the match field, choose the character that represents the range of data entry that you want. Refer to the following list of default settings for the wildcard match characters:

- ? Alpha only match (A–Z, a–z, comma, period, dash, space)
- \$ Digits only match (0–9)
- # Numeric only match (0–9, plus, comma, period, dash, space)
- + Alphanumeric (A–Z, a–z, 0–9, plus, comma, dash, space)
- * Match all ((A–Z, a–z, 0–9, plus, comma, period, dash, space)

You can change these default settings for the wildcard characters by using the command string for local edit wildcard in the following section. You can use as many wildcard match characters as you need in a match field.

Match Field Commands

There are several types of match field commands that indicate the match field type. The commands and their field types are discussed in detail.

Commands

The following commands determine what type of match field you have. These commands appear in the predecessor field.

Command	Field Type
*C	Nondisplayable. Indicates to the computer to not display the data entry made by the computer operator.
*D	Displayable. Indicates to the computer to display the data entry made by the computer operator.

Refer to the following diagram of a predecessor field and match field on a 3270 screen:




Figure 5-6 3270 Screen with Predecessor and Match Fields

Computer Setup

There are two ways to configure the 3270 computer:

- Configuration Utility in the RF computer.
- Remote host configuration with command strings.

This section discusses the elements of the command strings that enable you to configure the computer from the host.

Command String for Computer Setup

Use the following command string for computer setup:

`*Ec1;p1;p2;p3;p4;p5;p6;p7;p8;p9`

This command must be sent to the computer in the first field on the screen. Refer to “Screen Design for Computer Setup.”

Semicolon

Each parameter must be preceded by a semicolon (;). You can use the semicolon as a place holder if you want to change only one parameter, except for the first parameter, p1. You must always include a value for p1. For example, you can send the following string to change only p5 of the command string:

`*E1;0;;;;1`

Since you are not changing parameters 6–9, you can end the command string without adding placeholders for the parameters following p5.

String Elements

The following table describes the different elements of the command string for the terminal emulation setup:

Element	Description				
*E	Indicates that this command string is a terminal emulation setup command.				
c1	A compatibility byte that ensures the terminal emulation understands the command string sent to it. The c1 is a revision level character for compatibility purposes, which increments when a change in the string content would make newer RF computers incompatible with older host applications.				
;	A required delimiter that must precede all parameter entries.				
p1	Save to disk (save the command string to EEPROM). <table style="margin-left: 20px;"> <tr> <td style="width: 40px; text-align: center;">0</td><td>Use the command string in the computer but do not save. The configuration is used only as long as the computer is powered on.</td></tr> <tr> <td style="width: 40px; text-align: center;">1</td><td>Use the command string in the computer and save. The configuration is saved even after the computer is powered off.</td></tr> </table>	0	Use the command string in the computer but do not save. The configuration is used only as long as the computer is powered on.	1	Use the command string in the computer and save. The configuration is saved even after the computer is powered off.
0	Use the command string in the computer but do not save. The configuration is used only as long as the computer is powered on.				
1	Use the command string in the computer and save. The configuration is saved even after the computer is powered off.				
p2	Bar Code/RS-232 Input Left Justify Mode <table style="margin-left: 20px;"> <tr> <td style="width: 40px; text-align: center;">0</td><td>Left Justify Mode Off</td></tr> <tr> <td style="width: 40px; text-align: center;">1</td><td>Left Justify Mode On</td></tr> </table> “Left Justify Mode: p2” in this section discusses this parameter in more detail.	0	Left Justify Mode Off	1	Left Justify Mode On
0	Left Justify Mode Off				
1	Left Justify Mode On				
p3	Bar Code/RS-232 Input Clear Mode <table style="margin-left: 20px;"> <tr> <td style="width: 40px; text-align: center;">0</td><td>Clear Off</td></tr> <tr> <td style="width: 40px; text-align: center;">1</td><td>Clear On</td></tr> </table> “Clear Mode: p3” in this section discusses this parameter in more detail.	0	Clear Off	1	Clear On
0	Clear Off				
1	Clear On				
p4	Bar Code/RS-232 Input Truncate Mode <table style="margin-left: 20px;"> <tr> <td style="width: 40px; text-align: center;">0</td><td>Truncate OFF</td></tr> <tr> <td style="width: 40px; text-align: center;">1</td><td>Truncate ON</td></tr> </table> “Truncate Mode: p4” in this section discusses this parameter in more detail.	0	Truncate OFF	1	Truncate ON
0	Truncate OFF				
1	Truncate ON				

Element	Description
p5	Bar Code/RS-232 Input Advance Mode 0 Advance OFF 1 Advance ON “Advance Mode: p5” in this section discusses this parameter in more detail.
p6	Auto transmit after a data stream print 0 Do not auto transmit after a data stream print. 1 Auto transmit after a data stream print. “Auto Transmit: p6” in this section discusses this parameter in more detail.
p7	Printer Carriage Return per Line 0 No carriage return per line on a screen print 1 Carriage return per line on a screen print “Printer Carriage Return per Line: p7” in this section discusses this parameter in more detail.
p8	Printer Line Feed per Line 0 No line feed per line on a screen print 1 Line feed per line on a screen print “Printer Line Feed per Line: p8” in this section discusses this parameter in more detail.
p9	Status Line Display Mode 0 Status line always off 1 Status line only on when there is an exception “Status Line Display Mode: p9” in this section discusses this parameter in more detail.

Left Justify Mode: p2

Left justify mode determines where the cursor appears in a field from one barcode entry or RS-232 entry to the next. You must decide if the cursor in a field justifies to the left each time a new barcode or RS-232 entry occurs or if the entry begins at the cursor's position.

Parameter Values

Refer to the following table on how to set p2 of the command string to disable or enable left justify mode:

When you enter...	Then left justify mode is...
0	off.
1 (default)	on.

Left Justify Off

Left Justify Off enables a barcode or RS-232 read to appear in the next available cursor position of a field directly following a previous entry. For example, the first entry fills the first five positions of the first field available as shown below:



Figure 5-7 Left Justify Off

The next barcode or RS-232 read is entered starting at the cursor position and proceeding to the next unprotected field.

Left Justify On

Left Justify On enables the cursor to left justify in a field each time a barcode or RS-232 read occurs. For example, the following barcode or RS-232 read appears in the field and then the cursor left justifies when the next barcode or RS-232 entry occurs. The next barcode or RS-232 read appears in the field starting at the B position:



Figure 5-8 Left Justify On

Clear Mode: p3

Clear mode determines if a field is automatically cleared before the barcode or RS-232 data is entered into the field or if the data in the field is overwritten by the new entry.

Parameter Values

Refer to the following table on how to set p3 of the command string to disable or enable clear mode:

When you enter...	Then clear mode is...
0	off.
1 (default)	on.

Clear Mode Off

When clear mode is off, the computer does not clear the data in a field. The new data entered into the field overwrites portions of the leftover data. An operation that has barcode or RS-232 entries with equal character lengths might choose clear mode OFF.

Clear Mode On

When clear mode is on, the computer clears the data in a field before the barcode or RS-232 entry begins. An operation that has barcode or RS-232 entries with varying lengths would need to use clear mode ON to ensure positions in the field that were not overwritten by the new data are filled with nulls.

Truncate Mode: p4

Truncate mode determines whether the character positions of a barcode or RS-232 entry exceeding the field length are dropped off or if the leftover characters are entered in the next available field.

Parameter Values

Refer to the following table on how to set p4 of the command string to disable or enable truncate mode:

When you enter...	Then truncate mode is...
0	off.
1 (default)	on.

Truncate Mode Off

When truncate mode is off, the character positions of a barcode or RS-232 entry exceeding the field length are entered in the next available field.

Truncate Mode On

When truncate mode is on, the character positions of an entry exceeding the field length are dropped off. If the field has 10 available character positions and the barcode or RS-232 entry has 22, the first 10 character positions of the entry are entered in the field and the remaining 12 character positions are dropped.

Advance Mode: p5

When advance mode is off, the cursor does not advance to the next field at the end of a barcode or RS-232 entry. The next entry is entered directly following the previous barcode entry.

When advance mode is on, the cursor advances to the next field at the end of each entry regardless of whether the field is completely filled or not.

Parameter Values

Refer to the following table on how to set p5 of the command string to disable or enable advance mode:

When you enter...	Then advance mode is...
0	off.
1 (default)	on.

Auto Transmit After Data Stream Print: p6

Auto transmit after data stream print enables you to transmit a [SEND] key automatically to the host after the field prints out the RS-232 port.

When data stream print auto transmit is off, the [SEND] key does not go to the host when the data stream prints out the RS-232 port. When data stream print auto transmit is on, the computer automatically transmits a [SEND] key to the host when the data stream prints out the RS-232 port.

Parameter Values

Refer to the following table on how to set p6 of the command string to disable or enable data stream print auto transmit mode:

When you enter...	Then auto transmit is...
0 (default)	off.
1	on.

Printer Carriage Return per Line: p7

When carriage return per line is on, a carriage return is included at the end of each line (80 characters) in a screen print and a data print command. The host application cannot generate a screen print, but the host application can generate a data print command that prints a field. Refer to “Printing a Field” for more information.

Parameter Values

Refer to the following table on how to set p7 of the command string to disable or enable printer carriage return mode:

When you enter...	Then carriage return is...
0 (default)	off.
1	on.

Printer Line Feed per Line: p8

When printer line feed per line is on, a line feed is included at the end of each line (80 characters) in a screen print and a data print command. The host application cannot generate a screen print, but it can generate a data print command that prints a field. Refer to “Printing a Field” for more information.

Parameter Values

Refer to the following table on how to set p8 of the command string to disable or enable printer line feed mode:

When you enter...	Then line feed is...
0 (default)	off.
1	on.

Status Line Display Mode: p9

Status line display mode determines if the status line is always off or if the status line appears on exception only. An exception condition exists when an X (keyboard lock), T (time), or an error message occurs. Refer to “Status Line” for more information.

Parameter Values

Refer to the following table on how to set p9 of the command string to disable or enable status line display mode:

When you enter...	Then display mode is...
0	off.
1 (default)	on.

Command String for Wildcard Match Characters

A wildcard match field command string enables you to change the default match parameters. Wildcard match values represent a range of acceptable operator input.

Command String

Use the following command string for wildcard match fields:

`*Lc1;p1;p2;p3;p4;p5;p6`

This command must be sent to the computer in the first field on the screen. The field attribute must occupy position 1,1. Refer to “Screen Design for Computer Setup Commands” for more information.

String Elements

The following table describes the different elements of the command string for specifying a wildcard match character:

Element	Description
<code>*L</code>	Indicates that this command string is a wildcard match field command.
<code>c1</code>	A compatibility byte that ensures the computer emulation understands the command string sent to it. The <code>c1</code> is a revision level character for compatibility purposes, which increments when a change in the string content would make newer RF computers incompatible with older host applications.
<code>;</code>	A required delimiter that must precede all parameter entries.
<code>p1</code>	Save to disk (save the command string to EEPROM).
	0 Use the command in the computer but do not save. The configuration in the computer is used only as long as the computer is powered on.
	1 Use the command string in the computer and save. The configuration is saved even after the computer is powered off.
<code>p2</code>	Alpha only match includes the following characters: A–Z, a–z, comma, period, dash, space. ? (Default value for Alpha Only Match)
<code>p3</code>	Digits only match includes the following characters: 0–9. \$ (Default value for Digits Only Match)
<code>p4</code>	Numeric only match includes the following characters: 0–9, plus, comma, period, dash, space. # (Default value for Numeric Only Match)

Element	Description
p5	Alphanumeric only match includes the following characters: A–Z, a–z, 0–9, plus, comma, dash, space. + (Default value for Alphanumeric Only Match)
p6	Match all includes the following characters: A–Z, a–z, 0–9, plus, comma, period, dash, space. * (Default value for Match All)

Command String for Window Setup

Window setup determines how the display window shows portions of the virtual screen. You can set the parameters for window setup by using the correct command string.

Command String

Use the following command string for window setup:

`*Wc1;p1;p2;p3;p4;p5;p6`

This command must be sent to the computer in the screen definition in the first field on the screen. Whenever the computer receives this command it will perform an auto transmit.

Refer to “Screen Design for Computer Setup Commands” in this section for more information.

String Elements

The following table describes the different elements of the command string for window setup:

Element	Description
<code>*W</code>	Indicates that this command string is a window setup command string.
<code>c1</code>	A compatibility byte that ensures the host emulation understands the command string sent to it. The <code>c1</code> is a revision level character for compatibility purposes, which increments when a change in the string content would make newer RF computers incompatible with older host applications.
<code>;</code>	A required delimiter that must precede all parameter entries.
<code>p1</code>	Save to Disk (save the command string to EEPROM) 0 Use command string in the computer but do not save. The configuration in the computer is used only as long as the computer is powered on. 1 Use the command string in the computer and save. The configuration is saved even after the computer is powered off.
<code>p2</code>	Lock Window Mode. 0 Lock window mode off. (Cursor Tracking Mode) 1 Lock window mode on. “Display Modes: p2” in this section discusses lock window mode and cursor tracking mode in more detail.
<code>p3</code>	Lock Window Line Number. This two-digit number between 01 and 24 identifies the line of the top left corner position of the display window. “Valid Window Positions: p3 and p4” in this section lists the valid window positions.

Element	Description								
p4	<p>Lock Window Column Number. This two-digit number between 01 and 80 identifies the column of the top left corner position of the display window.</p> <p>“Valid Window Positions: p3 and p4” in this section lists the valid window positions.</p>								
p5	<p>Window Movement Mode.</p> <table style="margin-left: 40px;"> <tr> <td style="text-align: center;">0</td> <td>Move by Quadrant</td> </tr> <tr> <td style="text-align: center;">1</td> <td>Move by Full Window</td> </tr> </table> <p>“Window Movement: p5” in this section describes Quadrant and full window movement.</p>	0	Move by Quadrant	1	Move by Full Window				
0	Move by Quadrant								
1	Move by Full Window								
p6	<p>Quadrant for Cursor. The quadrant the cursor is in when the host sends a screen to the computer.</p> <table style="margin-left: 40px;"> <tr> <td style="text-align: center;">1</td> <td>Top right quadrant</td> </tr> <tr> <td style="text-align: center;">2</td> <td>Top left quadrant</td> </tr> <tr> <td style="text-align: center;">3</td> <td>Bottom left quadrant</td> </tr> <tr> <td style="text-align: center;">4</td> <td>Bottom right quadrant</td> </tr> </table> <p>“Quadrant for Cursor: p6” in this chapter discusses this parameter in more detail.</p>	1	Top right quadrant	2	Top left quadrant	3	Bottom left quadrant	4	Bottom right quadrant
1	Top right quadrant								
2	Top left quadrant								
3	Bottom left quadrant								
4	Bottom right quadrant								

Display Modes: p2

Parameter p2 of the window setup command string enables you to choose the display mode. The window setup supports two types of display modes for displaying the information from the virtual screen at the computer: cursor tracking mode and lock window mode.

Cursor tracking mode is a display mode that enables the window to follow the movement of the cursor.

Lock window mode is a display mode that enables the programmer to lock the display window in a permanent window position.

Parameter Values

When you enter...	Then display modes are...
0	cursor tracking on.
1	lock window on.

Lock Window Mode Off

When lock window mode is off, window manager automatically defaults to cursor tracking mode.

Lock Window Mode On

When lock window mode is on, the programmer must specify valid line and column positions in p3 and p4 of the command string. The line and column positions specify the location of the top left corner of the locked window.

Note: *The computer does not reposition the display window if the operator moves the cursor outside the display window.*

Related Pages

Refer to “Valid Window Positions: p3 and p4” in this section for more information on valid line positions and valid column positions.

Valid Window Positions: p3 and p4

When the computer operates in lock window mode (p2 set to 1), you must specify valid line and column positions in p3 and p4 of the command string.

Parameter p3 sets the line position for the upper left corner of the display window, and *p4* sets the column position of the upper left corner of the display window.

Note: When p2 is set to 0 (lock window mode off), the display window defaults to cursor tracking mode, which does not use predefined window positions. Parameters p3 and p4 are ignored.

Screen	Physical Window Size
Half Size	Window Size: approximately 8" wide by 3" high.
Full Size	Window Size: approximately 7.5" wide by 5.5" high.
Small	Window Size: three inches measured diagonally.

For available rows/columns, please refer to the ScreenSize parameter in Chapter 3, “TN3270 Configuration Utility”.

Refer to the following rules on valid window positions:

- When lock mode is on, the programmer must specify the display window's line/column positions in p3 and p4.
- The line and column positions must be among the valid numbers listed in the charts that follow that represent the location of the top left corner of the display window.

These coordinates define the home position of the lock window. The first number in each pair represents a line; the second a column. Your selection will vary depending on display size and whether full window movement or quadrant movement is in effect.

The 12/25 Row x 80 Column Screen

Quadrant Mode	25 row x 80 column display	12 row x 80 column display
	1, 1	1,1 7,1 13,1
Full Window Mode	25 row x 80 column display	12 row x 80 column display
	1,1	1,1 13,1

Figure 5-9 Valid Window Positions - 12 and 25 Row x 80 Column

The 10 Row x 20 Column Screen

Quadrant Mode	10 row x 20 column display							
	1,1 1,11 1,21 1,31 1,41 1,51 1,61	6,1 6,11 6,21 6,31 6,41 6,51 6,61	11,1 11,11 11,21 11,31 11,41 11,51 11,61	16,1 16,11 16,21 16,31 16,41 16,51 16,61	21,1 21,11 21,21 21,31 21,41 21,51 21,61			
Full Window Mode	10 row x 20 column display							
	1,1 1,11 1,21 1,31 1,41 1,51 1,61	11,1 11,11 11,21 11,31 11,41 11,51 11,61						

Figure 5-10 Valid Window Positions - 10 Row x 20 Column

Quadrant Mode	20 row x 20 column display							
	1,1 1,11 1,21 1,31 1,41 1,51 1,61	5,1 5,11 5,21 5,31 5,41 5,51 5,61						
Full Window Mode	10 row x 20 column display							
	1,1 1,11 1,21 1,31 1,41 1,51 1,61	5,1 5,11 5,21 5,31 5,41 5,51 5,61						

Figure 5-11 Valid Window Positions - 20 Row x 20 Column

Window Movement: p5

You must set the window movement in p5 of the command string for quadrant movement or full window movement.

Parameter Values

When you enter...	Then the window moves in...
0	quadrant movement
1	full window movement

See Chapter 3, “Daily Operation”, section titled “Window Manager” for complete information on window movement.

Quadrant for Cursor: p6

The display window is divided into four quadrants that identify sections of the virtual screen. The programmer must choose which quadrant the cursor appears in when the host sends a virtual screen to the computer:

1. Upper Right
2. Upper Left
3. Lower Left
4. Lower Right

Parameter p6 enables you to determine where the cursor appears when the host sends a screen down to the computer. The cursor appears in the specified quadrant entered in p6 once the computer receives the screen. The default for this parameter is quadrant 4.

Beep Pattern Command

The beep pattern command is an LXE private remote setup command that the programmer sends to the computer, causing the computer speaker to produce a patterned auditory signal.

Rules

- Do not include any space characters in the command string.
- The command string must be in the first field of the 3270 screen.
- The command string must be preceded by a field attribute (FA).
- The field attribute must occupy row 1, column 1.
- The patterned beep only sounds at the computer when the computer first receives the screen.
- The computer allows only one beep pattern command for each screen.
- You cannot change the volume within a screen.

This 3270 screen illustrates the command string for a beep pattern:




Figure 5-12 Beep Pattern Command String

Command String

The beep pattern command consists of the following command string:

*Bx;yyy

Elements

The elements of the beep pattern command string are listed here:

Description	Element
*B	Indicates that this is a beep pattern command string.
x	Volume control. Enter a value from 0–9. <i>Note: The lower values may not provide an audible beep for some computers.</i>
;	A required delimiter.
yyy	Beep pattern. Enter a number from 000 to 255 to indicate the pattern. See “Determine the Beep Pattern Number” in this section to determine a value for yyy.

Determine the Beep Pattern Number

The following will help you create a custom beep pattern.

The diagram presented here is a *template* for the beep pattern. Follow the instructions to calculate a value for *yyy* that will represent the beep pattern.

0	1	2	4	8	16	32	64	128
B								

Figure 5-13 Beep Pattern Template

The template is divided into boxes. Each box corresponds to a unit of time when either a beep or silence occurs.

The leftmost box always contains a B and represents a beep. This beep always occurs, regardless of the rest of the beep pattern.

0	1	2	4	8	16	32	64	128
B	B		B	B		B	B	

Figure 5-14 Beep Pattern Example

Follow this procedure to determine a beep pattern:

1. Starting from the left, put a B in the first box and in each box of the template where you want a beep to occur. Leave the boxes blank where you want a pause to occur.
2. Add the numbers listed above each box that has a B in it.

*Note: The total is the number you use in the command string for *yyy*.*

Or, using the Beep Pattern Example, add $0 + 1 + 4 + 8 + 32 + 64 = 109$

3. Enter the total from Step 2 in the *yyy* position of the command string *Bx;yyy.

*Using the example, the *yyy* total is 109.*

Result:

If you execute this command string:

**B5;109*

you will hear the computer emit three short beeps at medium volume.

Printing a Field

You can print a field in a screen with a print command (*P) in the first two character positions of the first field of your screen. The *P indicates to the *computer* to send the following characters through the RS-232 port. This feature is commonly used to print barcode labels with an attached printer.

Rules

- The *P must be preceded by a field attribute (FA).
- The field attribute must be at row 1, column 1.
- When the next FA is encountered, the print job ends.
- The value of the field attribute does not matter for this feature to work.

This 3270 screen illustrates the print command:




Figure 5-15 Print Command Example

Auto Transmit

When data stream auto transmit is enabled the *computer* automatically transmits a [SEND] when a print job ends. This notifies the host application that the print is complete and the host application can send another screen.

To enable data stream auto transmit from the host refer to “Auto Transmit after Datastream Print: p6” in this guide.

To enable data stream auto transmit from the *computer* refer to the Configuration Utility.

CR/LF

Some printers require a carriage return and/or a line feed at the end of each line.

To configure the *computer* to append a CR/LF with a host command string, refer to “Printer Carriage Return per Line: p7”, and “Printer Line Feed per Line: p8” in this guide.

To directly configure the *computer* to append a CR/LF see Configuration Utility.

Screen Print Command

Pressing key sequence [CTRL] [P] at the computer sends the entire virtual screen to a printer attached to the RS-232 port.

[CTRL] [P] is a local procedure that is initiated only from the computer. It does not involve the host in any way, nor can it be initiated by the host.

See Also Chapter 2 “Daily Operation”, “TN3270 Keyed Functions”, “PRT_SCRN.”

Display Window and Virtual Screen

This section discusses the relationship of the display window to the virtual screen. When the host sends a 25 line x 80 column virtual screen to the RF computer, the window setup determines how the display window moves on the virtual screen. The location and content of the status line and message line are also discussed in detail.

Refer to “Command String for Window Setup” for more information about window setup.

When the host sends a virtual screen to a computer, the display window cannot show the whole virtual screen. The display window can only show parts of the virtual screen. The size of the display window varies according to the type of computer. This distinction does not apply to the 1330.

The *display window* is the part of the virtual screen viewed at the computer. Usually this window is either 10 lines x 20 columns or 20 lines x 20 columns on a small screen HHT and 12 lines by 80 columns on a Half Screen VMT. This distinction does not apply to the full screen VMT.

The *virtual screen* is a 25 line x 80 column screen that the host sends to the computer.

When the computer receives the virtual screen from the host, the computer displays portions of the virtual screen through the display window. The following illustration shows the relationship between the virtual screen and display window:




Figure 5-16 Virtual Screen and Display Window Relationship

Note: This display window is an 8 line x 40 column display.

Status Line

The status line is usually the last line on the virtual screen. You must decide whether the status line is displayed on exception only or never displayed. This line uses up to 80 character positions and stores data for display.

The status line is located on line 25 of the virtual screen.

Behavior

When the status line is displayed, it overwrites the last line of the display window. If the cursor is on the bottom line of the display, the status line can overwrite the cursor position. However, the previous virtual screen appears when the operator enters valid data. When the cursor moves out of the bottom line of the display window, the status line appears again.

When the window movement keys are used to move the window or when cursor tracking occurs, the status line is not removed from the display window. The status line always appears at the bottom of the display.

Removing the Status Line

If the cursor is overwritten and the computer operator enters valid data, the status line is removed from the display window and the operator views the entered data.

Modes of Operation

Window manager supports the following modes of operation for the status line:

- Always off in which case the status line never appears.
- Display on command by operator action at the keyboard.
- Display on exception only, which occurs when either an X (keyboard lock) or a T (time) error message occurs.

Message Line

The LXE 3270 emulation supports a message line that the host can address. The message line is displayed before the status line in the current display window on the computer and is shown in its full 80-character length on the display window.

The host specifies a line as the message line and the message line appears in the display window above the status line. The message line is used for error messages from the host.

Display Window

Window manager enables the terminal emulation to identify when the message line is active and which line of the virtual screen contains the 80 characters of data.

Overwriting the Display

The message line overwrites information on the display, but the message line does not overwrite the status line. They are displayed at the same time with the message line shown above the status line.

Removing the Message Line

If the cursor is overwritten and the computer operator enters valid data, the message line is removed from the display window and the operator views the entered data.

Window Movement Keys

If the operator moves the window with the window movement keys, the message line does not follow the display window.

Table of Contents

APPENDIX A EBCDIC CODE PAGES	A-1
USA/Canada EBCDIC Code Page 00037	A-1
LXE Character Set.....	A-2
Decimal - Hexadecimal Equivalents	A-3
DOS U.S. PC Standard Character Set	A-5



USA/Canada EBCDIC Code Page 00037

	4	5	6	7	8	9	A	B	C	D	E	F
0	Sp SP010000	Sp SM030000	& SP000000	- SP100000	ø L0610000	ø L0620000	ø SM190000	ø SM170000	µ SD150000	^ SD140000	{ SM110000	\ SM070000
1	Req Space SP300000	é LE110000	/ SP120000	É LE120000	a LA010000	j LA010000	~ AD190000	f SC020000	A LA020000	J LJ020000	÷ SA060000	0 ND010000
2	â LA150000	ê LE150000	Â LA160000	Ê LE160000	b LB010000	k LK010000	s LS010000	¥ SC050000	B LB020000	K LK020000	S LS020000	2 ND020000
3	ã LA170000	ë LE170000	Ä LA180000	Ë LE180000	c LC010000	l LL010000	t LT010000	.	C LC020000	L LL020000	T LT020000	3 ND030000
4	à LA130000	è LE130000	À LA140000	È LE140000	d LD010000	m LM010000	u LU010000	© SM520000	D LD020000	M LM020000	U LU020000	4 ND040000
5	á LA110000	í LJ110000	Á LA120000	Í LJ120000	e LE010000	n LN010000	v LY010000	§ SM240000	E LE020000	N LN020000	V LY020000	5 ND050000
6	ã LA190000	í LJ150000	Ä LA200000	Î LJ160000	f LF010000	o LO010000	w LW010000	¶ SM250000	F LF020000	O LO020000	W LW020000	6 ND060000
7	ã LA270000	ÿ LJ170000	Ä LA280000	Ï LJ180000	g LG010000	p LP010000	x LX010000	¼ NF040000	G LG020000	P LP020000	X LX020000	7 ND070000
8	ç LC410000	ì LJ130000	Ç LC420000	Ì LJ140000	h LH010000	q LQ010000	y LY010000	½ NF010000	H LH020000	Q LQ020000	Y LY020000	8 ND080000
9	ñ LN190000	ß LS610000	Ñ LN200000	ñ SD130000	i LJ010000	r LR010000	z LZ010000	¾ NF050000	I LJ020000	R LR020000	Z LZ020000	9 ND090000
A	¢ SC040000	\$ SP020000	% SC030000	# SP080000	ø SM0650000	ø SP130000	ø SP170000	ø SM210000	ø SP030000	[SM060000	(SHY) SP320000	ND010000
B	.	,	,	,	ø SM020000	ø SP050000	ø SP180000	ø SM200000	ø SP160000]	ø SM080000	ND020000
C	< SA330000	*	%	@ SP040000	ø SM050000	ø LD630000	ø LA510000	ø LD620000	ø SM150000	-	ö SM170000	ND031000
D	(SP060000) SP070000	,	,	ø SP050000	ø LY110000	ø SD410000	ø LY120000	ø SD170000	..	ò LJ130000	Û LJ150000
E	+	;	>	=	ø SA040000	ø LT630000	ø LA520000	ø LT640000	ø SD110000	'	ó LJ110000	Û LJ120000
F	SA010000	SP140000	?	"	ø SA050000	ø LT630000	ø LA530000	ø SA020000	ø SC010000	×	ð SA070000	Û LJ170000
												(EO)

LXE Character Set

	2	3	4	5	6	7	8	9	A	B	C	D	E	F
0	Sp010000	ND100000	SN050000	LP010000	SD130000	LP010000	SF110000	SP120000	SM190000	LA140000	LG200000	LA130000	LA130000	÷
1	!	1	A	Q	a	q	ü	æ	í	È	Ý	Ø	ß	±
2	"	2	B	R	b	r	é	Æ	ó	Ê	(R)	–	Γ	≥
3	#	3	C	S	c	s	â	ô	ú	Ë	(C)	"	π	≤
4	\$	4	D	T	d	t	ã	ö	ñ	ß	¾		Σ	(
5	%	5	E	U	e	u	à	ò	Ñ	ø	ð	˜	σ)
6	&	6	F	V	f	v	å	û	a	í	Ô	¶	÷	
7	'	7	G	W	g	w	ç	ù	o	î	Ô	¶	τ	
8	(8	H	X	h	x	ê	ÿ	å	í	Ï	¶	μ	
9)	9	I	Y	i	y	ë	Ö	“	î	Ï	¶	~	
A	*	:	J	Z	j	z	è	Ü	”	ï	Ó	+	φ	
B	+	,	K	[k	{	í	¢	½	¶	Ó	¶	Θ	.
C	,	<	L	\	l		î	£	¼	¶	Û	¶	Ω	.
D	-	=	M]	m	}	ì	¥	í	SM20000	LE160000	LE120000	LE140000	LE130000
E	.	>	N	^	n	~	Ä	Å	«	SP180000	LE180000	LE160000	LE140000	LE130000
F	/	?	O	o	ä	å	Å	SM530000	SM060000	NF050000	LG640000	LG660000	LG680000	LG700000
								SC070000	SD190000	SD110000	LA120000	LA110000	LA100000	LY170000

Decimal - Hexadecimal Equivalents

0.....	0x00	54.....	0x36	108.....	0x6C
1.....	0x01	55.....	0x37	109.....	0x6D
2.....	0x02	56.....	0x38	110.....	0x6E
3.....	0x03	57.....	0x39	111.....	0x6F
4.....	0x04	58.....	0x3A	112.....	0x70
5.....	0x05	59.....	0x3B	113.....	0x71
6.....	0x06	60.....	0x3C	114.....	0x72
7.....	0x07	61.....	0x3D	115.....	0x73
8.....	0x08	62.....	0x3E	116.....	0x74
9.....	0x09	63.....	0x3F	117.....	0x75
10.....	0x0A	64.....	0x40	118.....	0x76
11.....	0x0B	65.....	0x41	119.....	0x77
12.....	0x0C	66.....	0x42	120.....	0x78
13.....	0x0D	67.....	0x43	121.....	0x79
14.....	0x0E	68.....	0x44	122.....	0x7A
15.....	0x0F	69.....	0x45	123.....	0x7B
16.....	0x10	70.....	0x46	124.....	0x7C
17.....	0x11	71.....	0x47	125.....	0x7D
18.....	0x12	72.....	0x48	126.....	0x7E
19.....	0x13	73.....	0x49	127.....	0x7F
20.....	0x14	74.....	0x4A	128.....	0x80
21.....	0x15	75.....	0x4B	129.....	0x81
22.....	0x16	76.....	0x4C	130.....	0x82
23.....	0x17	77.....	0x4D	131.....	0x83
24.....	0x18	78.....	0x4E	132.....	0x84
25.....	0x19	79.....	0x4F	133.....	0x85
26.....	0x1A	80.....	0x50	134.....	0x86
27.....	0x1B	81.....	0x51	135.....	0x87
28.....	0x1C	82.....	0x52	136.....	0x88
29.....	0x1D	83.....	0x53	137.....	0x89
30.....	0x1E	84.....	0x54	138.....	0x8A
31.....	0x1F	85.....	0x55	139.....	0x8B
32.....	0x20	86.....	0x56	140.....	0x8C
33.....	0x21	87.....	0x57	141.....	0x8D
34.....	0x22	88.....	0x58	142.....	0x8E
35.....	0x23	89.....	0x59	143.....	0x8F
36.....	0x24	90.....	0x5A	144.....	0x90
37.....	0x25	91.....	0x5B	145.....	0x91
38.....	0x26	92.....	0x5C	146.....	0x92
39.....	0x27	93.....	0x5D	147.....	0x93
40.....	0x28	94.....	0x5E	148.....	0x94
41.....	0x29	95.....	0x5F	149.....	0x95
42.....	0x2A	96.....	0x60	150.....	0x96
43.....	0x2B	97.....	0x61	151.....	0x97
44.....	0x2C	98.....	0x62	152.....	0x98
45.....	0x2D	99.....	0x63	153.....	0x99
46.....	0x2E	100.....	0x64	154.....	0x9A
47.....	0x2F	101.....	0x65	155.....	0x9B
48.....	0x30	102.....	0x66	156.....	0x9C
49.....	0x31	103.....	0x67	157.....	0x9D
50.....	0x32	104.....	0x68	158.....	0x9E
51.....	0x33	105.....	0x69	159.....	0x9F
52.....	0x34	106.....	0x6A	160.....	0xA0
53.....	0x35	107.....	0x6B	161.....	0xA1

162.....	0xA2	194.....	0xC2	225.....	0xE1
163.....	0xA3	195.....	0xC3	226.....	0xE2
164.....	0xA4	196.....	0xC4	227.....	0xE3
165.....	0xA5	197.....	0xC5	228.....	0xE4
166.....	0xA6	198.....	0xC6	229.....	0xE5
167.....	0xA7	199.....	0xC7	230.....	0xE6
168.....	0xA8	200.....	0xC8	231.....	0xE7
169.....	0xA9	201.....	0xC9	232.....	0xE8
170.....	0xAA	202.....	0xCA	233.....	0xE9
171.....	0xAB	203.....	0xCB	234.....	0xEA
172.....	0xAC	204.....	0xCC	235.....	0xEB
173.....	0xAD	205.....	0xCD	236.....	0xEC
174.....	0xAE	206.....	0xCE	237.....	0xED
175.....	0xAF	207.....	0xCF	238.....	0xEE
176.....	0xB0	208.....	0xD0	239.....	0xEF
177.....	0xB1	209.....	0xD1	240.....	0xF0
178.....	0xB2	210.....	0xD2	241.....	0xF1
179.....	0xB3	211.....	0xD3	242.....	0xF2
180.....	0xB4	212.....	0xD4	243.....	0xF3
181.....	0xB5	213.....	0xD5	244.....	0xF4
182.....	0xB6	214.....	0xD6	245.....	0xF5
183.....	0xB7	215.....	0xD7	246.....	0xF6
184.....	0xB8	216.....	0xD8	247.....	0xF7
185.....	0xB9	217.....	0xD9	248.....	0xF8
186.....	0xBA	218.....	0xDA	249.....	0xF9
187.....	0xBB	219.....	0xDB	250.....	0xFA
188.....	0xBC	220.....	0xDC	251.....	0xFB
189.....	0xBD	221.....	0xDD	252.....	0xFC
190.....	0xBE	222.....	0xDE	253.....	0xFD
191.....	0xBF	223.....	0xDF	254.....	0xFE
192.....	0xC0	224.....	0xE0	255.....	0xFF
193.....	0xC1				

DOS U.S. PC Standard Character Set

1	□	49	1	97	a
2	□	50	2	98	b
3	□	51	3	99	c
4	□	52	4	100	d
5	□	53	5	101	e
6	□	54	6	102	f
7		55	7	103	g
8		56	8	104	h
9	(tab)	57	9	105	i
10	(LF)	58	:	106	j
11		59	;	107	k
12	(FF)	60	<	108	l
13		61	=	109	m
14		62	>	110	n
15		63	?	111	o
16	□	64	€	112	p
17	□	65	À	113	q
18	□	66	Â	114	r
19	□	67	Ç	115	s
20	□	68	Ð	116	t
21	□	69	È	117	u
22	□	70	Ê	118	v
23	□	71	Ğ	119	w
24	□	72	Ĳ	120	x
25	□	73	Ĳ	121	y
26	□	74	Ĳ	122	z
27	□	75	Ĳ	123	{
28	□	76	Ĳ	124	
29	□	77	Ĳ	125	}
30	-	78	Ĳ	126	~
31		79	Ĳ	127	□
32	(space)	80	Ĳ	128	€
33	!	81	Ĳ	129	□
34	"	82	Ĳ	130	,
35	#	83	Ĳ	131	f
36	\$	84	Ĳ	132	"
37	%	85	Ĳ	133	
38	&	86	Ĳ	134	†
39	'	87	Ĳ	135	‡
40	(88	Ĳ	136	^
41)	89	Ĳ	137	‰
42	*	90	Ĳ	138	ſ
43	+	91	[139	<
44	,	92	\	140	Œ
45	-	93]	141	□
46	94	^	142	Ž
47	/	95	–	143	□
48	0	96	–	144	□

145	'	182	¶	219	Û
146	'	183	220	Ü
147	"	184	,	221	Ý
148	"	185	¹	222	Þ
149	•	186	°	223	ß
150	-	187	»	224	à
151	-	188	½	225	á
152	~	189	½	226	â
153	™	190	¾	227	ã
154	š	191	¿	228	ä
155	>	192	À	229	å
156	œ	193	Á	230	æ
157	□	194	Â	231	ç
158	ž	195	Ã	232	è
159	ÿ	196	Ä	233	é
160		197	Å	234	ê
161	í	198	Æ	235	ë
162	¢	199	Ç	236	ì
163	£	200	È	237	í
164	¤	201	É	238	î
165	¥	202	Ê	239	ï
166	¡	203	Ë	240	ð
167	§	204	Ì	241	ñ
168	“	205	Í	242	ò
169	©	206	Î	243	ó
170	ª	207	Ï	244	ô
171	«	208	Ð	245	õ
172	¬	209	Ñ	246	ö
173	-	210	Ò	247	÷
174	®	211	Ó	248	ø
175	—	212	Ô	249	ù
176	°	213	Õ	250	ú
177	±	214	Ö	251	û
178	²	215	×	252	ü
179	³	216	Ø	253	ý
180	‘	217	Ù	254	þ
181	µ	218	Ú	255	

Table of Contents

APPENDIX B KEY MAPS	B-1
The MX1 Keypad	B-1
Alpha-Numeric Keypad (60 Key)	B-1
The MX1 Numeric-Alpha Keypad (41 Key).....	B-3
The MX2 Keypad	B-5
38-key Keypad (Also 2325 Keypad)	B-5
48-key Keypad.....	B-7
The MX3 Keypad	B-9
The VX1, VX2 and VX4 Keyboards.....	B-11
The 1380 Keyboard	B-13



Appendix B Key Maps

The MX1 Keypad

Alpha-Numeric Keypad (60 Key)

Please refer to the “MX1 Reference Guide”, Appendix A “Key Maps” for detailed key-mapping information for the 60-key Alpha-Numeric keypad.

This section reflects the TN3270 specific keys and keypress sequences that can be made when the TN3270 terminal emulator is running on an **MX1 with an Alpha-Numeric 60-key keypad**.

When using a sequence of keys that includes the 2nd key, press the 2nd key first then the rest of the key sequence. Set the On/Off condition of NumLock before pressing a key sequence. There is no visual indication of the condition of NumLock.

Note: When the MX1 boots, the default condition of NumLock is On. NumLock can be set using the MX1 BIOS Setup or toggled with a 2nd-Shift-Right Arrow key sequence.

Note: When the MX1 boots, the default condition of Caps (or CapsLock) is Off. The Caps (or CapsLock) condition can be set using the MX1 BIOS Setup or toggled with a 2nd-Shift-Left Arrow key sequence. CAPS is displayed on the screen when CapsLock is On.

To get this TE result	Press These Keys and Then				Press this key
	2 nd	Shift	Ctrl	Alt	
Attn			x		A
Backtab	x				Tab
Clear			x		C (or see below)
Clear					ESC
Cursor Block/ Underline				x	B
Delete			x		D
Erase			x		V
E-Input			x		Q
Error Reset			x		R
Exit Program				x	X
Function Key Editor				x	F
Help				x	H
HomekeyA HomekeyB			x		G
Inquiry				x	I
Insert			x		I
LDUB			x		B
Log File Toggle				x	L

To get this TE result	Press These Keys and Then				Press this key
	2 nd	Shift	Ctrl	Alt	
New Line Key		x			N
Next or Tab					Tab
Printer On/Off			x		P
PRT_FLD		x			Y
PRT_SCRN		x			P
RDUB		x			F
RTM Setup			x		R
SW Rev			x		V
Send					Enter
Status Line Toggle			x		T
Sys_Req		x			S
Window Down		x			Down Arrow
Window Right		x			Right Arrow
Window Left		x			Left Arrow
Window Up		x			Up Arrow
Window Home Key			x		Up Arrow
PA1 through PA3		x			F1 through F3
PF1 through PF10					F1 through F10
PF11 through PF20			x		F1 through F10
PF21 through PF24	x				F1 through F4

The MX1 Numeric-Alpha Keypad (41 Key)

Please refer to the “MX1 Reference Guide”, Appendix A “Key Maps” for detailed key-mapping information for the 41-key Numeric-Alpha keypad.

This section reflects the TN3270 specific keys and keypress sequences that can be made when the TN3270 terminal emulator is running on an **MX1 with a Numeric-Alpha 41-key keypad**.

When using a sequence of keys that include the A/# key, first press A/#.

When using a sequence of keys that include the A/# key and the 2nd key, first press the A/# key then the 2nd key.

When using a sequence of keys that do not include the A/# key and includes the 2nd key, press the 2nd key first then the rest of the key sequence.

To get this TE result	Press These Keys and then					Press this key
	A / #	2 nd	Shift	Ctrl	Spc	
Attn	x			x		NO (A)
Backtab		x				Left Arrow
Clear	x			x		7 (C) (or see below)
Clear		x				A/# (ESC)
Cursor Block/Underline	x	x			x	YES (B)
Delete	x			x		8 (D)
Erase		x				Del
E-Input		x		x		Del
Error Reset	x			x		F4 (R)
Exit Program	x	x			x	F10 (X)
Function Key Editor	x	x			x	4 (F)
Help	x	x			x	6 (H)
HomekeyA HomekeyB		x	x			Up Arrow
Inquiry	x	x			x	1 (I)
Insert	x			x		1 (I)
LDUB	x			x		YES (B)
Log File Toggle	x	x			x	DOT (L)
New Line Key	x			x		- (N)
Next or Tab		x				Right Arrow
Printer On/Off	x	x			x	F2 (P)
PRT_FLD	x			x		F11 (Y)
PRT_SCRN	x			x		F2 (P)
RDUB	x			x		4 (F)
RTM Setup	x	x			x	F4 (R)
SW Rev	x	x			x	F8 (V)
Send						Enter
Status Line Toggle	x	x			x	F6 (T)

To get this TE result	Press These Keys and then					Press this key
	A / #	2 nd	Shift	Ctrl	Spc	
Sys_Req	x			x		F5 (S)
Window Down				x		Down Arrow
Window Right				x		Right Arrow
Window Left				x		Left Arrow
Window Up				x		Up Arrow
Window Home Key		x			x	Up Arrow or (see below)
Window Home Key		x	x	x		Up Arrow
PA1 through PA3				x		F1 through F3
PF1 through PF10						F1 through F10
PF11 through PF20		x			x	F1 through F10
PF21 through PF24			x			F1 through F4

The MX2 Keypad

38-key Keypad (Also 2325 Keypad)

Please refer to the “MX2 Reference Guide”, Appendix A “Key Maps” for detailed key-mapping information for the 38-key keypad.

This section reflects the TN3270 specific keys and keypress sequences that can be made when the TN3270 terminal emulator is running on an **MX2 with a 38-key keypad**.

Note: When running TN3270, the Flag key (International or Fn+ALT) operates as a Shift key.

When using a sequence of keys that include the Fn key, first press Fn.

The MX2 does not use the following keys normally found on a computer keyboard:

F11	F12	Open/Closed Parentheses
Scroll Lock	Pause/Break	Print Screen/SysReq
Insert	Num Lock	Numeric keypad number keys
Right Alt		Open/Closed Square Brackets
Right Ctrl		Open/Closed Curly Braces

The Caps key provides the function of computer keyboard's Left Shift, Right Shift and Caps Lock keys.

Note: DblStk means to press the key twice, or doublestrike the key.

To get this TE result	Press These Keys and Then				Press this key
	Fn	DblStk	Ctrl	Alt	
Attn			x		A
Backtab	Fn + Alt + Fn + 0 (zero)				
Clear			x		CD (or see below)
Clear					ESC
Cursor Block/ Underline		x		x	AB
Delete		x	x		CD
Erase	x				Space
E-Input	x		x		Space
Error Reset		x	x		QR
Exit Program		x		x	WX
Function Key Editor		x		x	EF
Help		x		x	GH
HomekeyA, HomekeyB	x				7
Inquiry				x	IJ
Insert			x		IJ
LDUB		x	x		AB
Log File Toggle		x		x	KL
New Line Key		x	x		MN

To get this TE result	Press These Keys and Then				Press this key
	Fn	DblStk	Ctrl	Alt	
Next or Tab	x				0
Printer On/Off		x		x	OP
PRT_FLD			x		YZ
PRT_SCRN		x	x		OP
RDUB		x	x		EF
RTM Setup		x		x	QR
SW Rev		x		x	UV
Send					Enter
Status Line Toggle		x		x	ST
Sys_Req			x		ST
Window Down	x		x		Ctrl+Fn+2
Window Right	x		x		Ctrl+Fn+6
Window Left	x		x		Ctrl+Fn+4
Window Up	x		x		Ctrl+Fn+8
Window Home Key	x		x		7
PA1 through PA3			x		F1 through F3
PF1					Ctrl+F1+F1
PF2					Ctrl+F1+F2
PF3					Ctrl+F1+F3
PF4					Ctrl+F1+F4
PF5					Ctrl+F1+F5
PF6					Ctrl+F1+Fn+F1
PF7					Ctrl+F1+Fn+F2
PF8					Ctrl+F1+Fn+F3
PF9					Ctrl+F1+Fn+F4
PF10					Ctrl+F1+Fn+F5

48-key Keypad

Please refer to the “MX2 Reference Guide”, Appendix A “Key Maps” for detailed key-mapping information for the 48-key keypad.

This section reflects the TN3270 specific keys and keypress sequences that can be made when the TN3270 terminal emulator is running on an **MX2 with a 48-key keypad**.

When using a sequence of keys that include the Fn key, first press Fn.

The MX2 does not use the following keys normally found on a computer keyboard:

F11	F12	Tab / Next
Open/Closed Curly Braces	Caps Lock	Left Shift
Right Shift	Scroll Lock	Right Alt
Right Ctrl	Numeric keypad number keys	Home
Pg Up	Pg Down	End
Num Lock		

To get this TE result	Press These Keys and Then				Press this key
	Fn	Shift	Ctrl	Alt	
Attn			x		A
Backtab				x	BkSp
Clear			x		C (or see below)
Clear					ESC
Cursor Block/ Underline				x	B
Delete			x		D
Erase					BkSp
E-Input			x		BkSp
Error Reset			x		R
Exit Program				x	X
Function Key Editor				x	F
Help				x	H
HomekeyA, HomekeyB			x		H
Inquiry				x	I
Insert			x		I
LDUB			x		B
Log File Toggle				x	L
New Line Key			x		N
Next or Tab				x	Enter
Printer On/Off				x	P
PRT_FLD			x		Y
PRT_SCRN			x		P

To get this TE result	Press These Keys and Then				Press this key
	Fn	Shift	Ctrl	Alt	
RDUB			x		F
RTM Setup				x	R
SW Rev				x	V
Send					Enter
Status Line Toggle				x	T
Sys_Req			x		S
Window Down				x	C then B
Window Right				x	C then F
Window Left				x	C then E
Window Up				x	C then A
Window Home Key				x	A then H
PA1 through PA3	x		x		1 through 3
PF1through PF10	x				1 through 0
PF11 through PF20				x	A then 1 through 0
PF21 through PF24				x	S then 1 through 4

The MX3 Keypad

Please refer to the “MX3 Reference Guide”, Appendix A “Key Maps” for detailed MX3 key-mapping information.

This section reflects the TN3270 specific keys and keypress sequences that can be made when the TN3270 terminal emulator is running on an MX3.

When using a sequence of keys that includes the 2nd key, press the 2nd key first then the rest of the key sequence. Set the On/Off condition of NumLock before pressing a key sequence. There is no visual indication of the condition of NumLock.

Note: When the MX3 boots, the default condition of NumLock is On. NumLock can be set using the MX3 BIOS Setup.

Note: When the MX3 boots, the default condition of Caps (or CapsLock) is Off. The Caps (or CapsLock) condition can be set using the MX3 BIOS Setup or toggled with a 2nd-F1 key sequence. CAPS is illuminated when CapsLock is On.

To get this TE result	Press These Keys and Then				Press this key
	2 nd	Shift	Ctrl	Alt	
Attn			x		A
Backtab	x				Tab
Clear			x		C (or see below)
Clear					ESC
Cursor Block/ Underline				x	B
Delete		x			D
Erase					Bksp
E-Input		x			Bksp
Error Reset			x		R
Exit Program				x	X
Function Key Editor				x	F
Help				x	H
HomekeyA HomekeyB		x			Left Arrow
Inquiry				x	I
Insert		x			I
LDUB		x			B
Log File Toggle				x	L
New Line Key		x			N
Next or Tab					Tab
Printer On/Off				x	P
PRT_FLD		x			Y
PRT_SCRN		x			P
RDUB		x			F

To get this TE result	Press These Keys and Then				Press this key
	2 nd	Shift	Ctrl	Alt	
RTM Setup				x	R
SW Rev				x	V
Send					Enter
Status Line Toggle				x	T
Sys_Req		x			S
Window Down		x			Down Arrow
Window Right		x			N/A on 80 column
Window Left		x			N/A on 80 column
Window Up		x			Up Arrow
Window Home Key				x	Up Arrow
PA1 through PA3		x			F1 through F3
PF1 through PF10					F1 through F10
PF11 through PF20				x	F1 through F10
PF21 through PF24	x				F1 through F4

The VX1, VX2 and VX4 Keyboards

Please refer to the “VX1 Reference Guide”, “VX2 Reference Guide” and “VX4D Reference Guide”.

This section reflects the TE specific keys and keypress sequences that can be made when the TN3270 terminal emulator is running on an LXE VX1, or for the VX2 and VX4, the LXE VMT keyboard.

When using a sequence of keys that includes the 2nd key, press the 2nd key first then the rest of the key sequence. For the VX1 and VX2 computers, NumLock is always On. NumLock may be toggled on and Off for the VX4, however the default status for NumLock is On.

When the VX computers bootup, the default condition of Caps (or Capslock) is Off. The Caps (or Capslock) condition can be set using the CMOS Setup or toggled with a 2nd + F1 key sequence. The CAPS LED is illuminated when Caps is On.

To get this TE result	Press These Keys and Then				Press this key
	2 nd	Shift	Ctrl	Alt	
Attn			x		A
Backtab	x				Tab
Clear			x		C (or see below)
Clear					ESC
Cursor Block/ Underline				x	B
Delete			x		D
Erase					Bksp
E-Input			x		Bksp
Error Reset			x		R
Exit Program				x	X
Function Key Editor				x	F
Help				x	H
HomekeyA HomekeyB	x				Left Arrow
Inquiry				x	I
Insert			x		I
LDUB			x		B
Log File Toggle				x	L
New Line Key			x		N
Next or Tab					Tab
Printer On/Off				x	P
PRT_FLD			x		Y
PRT_SCRN			x		P
RDUB			x		F
RTM Setup				x	R
SW Rev				x	V
Send					Enter

To get this TE result	Press These Keys and Then				Press this key
	2 nd	Shift	Ctrl	Alt	
Status Line Toggle				x	T
Sys_Req			x		S
Window Down ¹			x		Down Arrow
Window Right					N/A on 80-col
Window Left					N/A on 80-col
Window Up			x		Up Arrow
Window Home Key			x x	x	Up Arrow Home
PA1 through PA3			x		F1 through F3
PF1 through PF10					F1 through F10
PF11 through PF20				x	F1 through F10
PF21 through PF24		x			F1 through F4

¹ Window movement commands are not used with the VX2 and VX4 as they have a 640x480 pixel wide screen.

The 1380 Keyboard

Please refer to the "1380 Reference Guide".

This section reflects the TN3270 specific keys and keypress sequences that can be made when the TN3270 terminal emulator is running on an LXE 1380 DOS computer.

When using a sequence of keys that includes the 2nd key, press the 2nd key first then the rest of the key sequence. Set the On/Off condition of NumLock before pressing a key sequence. There is no visual indication of the condition of NumLock.

To get this TE result	Press These Keys and Then				Press this key
	2 nd	Shift	Ctrl	Alt	
Attn			x		A
Backtab	x				Tab
Clear			x		C (or see below)
Clear					ESC
Cursor Block/ Underline				x	B
Delete			x		D
Erase					Bksp
E-Input			x		Ctrl Bksp
Error Reset			x		R
Exit Program				x	X
Function Key Editor				x	F
Help				x	H
HomekeyA HomekeyB			x		Left Arrow
Inquiry				x	I
Insert			x		I
LDUB			x		B
Log File Toggle				x	L
New Line Key			x		N
Next or Tab					Tab
Printer On/Off				x	P
PRT_FLD			x		Y
PRT_SCRN			x		P
RDUB			x		F
RTM Setup				x	R
SW Rev				x	V
Send					Enter
Status Line Toggle				x	T
Sys_Req			x		S
Window Down			x		Down Arrow

To get this TE result	Press These Keys and Then				Press this key
	2 nd	Shift	Ctrl	Alt	
Window Right					N/A on 80-col
Window Left					N/A on 80-col
Window Up			x		Up Arrow
Window Home Key				x	Up Arrow
PA1 through PA3			x		F1 through F3
PF1 through PF10					F1 through F10
PF11 through PF20				x	F1 through F10
PF21 through PF24		x			F1 through F4

Index

Numeric

1380 Key Map	B-13
2.4GHz Radio Terminals only	3-38, 3-41
2325 Key Maps	2-7
3270/TN3270 Units	
Key Map Chart.....	B-11
6400 System Radio Menu.....	3-41

A

About RF Performance.....	5-1
Access Configuration Utility	3-3
Active Code Page	4-1, 4-4
ACTLU.....	5-10
ACTPU.....	5-10
Advance Mode p5	5-22
ALITimeout.....	3-37
AlphaNumericOnly	3-18
AlphaOnly	3-17
ASCII Files, Edit	4-12
Attributes	5-3
Attributes and Orders	5-3
Auto Login	3-33
Auto Transmit.....	5-4
LXE Recommendations	5-4
Auto Transmit After Data Stream Print p6.....	5-23
AutoAdvance.....	3-21
AutoEnter	3-21
Autologin.....	2-4
Autologin script file.....	2-4
AutoLoginOn.....	3-34

B

Barcode	
Data Entry	2-18
TN3270 TE	1-4
Strip Head Characters	3-22
Strip Tail Characters	3-22
Type Supported.....	2-18
Baud Rate	3-44, 3-49
BCPostStrip	3-22
BCPreStrip.....	3-22
Beep Pattern Command	5-33
Command String	5-34
Elements.....	5-34
Beep Pattern Template.....	5-35

BeeperVolume	3-43
Bind	5-10

C

Cancel	5-10
Change RF ID.....	2-6
Chapter Descriptions	1-1
character attributes.....	5-3
Character Attributes.....	5-4
Character Set	5-4
Clear Mode p3	5-21
Clear Mode Off.....	5-21
Clear Mode On	5-21
ClearData.....	3-20
Code Page	4-1
Code Page 00437 (USA)	4-1
Collisions.....	5-1
Com1BaudRate.....	3-44
Com1DataBits	3-44
Com1HalfDuplex	3-46
Com1HwFlowCtrl	3-47
Com1Interrupt	3-48
Com1Parity.....	3-45
Com1PassTermChar	3-48
Com1StopBits.....	3-45
Com1TimeOut	3-47
Com1Xon	3-46
Com2BaudRate.....	3-49
Com2DataBits	3-49
Com2HalfDuplex	3-51
Com2HwFlowCtrl	3-52
Com2Interrupt	3-53
Com2Parity.....	3-50
Com2PassTermChar	3-53
Com2StopBits.....	3-50
Com2TimeOut	3-52
Com2Xon	3-51
Command	
Nondisplayable, Displayable	5-16
Command String for Terminal Setup	
String Elements	5-18
Command String for Wildcard Match	
Characters	5-25
Command String for Wildcard Match Characters	
Command String	5-25
String Elements	5-25
Command String for Window Setup	5-27
Command String	5-27

String Elements	5-27
Command String sent by Host.....	5-17
Commands	
First Field	5-12
Multiple Fields	5-12
Communications Test	2-9
Computer Display Window	
Quadrants	2-34
CONFIG.EXE	3-2
CONFIG.INF	3-2
Configuration Program	
Modifiable Parameters	3-5
Non-Modifiable Parameters	3-5
Pre-Defined Parameters	3-5
User Defined Parameters	3-5
Configuration Utility	3-1
6400 System Radio Menu	3-41
Emulation Menu.....	3-14
Exit With Save Option	3-60
Exit Without Save	3-60
Keypresses	3-6
Main Menu	3-7
Main Menu Options	3-7
Menu Components	3-4
Passwords.....	3-3
Platform Menu	3-42
Pre-configured passwords	3-3
Protocol Menu.....	3-26
System Menu	3-10
Configuration Utility Access	3-3
Connecting to the Host	
Failure to	2-4
Constructing Match Fields.....	5-14
Constructing Predecessor Fields.....	5-14
CRPerLine	3-23
Cursor Block/Underline Toggle	2-8
Cursor Position	
Window Movement	2-28
Cursor Tracking Display Examples.....	2-34
Cursor Tracking Mode	2-22, 2-33
CursorType	3-42

D

DACTLU	5-10
DACTPU	5-10
Daily Operation	2-1
Data Entry	2-18
Barcode	2-18
Keyboard	2-18
Lock Window Mode	2-32
RS-232	2-19
Data Fails Match Test.....	5-14
Data Stream	
IBM Host Programming	5-2

Default Code Page	4-2
Default Passwords	3-11
Default Values	3-13
DigitsOnly	3-17
Directory Structure	
DOS terminal or computer	3-2
Disconnect (DISC)	5-9
Disconnect Mode (DM).....	5-9
Display	5-38
Display Modes p2	5-29
Display Version	2-8
Display Window	2-22
Display Window and Virtual Screen	5-38
Docked I/O Configuration	3-56
DockedBehavior	3-56
Document Conventions	1-2
DOS3270.EXE	3-2

E

EAN128Fnc1	3-59
EAU (Erase All Unprotected)	5-6
EBCDIC	4-1
EBCDIC.TXT	4-5
Echo	3-46, 3-51
Edit ASCII Files	4-12
Edit Function Keys	2-13
Emulation Menu	3-14
AlphaNumericOnly	3-18
AlphaOnly	3-17
AutoAdvance	3-21
AutoEnter	3-21
BCPostStrip	3-22
BCPreStrip	3-22
ClearData	3-20
CRPerLine	3-23
DigitsOnly	3-17
FullWinIncs	3-15
HostQuad	3-16
LeftJustify	3-19
LFPerLine	3-23
LockCol	3-15
LockRow	3-14
LockWindow	3-14
MatchAll	3-19
NumericOnly	3-18
ResetToLock	3-25
StatusLine	3-16
Trigger	3-23
TruncateData	3-20
Enter key	2-9
Entering Messages	
TN3270 TE	1-4
Erase All Unprotected (EAU)	5-6
Erase Function	2-8

Erase Unprotected to Address (EUA)	5-5
Erase/Write (EW)	5-6
ERRGEN	4-10
ERROOR	4-10
Error Messages	2-4
EUA (Erase Unprotected to Address)	5-5
EvtMask	3-39
EW (Erase/Write)	5-6
Examples	
IBM Host Programming.....	5-1
Exception Mode	
Status Line	2-20
Exit Program Function Keys	2-9
Exit With Save Option.....	3-60
Exit Without Save Option	3-60
Exiting TE	2-3
Extended Characters	4-2
Extended Color	5-4
Extended Field Attributes.....	5-3
extended field attributes (EFA)	5-3
Extended Highlighting.....	5-3
Extra Features, Host Programming	5-11

F

Factory Defaults	3-13
Features	
Configuration Utility.....	3-1
TN3270 TE	1-4
field attribute (FA).....	5-3
Field Attributes	5-3
Field Validation	5-3, 5-8
File Transfer	4-13
INTERLNK/INTERSVR	4-15
Flag key is Shift Key, 2325	2-7
Font File	4-3
Four Quadrants	2-34
Frame Reject (FRMR)	5-9
Full Window Movement.....	2-25
FullWinIncs	3-15
Function Key Editing	2-13
Function Key Editor	2-9

H

Hardware flow control.....	3-52
Hardware type	
Configuration Utility.....	3-54
HardwareModel	3-54
HELP3270.TXT	3-2
Highlighting	5-8
Host Command String for Terminal Setup	5-17
Host Commands (Primary)	5-9
Host Connection	

Failed	2-4
Host Connection Logic.....	3-27
Host string	
Fifth.....	3-36
Fourth.....	3-36
Second.....	3-35
Sixth	3-36
Third.....	3-35
Host1	3-28
Host1LU	3-28
Host1RLS	3-29
Host2	3-29
Host2LU	3-29
Host2RLS	3-29
Host3	3-30
Host3LU	3-30
Host3RLS	3-30
Host4	3-30
Host4LU	3-30
Host4RLS	3-30
Host5	3-31
Host5LU	3-31
Host5RLS	3-31
Host6	3-31
Host6LU	3-31
Host6RLS	3-31
HostDataTimeout	3-32
HostQuad	3-16
Hosts	3-27
Hot Keys	2-6
How to	
Determine a Beep Pattern Number	5-35
How To	
Edit ASCII Files.....	4-12
Edit Files at the Terminal	4-12
Edit MESSAGE.TXT File	4-10
Edit then Transfer Files with PC Card	4-13
Ignore changes and exit configuration utility	3-60
Restore Default Values	3-13
Save changes and exit configuration utility	3-60
Set auto login parameters	3-33
Set autologin timer	3-37
Set Emulation parameters	3-14
Set function on trigger press	3-23
Set Host parameters	3-27
set local comm port	3-56, 3-58
Set network protocol parameters	3-26
Set passwords	3-11
Set Radio parameters	3-41
Set TN logging parameters	3-39
Use INTERLNK and INTERSVR	4-15

I

IBM 3270 Commands	5-6
-------------------------	-----

IBM Attributes, Orders, and Commands	5-3
IBM Commands Supported by LXE	5-6
IBM EBCDIC	4-2
IBM Host Programming	5-1
IBM TN5250 Terminal Emulation	
Keys and Key Sequences	2-5
IC (Insert Cursor)	5-5
Implicit Partition	5-8
Inbound Structured Fields	5-8
Incompatible Keys	
Legacy	2-6
Indicator	
Keyboard Lock	2-18
Information (I)	5-9
Initial scroll key delay	3-54
InitialScrlDly	3-54
Inquire Function	2-9
Insert Cursor (IC)	5-5
INTERLNK.EXE	4-15
International Key on the 2325	2-7
Interrupt	
Com1	3-48
Com2	3-53
INTERSVR.EXE	4-15
IRDAPort	3-56

K

Key Map	
1380	B-13
MX1	B-1
MX2	B-5, B-7
MX3	B-9
Key Map Chart	
3270/TN3270 Unit	B-11
Key Mapping	4-8
Keyboard	
1330-B VMT	2-5
Data Entry	2-18
Keyboard Data Entry	
TN3270 TE	1-4
Keyboard Functions	2-5
Keyboard Lock	2-5
Indicator	2-18
Keyboard Map, Modify	4-9
Keypresses	
Configuration Utility	3-6
KEYS.TXT	4-9

L

LANG2.TXT	3-2
LANGUAGE.TXT	3-2
Left Justify Mode p2	5-20

Left Justify Off	5-20
Left Justify On	5-20
LeftJustify	3-19
LFPerLine	3-23
Lock Window	2-30
Lock Window Mode	2-22, 3-14
Lock Window Mode Off	5-29
Lock Window Mode On	5-29
LockCol	3-15
Locked Keyboard	2-5
LockRow	3-14
LockWindow	3-14
Log File Toggle	2-10
Logging Parameters	3-39
LUSTAT	5-10
LXE Character Set	4-1, 4-3, A-2
LXE Escape P	3-43
LXE.INI	3-2, 3-11
LxeEngPasswd	3-12

M

Main Menu Display	3-7
Mandatory entry	5-3
Mandatory fill	5-3
Manuals	1-3
Mapping	4-4
Maps, Keys, 2325	2-7
Match Field Commands	5-16
Match Fields	5-14
MatchAll	3-19
Menu Components	3-4
Option List	3-4
Status Bar	3-4
Title Bar	3-4
Message Line	2-36, 5-40
and Status Line	2-35
Clear	2-36
Display Window	5-40
Format	2-36
Location	5-40
Overwriting the Display	5-40
Review	2-36
Window Movement Keys	5-40
MESSAGE.TXT	3-2, 4-10
Messages	
Status Line	2-20
MF (Modify Field)	5-5
Mode	
Status Line	2-35
modifiable parameters	3-5
Modify Field (MF)	5-5
Modify TN3270 TE Parameters	3-1
MX1 Key Map	B-1
MX2 Key Map	B-5, B-7

MX3 Key Map..... B-9

N

NC Responses (Secondary) 5-9
 NMVT 5-10
 no operation (NOP) 5-3, 5-6
 non-modifiable parameters 3-5
 NormalIO 3-58
 Null 5-8
 NumericOnly 3-18

O

Off Mode
 Status Line 2-20
 OperatorPasswd 3-11
 option list 3-4
 Orders 5-5
 Outbound Structured Fields 5-7
 outbound/inbound structured fields 5-7

P

PA1, PA2, PA3 2-10
 Parameter Access Levels 3-1
 Password
 Default 3-11
 Level 3, Default 3-11
 Operator 3-3
 System Administrator 3-3
 Password Parameters 3-10
 Passwords 3-1
 Physical Window Size and Type 2-22
 Platform Menu 3-42
 BeeperVolume 3-43
 Com1BaudRate 3-44
 Com1DataRate 3-44
 Com1HalfDuplex 3-46
 Com1HwFlowCtrl 3-47
 Com1Interrupt 3-48, 3-53
 Com1Parity 3-45
 Com1PassTermChar 3-48
 Com1StopBits 3-45
 Com1TimeOut 3-47
 Com1Xon 3-46
 Com2BaudRate 3-49
 Com2DataBits 3-49
 Com2HalfDuplex 3-51
 Com2HwFlowCtrl 3-52
 Com2Parity 3-50
 Com2PassTermChar 3-53
 Com2StopBits 3-50
 Com2TimeOut 3-52

Com2Xon 3-51
 CursorType 3-42
 EAN128Fnc1 3-59
 HardwareModel 3-54
 InitialScrlDly 3-54
 IRDAPort 3-56
 Printing 3-43
 RepeatScrlDly 3-54
 Pre-Configured Passwords 3-3
 Predecessor Fields 5-14
 Primary Audience
 IBM Host Programming 5-1
 Printer Carriage Return per Line p7 5-23
 Printer Line Feed per Line p8 5-24
 Printer On/Off Function 2-11
 Printing 3-43
 Printing a Field 5-36
 Auto Transmit 5-37
 CR/LF 5-37
 Program Tab (PT) 5-5
 Prompt1 3-34
 Prompt2 3-35
 Prompt3 3-35
 Prompt4 3-36
 Prompt5 3-36
 Prompt6 3-36
 Protocol Menu 3-26
 ALITimeout 3-37
 Auto Login 3-33
 AutoLoginOn 3-34
 EvtMask 3-39
 Host1 3-28
 Host1RLS 3-29
 Host2 3-29
 Host2LU 3-29
 Host2RLS 3-29
 Host3 3-30
 Host3LU 3-30
 Host3RLS 3-30
 Host4 3-30
 Host4LU 3-30
 Host4RLS 3-30
 Host5 3-31
 Host5LU 3-31
 Host5RLS 3-31
 Host6 3-31
 Host6LU 3-31
 Host6RLS 3-31
 HostDataTimeout 3-32
 HostLU 3-28
 Hosts 3-27
 Logging Parameters 3-39
 Prompt1 3-34
 Prompt2 3-35
 Prompt3 3-35

Prompt4.....	3-36
Prompt5.....	3-36
Prompt6.....	3-36
Reply1	3-35
Reply2.....	3-35
Reply3.....	3-35
Reply4.....	3-36
Reply5.....	3-36
Reply6.....	3-36
TNLogFS	3-40
TNLogging.....	3-39
PT (Program Tab).....	5-5

Q

Quadrant for Cursor p6.....	5-33
Quadrant Window Movement	2-26
Quadrants Computer Display Window	2-34

R

RA (Repeat to Address).....	5-5
RB (Read Buffer)	5-6
Read Buffer (RB)	5-6
Read Modified (RM)	5-6
Read Modified All (RMA)	5-6
read only parameter	3-5, 3-54, 3-56
Receive Not Ready (RNR)	5-9
Receive Ready (RR)	5-9
Recordable Macro Maximum Length.....	2-13
Remote Setup From Host TN3270 TE	1-5
Removing the Message Line	5-40
Removing the Status Line.....	5-39
Repeat scroll delay	3-54
Repeat to Address (RA)	5-5
RepeatScrlDly.....	3-54
Reply Modes.....	5-8
Reply1	3-35
Reply2	3-35
Reply3	3-35
Reply4	3-36
Reply5	3-36
Reply6	3-36
REQFMS	5-10
REQMS	5-10
REQTEST	5-10
Requirements for Extra Feature Commands.....	5-11
Reset Defaults.....	3-13
Reset Key Sequence	2-5
Reset Parameters.....	3-13
ResetToLock.....	3-25

RF Header.....	5-2
RF Performance Collisions	5-1
Screen Design	5-1
RF Trailer	5-2
RM (Read Modified)	5-6
RMA (Read Modified All)	5-6
RS-232 Data Entry	2-19
RS-232 Data Entry TN3270 TE	1-4
RSHUTD	5-10
Rules Beep Pattern Command	5-33
Command String for Terminal Setup.....	5-17
Printing a Field.....	5-36
Valid Window Positions p3 and p4	5-30

S

SA (Set Attribute).....	5-5
SBA (Set Buffer Address)	5-5
Screen Design for Terminal Setup Commands	5-13
Screen Displays and screen types	3-9
Screen Print Command.....	5-37
Screen Sizes.....	2-22
Screen Wrap	2-29
script file	2-4
SDLC Commands.....	5-9
Set Attribute (SA).....	5-5
Set Buffer Address (SBA)	5-5
Set Normal Response Mode (SNRM)	5-9
SF (Start Field)	5-5
SFE (Start Field Extended)	5-5
SHIFT Key on the 2325	2-7
Signal.....	5-10
SNA Commands	5-10
Software flow control	3-46, 3-51
Special Keys	2-6, 4-8
Start Field (SF)	5-5
Start Field Extended (SFE)	5-5
Starting TE Dual TE	2-2
Manually	2-1
Single TE	2-1
status bar	3-4
Status Line	2-20, 2-35, 5-39
and Message Line	2-35
Description	5-39
Location	2-35, 5-39
Modes of Operation	5-39
Off and Exception Modes	2-20
Status Line Display Mode p9	5-24

Status Line Function.....	2-11
Status Line Messages	2-20
Status Line Mode	
Always Off.....	2-35
Exception Only	2-35
StatusLine.....	3-16
String Elements	5-18
Summary.....	5-8
Supported Orders.....	5-5
SupvPasswd.....	3-12
Swap Application	2-6
System Menu.....	3-10
LxeEngPasswd.....	3-12
Operating Mode Parameters	
DockedBehavior.....	3-56
NormalIO	3-58
OperatorPasswd	3-11
Passwords.....	3-10
Reset Defaults	3-13
SupvPasswd	3-12

T

TE Selection Menu	2-2
Multiple TEs	2-2
TELNET Host	
Autologin	2-4
Terminal Setup	5-17
Terminal Setup Commands	
Screen Design	5-13
Termination character.....	3-53
Test	5-9
Timeout feature	3-52
title bar.....	3-4
TN3270 Message Line	2-36
TN3270 TE	1-4
TN3270 TE Files	3-2
TNLogFS.....	3-40
TNLLogging	3-39
Toggle Status Line Function	2-11
Transfer Files.....	4-15
Transmit Identification (XID)	5-9
Trigger	3-23, 5-3, 5-4
LXE Recommendations	5-4
Truncate Mode p4.....	5-22
Truncate Mode Off.....	5-22
Truncate Mode On.....	5-22
TruncateData	3-20
Types of Extra Feature Commands	

Extended Commands	5-11
Terminal Setup.....	5-11

U

U.S. ASCII Character Set	A-5
UK EBCDIC Character Set	4-6
Unbind	5-10
Undocked I/O Configuration	3-58
Unnumbered Acknowledgment (UA)	5-9
Unsuccessful Host Connection.....	2-4
USA/Canada Code Page 00037	4-1
Using the Configuration Program.....	3-6
Using the Extra Feature Commands	5-11

V

Valid Window	2-30
Valid Window Positions.....	2-30, 5-31
Valid Window Positions p3 and p4	5-30
ViewAllCols	3-24
Virtual Screen	2-22
Volume, Beeper	3-43

W

W (Write)	5-6
Wildcard Match Characters	5-15, 5-25
Window Home	2-12
Window Manager	
TN3270 TE	1-5
Window Manager Software Program	2-22
Window Mode	
Cursor Tracking	2-33
Lock	2-30
Window Movement	
Cursor Position	2-28
Full	2-25
Keys	2-28
Methods	2-33
Quadrant.....	2-26
Window Movement p5	5-32
Window Movement Types	2-25
Wrap	
Window Movement	2-29
Write (W)	5-6
Write Structured Field (WSF)	5-6, 5-7
WSF (Write Structured Field)	5-6, 5-7

